

## IVEOPPE galaxy tab s9 keyboard case

# IVEOPPE Galaxy Tab S9/S8/S7 10.9-11 Inch Keyboard Case User Manual

Model: galaxy tab s9 keyboard case

## 1. INTRODUCTION

This manual provides instructions for the IVEOPPE Magnetic Bluetooth Keyboard Case, designed to enhance the functionality and protection of your compatible Samsung Galaxy Tab device. Please read this manual thoroughly before use to ensure proper operation and care.

## 2. COMPATIBILITY

This keyboard case is compatible with the following Samsung Galaxy Tab models:

- Samsung Galaxy Tab S9 FE 10.9 inch (Model: SM-X510, SM-X516B)
- Samsung Galaxy Tab S9 11 inch (Model: SM-X710, SM-X716, SM-X718) - 2023 Release
- Samsung Galaxy Tab S8 11 inch (Model: SM-X700, SM-X706) - 2022 Release
- Samsung Galaxy Tab S7 11 inch (Model: SM-T870, SM-T875, SM-T878) - 2020 Release

**Please verify your tablet's model number before installation to ensure compatibility.**



# ATTENTION

**ONLY Fit**

Samsung Galaxy Tab S9 11Inch 2023 Release  
(Model SM-X710/X716B/X718U/X700/X706/  
T870/T875/T878)



**Galaxy Tab S9 11" 2023**  
(SM-X710/X716B/X718U)



**Galaxy Tab S8/S7 11" 2022/2020**  
(SM-X700/X706/T870/T875/T878)

Image: Compatibility chart showing supported Samsung Galaxy Tab models and their dimensions.

### 3. WHAT'S IN THE BOX

Upon opening the package, please ensure all the following items are present:

- 1 x IVEOPPE Keyboard Case for Samsung Galaxy Tab S9/S9FE/S8/S7
- 1 x Bluetooth Keyboard
- 1 x USB Charging Cable
- 1 x User Manual (this document)

*Note: Tablet, S Pen, and other accessories are not included.*

### 4. SETUP

#### 4.1 Case Installation

1. Gently align your Samsung Galaxy Tab with the TPU back cover of the case.
2. Press the tablet firmly into the case, ensuring all edges and corners are securely seated. The precise

cutouts should align with all ports, buttons, and cameras.

## 4.2 Keyboard Charging

Before first use, fully charge the Bluetooth keyboard.

1. Locate the USB-C charging port on the keyboard.
2. Connect the provided USB charging cable to the keyboard and a suitable USB power adapter (not included).
3. The charging indicator light will illuminate. Once fully charged (approximately 2-3 hours), the light will change or turn off.
4. A full charge provides up to 70 hours of continuous use.

## 4.3 Bluetooth Keyboard Pairing

To connect the keyboard to your Samsung Galaxy Tab:

1. Ensure the keyboard is charged and powered on. The power switch is typically located on the side or top edge of the keyboard.
2. Activate Bluetooth on your Samsung Galaxy Tab: Go to **Settings > Connected devices > Bluetooth** and turn Bluetooth **On**.
3. On the keyboard, press the **Connect** button (often labeled with a Bluetooth symbol or 'Fn' + 'C' key combination) to enter pairing mode. The Bluetooth indicator light will flash.
4. On your tablet, search for available Bluetooth devices. The keyboard should appear as a device name (e.g., "Bluetooth Keyboard").
5. Select the keyboard from the list to pair. Follow any on-screen prompts, such as entering a pairing code.
6. Once paired, the Bluetooth indicator light on the keyboard will stop flashing, and your tablet will show the keyboard as connected.

# Detachable Wireless Keyboard

Magnetically Integrated-Waterproof Keyboard-Multiple Compatible



Image: Illustration of the detachable wireless keyboard and its magnetic attachment to the case, along with icons indicating multi-device compatibility.

## 5. OPERATING INSTRUCTIONS

### 5.1 Multiple Viewing Angles

The case features built-in anti-slip grooves that support three distinct viewing angles, allowing you to adjust your tablet for optimal comfort during typing, viewing, reading, or sketching.

- Angle 1: Approximately 120 degrees
- Angle 2: Approximately 125 degrees
- Angle 3: Approximately 130 degrees



## Multiple Viewing

It turns into a convenient stand, gives you a best viewing angle.




Image: Diagram illustrating the three adjustable viewing angles (120°, 125°, 130°) provided by the case's stand.

### 5.2 Detachable Magnetic Keyboard

The keyboard is magnetically attached to the case, allowing for easy detachment when not needed. This provides flexibility for different usage scenarios, such as using the tablet in portrait mode or reducing overall weight.

### 5.3 S Pen Holder

The case includes a dedicated S Pen holder, designed to securely store your S Pen. The S Pen is magnetically attached to a specific position on the back of the device, and the protective cover ensures it remains safe and prevents loss or slipping.

### 5.4 Auto Sleep/Wake Function

The case supports an automatic sleep/wake function. When the cover is opened, your tablet's screen will automatically wake up. Closing the cover will put your tablet to sleep, conserving battery life and protecting your screen.

# Soft TPU Back Cover Precise Cutouts

- 360 Degree Full Protect
- Easy to Install/Take Off
- Perfect Ports/Buttons Fit



Charging Port



Stylus Pen Holder



Raised Edges for Extra Protection



Sound Recorder



Speaker Cutout



Soft shock absorption



Image: Visual representation of the case's auto sleep/wake feature, showing the screen waking up when opened and turning off when closed.

## 6. MAINTENANCE

To ensure the longevity and appearance of your keyboard case, follow these maintenance guidelines:

- **Cleaning the Case:** The case is designed to be stain-resistant. For spills like ink, coffee, or food, wipe the affected area promptly with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Cleaning the Keyboard:** Use a soft, dry cloth to clean the keyboard. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the keys or ports.
- **Storage:** When not in use for extended periods, store the case and keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** While the case offers protection, avoid dropping the tablet, especially on hard surfaces, to prevent potential damage.

## 7. TROUBLESHOOTING

## 7.1 Keyboard Not Connecting

- **Check Power:** Ensure the keyboard is powered on and has sufficient battery charge.
- **Re-pair:** Delete the keyboard from your tablet's Bluetooth device list and attempt to re-pair it following the instructions in Section 4.3.
- **Tablet Bluetooth:** Verify that Bluetooth is enabled on your Samsung Galaxy Tab.
- **Interference:** Move away from other wireless devices that might cause interference.

## 7.2 Keys Not Responding

- **Battery Level:** The keyboard battery might be low. Charge the keyboard fully.
- **Connection:** Ensure the keyboard is properly connected via Bluetooth.
- **Restart:** Try turning the keyboard off and on again, then reconnect.

## 7.3 Auto Sleep/Wake Not Working

- **Case Alignment:** Ensure the tablet is correctly seated within the case and the cover closes completely.
- **Tablet Settings:** Check your tablet's display settings to ensure the sleep/wake function is enabled.

# 8. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.01 x 6.53 x 0.23 inches
Item Weight	1.57 pounds
Manufacturer	IVEOPPE
Model Number	galaxy tab s9 keyboard case
Connectivity Technology	Bluetooth, USB-C
Keyboard Description	Accessible
Special Features	Ergonomic, Foldable, Lightweight, Portable, Rechargeable
Keyboard Backlighting	Single Color
Material	Plastic, Polyurethane (PU)

# 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact IVEOPPE customer service directly through their official channels. Specific warranty terms may vary by region and retailer.

