

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TOHETO](#) /

› [TOHETO Camping String Lights JSK-L26 User Manual](#)

TOHETO JSK-L26

TOHETO JSK-L26 3-in-1 Retractable RGB Outdoor Tent Lights User Manual

Model: JSK-L26

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your TOHETO JSK-L26 3-in-1 Retractable RGB Outdoor Tent Lights. This versatile device functions as a camping lantern, a retractable string light, and a work light, offering multiple lighting modes for various outdoor and indoor settings. Please read this manual thoroughly before operation and retain it for future reference.

2. PRODUCT FEATURES

- **3-in-1 Functionality:** Combines a camping lantern, a 32.8 ft (10m) RGB string light, and a work light.
- **19 Lighting Modes:** Includes 4 Music Sync Modes, 8 Dynamic Modes, and 7 Static RGB Modes for diverse ambiance.
- **Retractable Design:** Features a quick 30-second recovery system for tangle-free storage of the string lights.
- **Rechargeable Battery:** Built-in 2200mAh lithium-ion polymer battery, offering 3.5 to 10 hours of working time.
- **USB-C Charging:** Convenient charging via the included Type-C cable. Can be used while charging.
- **Portable and Lightweight:** Compact design (Diameter: 12cm/4.72in, Height: 7cm/2.75in) weighing approximately 0.6 lbs (275g).
- **Durable and Waterproof:** IPX4 water resistance level, suitable for outdoor use.
- **Easy Hanging:** Equipped with a hook for versatile placement.

3. PACKAGE CONTENTS

Ensure all items are present upon unpacking:

- TOHETO Camping String Light Unit (JSK-L26)
- Type-C Charging Cable (USB-A to USB-C)
- User Guide (This document)

4. SETUP

4.1 Initial Charge

Before first use, fully charge the device. Connect the included USB-A to USB-C charging cable to the device's Type-C port and a compatible USB power source. The charging indicator will show charging status. A full charge typically takes 2 hours.

Note: Only USB-A to USB-C charging cables are supported. USB-C to USB-C charging cables are NOT compatible.

4.2 Deploying String Lights

1. Locate the string light outlet on the side of the main unit.
2. Gently pull the string lights out to the desired length (up to 32.8 ft).
3. Utilize the integrated hook at the end of the string lights to secure them in place, or wrap them around objects as needed.



Figure 1: Deploying the 32.8 ft RGB string lights and using the hook for fixing.



Figure 2: The TOHETO Camping String Lights illuminating a campsite at night.

5. OPERATION

5.1 Power On/Off

Press and hold the power button (usually marked with a power symbol) on the top of the unit to turn the device on or off.

5.2 Switching Modes

Once powered on, short press the mode button (often marked with a 'M' or similar symbol) to cycle through the available lighting modes. The device features 19 distinct modes:

- **4 Music Sync Modes:** Lights react to sound.
- **8 Dynamic Modes:** Various animated light patterns.
- **7 Static RGB Modes:** Solid color options.

7
SINGLE
COLOR MODE



19 TYPES NIGHT LIGHT MODE

Note: without unfolding the string of lights

8 Rhythmic Mode

4 Voice-activated Mode



Figure 3: Visual representation of various lighting modes available.



Advanced Music Sync Mode 19 modes for ambience



Figure 4: Advanced lighting modes for ambience, including music sync, dynamic, and static RGB.

5.3 Using as a Lantern or Work Light

The main unit itself functions as a camping lantern or work light. The string lights can be retracted or left deployed while using the main unit's light. The light output can be adjusted through the mode button or dedicated brightness controls if available.



Figure 5: The versatile 3-in-1 light unit in various usage scenarios.

6. CHARGING

The TOHETO JSK-L26 features a built-in 2200mAh rechargeable battery. To charge the device:

1. Locate the Type-C charging port on the unit.
2. Connect the provided USB-A to USB-C charging cable to the device and a standard USB power adapter (not included) or power bank.
3. The charging indicator will illuminate during charging and change color or turn off when fully charged.

The device can operate for up to 10 hours in string light mode and 3.5 hours in night light + string light mode on a full charge. It can also be used while charging, providing continuous illumination for extended periods.



Figure 6: Battery and charging information for the TOHETO JSK-L26 unit.

7. MAINTENANCE

7.1 Cleaning

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure the charging port cover is securely closed when not charging to maintain water resistance.


7.2 Storage

To retract the string lights, gently turn the storage handle on the unit. The lights will roll up automatically in approximately 30 seconds, preventing tangles. Store the device in a cool, dry place away from direct sunlight when not in use for extended periods. Ensure the battery is partially charged before long-term storage to preserve battery health.

32.8FT RGB STRING LIGHTS

Easy to Use, 30S Silky Storage

TOHETO



Hook Fixing



Tangle-free




Figure 7: Retracting the string lights for compact and tangle-free storage.

8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--|--|--|
| Device does not turn on. | Battery is depleted. | Charge the device using the provided USB-A to USB-C cable. |
| String lights are tangled during retraction. | Retraction speed too fast or uneven. | Retract the string lights slowly and evenly by turning the handle. If tangled, gently untangle manually before retracting. |
| Device not charging. | Incorrect charging cable or faulty power source. | Ensure you are using the USB-A to USB-C cable. Try a different USB power adapter or port. |

| Problem | Possible Cause | Solution |
|-------------------------------|---------------------------------------|--|
| Lights are dim or flickering. | Low battery or environmental factors. | Recharge the device. Ensure the device is not exposed to extreme temperatures. |

9. SPECIFICATIONS

| Feature | Detail |
|------------------------|---|
| Model Number | JSK-L26 |
| Brand | TOHETO |
| Power Source | Battery Powered |
| Battery Type | Rechargeable Lithium-Ion Polymer (2200mAh) |
| Charging Time | Approx. 2 hours |
| Working Time | 3.5 - 10 hours (depending on mode) |
| Light Source Type | LED |
| Wattage | 5 Watts |
| Number of Lights | 50 (on string) |
| String Light Length | 32.8 feet (10 meters) |
| Water Resistance Level | IPX4 (Waterproof) |
| Item Weight | Approx. 0.6 pounds (275g) |
| Dimensions (Unit) | Diameter: 12cm (4.72in), Height: 7cm (2.75in) |
| Material | Acrylonitrile Butadiene Styrene (ABS) |
| Special Features | Color Changing, Dimmable, Retractable String Lights, Music Sync Modes |

10. SAFETY INFORMATION

- Do not expose the device to extreme temperatures or direct flame.
- Avoid disassembling or modifying the device, as this may void the warranty and pose safety risks.
- Keep out of reach of children.
- Use only the provided or a compatible USB-A to USB-C charging cable.
- Ensure the charging port is dry before connecting the charging cable.
- Do not immerse the device in water, despite its IPX4 water resistance. IPX4 protects against splashing water from any direction, not submersion.

11. WARRANTY AND SUPPORT

TOHETO products are designed for quality and durability. If you encounter any issues or have questions regarding your TOHETO JSK-L26 Camping String Lights, please contact TOHETO US customer support. Refer to your purchase

documentation for specific warranty terms and contact information.

For support, please visit the [TOHETO Store on Amazon](#) or contact the seller directly.

