Babysense SINGLE DREAMER-2.0

Babysense Dreamer 2.0 Baby Sound Machine with Night Light User Manual

Model: SINGLE DREAMER-2.0

INTRODUCTION

The Babysense Dreamer 2.0 is an advanced baby sound machine and night light designed to create an optimal sleep environment for infants and toddlers. This device combines soothing sounds, customizable lighting, and smart features to promote healthy sleep habits. This manual provides detailed instructions for setup, operation, and maintenance to ensure you get the most out of your Dreamer 2.0.

PRODUCT FEATURES

- **Ultimate Sleep Companion:** Advanced sound and light technology for a peaceful sleep environment.
- **Customizable Soundscapes:** 28 soothing sounds including white, pink, and brown noises, lullabies, wake-up melodies, playtime music, and nature sounds.
- **Multi-Color Night Light:** Soothing multi-color night light with adjustable brightness for a calming bedtime routine and late-night check-ins.
- **Personalized Routines:** App-controlled custom sleep schedules and timers to establish healthy sleep habits.
- **Portable and Travel-Friendly:** Compact and lightweight design for consistent sleep on the go.
- **Manual & App Control:** Control features directly on the device or via the dedicated app.
- **Temperature Display:** Integrated display shows room temperature.
- **Digital Clock:** Displays current time.

PACKAGE CONTENTS

Please ensure all items are present in the package:

- Babysense Dreamer 2.0 Sound Machine with Night Light
- USB-C Charging Cable
- User Manual

Setup Instructions

Follow these steps to set up your Babysense Dreamer 2.0:

1. **Charge the Device:** Connect the Dreamer 2.0 to a power source using the provided USB-C cable. The device is battery-powered and can be used wirelessly once charged.

2. **Download the App:** Download the dedicated Babysense app (available in the USA only) from your smartphone's app store.

3. **Connect to WiFi:** Open the app and follow the on-screen instructions to connect the Dreamer 2.0 to your 2.4GHz WiFi network. This enables app control and advanced features.

4. **Placement:** Place the device on a stable, flat surface in your baby's nursery, away from direct sunlight or heat sources.

Image: The Babysense Dreamer 2.0 Sound Machine with Night Light, displaying the time, placed on a nightstand next to a teddy bear and a small potted plant.

Operating Instructions

App Control (Recommended)

The Babysense app provides full control over all features:

- **Sound Selection:** Browse and select from 28 calming sounds, including white noise, pink noise, brown noise, lullabies, wake-up melodies, playtime music, and nature sounds.

- **Volume Adjustment:** Precisely control the sound volume.

- **Light Control:** Adjust night light color (16 million RGB colors), brightness, and choose from various light modes.

- **Custom Schedules:** Create personalized sleep schedules and timers for nap time, bedtime, wake-up time, and playtime.

- **Multi-Device Control:** Manage multiple Dreamer 2.0 devices from a single app, ideal for multiple children or different rooms.

- **Favorites:** Save your preferred sound and light combinations for quick access.

Image: A hand holding a smartphone with the Babysense app open, demonstrating the ease of controlling the Dreamer 2.0's lights, sounds, and sleep settings.

Your browser does not support the video tag. Please update your browser to view this content.

Video: An official Babysense video demonstrating the features of the Dreamer 2.0 Baby Sound & Light Machine and its dedicated app,

Manual Control

The top panel of the Dreamer 2.0 features intuitive touch buttons for basic control without the app:

- **Power Button (Center 'b' logo):** Press to turn the device On/Off.

- **Play/Pause:** Start or stop the current sound.

- **Previous/Next Sound:** Cycle through available sounds.

- **Volume Up/Down:** Adjust the sound volume.

- **Brightness Up/Down:** Adjust the night light brightness.

- **Color Change ('C' button):** Cycle through different night light colors.

Image: A detailed view of the Babysense Dreamer 2.0's top panel, illustrating the layout and function of its manual control buttons for sound playback, volume, light brightness, and color changes.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Dreamer 2.0:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store in a cool, dry place when not in use for extended periods.
- **Battery Care:** For best battery life, avoid fully discharging the device frequently. Charge regularly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on	Low battery or no power connection.	Ensure the device is charged or connected to a power source.
Cannot connect to app	Incorrect WiFi network (not 2.4GHz) or incorrect password.	Verify your WiFi network is 2.4GHz. Re-enter WiFi password in the app. Ensure device is within WiFi range.
No sound or low volume	Volume is too low or muted.	Increase volume using the app or manual buttons. Check if a sound is selected.
Night light not working	Brightness is too low or light is off.	Adjust brightness using the app or manual buttons. Ensure the light is turned on.

SPECIFICATIONS

- **Brand:** Babysense
- **Model Name:** SINGLE DREAMER 2.0
- **Model Number:** SINGLE DREAMER-2.0
- **Age Range:** Baby, Toddler
- **Power Source:** Battery Powered (USB-C)
- **Number of Sounds:** 28
- **Connectivity:** 2.4GHz WiFi (US Only)
- **Color:** White
- **Material:** Plastic
- **Item Weight:** 0.5 Kilograms

WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your Babysense Dreamer 2.0, please visit the official Babysense website or contact customer service:

- **Website:** www.babysensemonitors.com
- **Email:** support@babysensemonitors.com