Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hetoy 5PW7jztUdMBlIAB7RgXUag8E

Hetoy 12V 4WD Kids Electric Ride On Dump Truck User Manual

Model: 5PW7jztUdMBlIAB7RgXUag8E

Introduction

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Hetoy 12V 4WD Kids Electric Ride On Dump Truck. Designed for children aged 3 to 8 years, this electric ride-on toy offers an engaging and realistic driving experience with its electric dump bed, shovel, and multiple control modes. Please read this manual thoroughly before assembly and use to ensure safe and proper operation.



Image: Hetoy 12V 4WD Kids Electric Ride On Dump Truck in white-green, ready for play.

Safety Information

Always supervise children during operation. Ensure the child is within the recommended age range (3-8 years) and weight limit (66 lbs max load). Ensure seat belts are securely fastened. Do not operate near stairs, steep inclines, or public roads. Always charge the battery fully before first use and after each use. Disconnect the battery when not in use for extended periods. Regularly inspect the vehicle for any loose parts, damaged wiring, or worn components. Do not allow children to stand in the dump bed while the vehicle is in motion.

Features

- **Electric Adjustable Dump Bed:** Equipped with an electric dump bed and a functional shovel for interactive play.
- **Two Driving Modes:** Child can operate manually via steering wheel and pedal, or parents can control using the remote.
- **Three-Speed Adjustments:** Manual mode offers 1.8 mph (low) and 3.1 mph (high). Remote control offers 3 adjustable speeds for enhanced safety.
- **Entertainment System:** Features music, Bluetooth connectivity, LED lights, volume control, and a battery display.
- **Enhanced Safety Features:** Includes smooth acceleration with soft start, one-touch start, seats with seat belts, lockable doors, and spring suspension.
- **Extended Playtime:** Powered by 7AH x 2 large batteries, providing up to 60 minutes of continuous driving time.
- **All-Terrain Capability:** High-quality tires ensure smooth driving on various surfaces such as lawns, concrete roads, tile roads, gravel roads, and sand.

Electric Tippling Bucket Design



Image: Electric tippling bucket design with joystick control.



Image: Two modes of driving: manual and remote control.

Setup and Assembly

Follow these steps carefully for proper assembly. Refer to the accompanying video for visual guidance.

Assembly Video Guide

Your browser does not support the video tag.

Video: Detailed installation instructions for the Hetoy Ride On Dump Truck.

Step-by-Step Assembly

1. **Unboxing and Parts Identification:** Carefully open the packaging and lay out all components. Verify that all parts listed in the manual are present.

2. **Front Axle Assembly:** Attach the front axle to the main body of the truck using the provided bolts and nuts. Ensure it is securely fastened.
3. **Rear Axle and Wheel Installation:** Install the rear axle and then attach all four wheels. Secure each wheel with the appropriate washers and nuts, ensuring they spin freely but are firmly attached.
4. **Cabin/Dashboard Installation:** Place the cabin and dashboard assembly onto the main body. Secure it with the designated screws.
5. **Steering Wheel Installation:** Insert the steering wheel into its designated slot on the dashboard. Ensure it clicks into place or is secured as per instructions. Install 2 AA batteries into the steering wheel for horn and music functions.
6. **Dump Bed Assembly and Attachment:** If the dump bed is in multiple pieces, assemble it first. Then, attach the assembled dump bed to the rear of the truck, aligning it with the electric lift mechanism. Secure it with screws.
7. **Battery Connection:** Locate the battery compartment, typically under the seat. Connect the red battery terminal to the corresponding red wire, and the black terminal to the black wire. Ensure connections are firm.
8. **Seat Assembly and Attachment:** Assemble the seat if necessary, ensuring the seat belt is properly integrated. Attach the seat to the truck body, securing it with screws.
9. **Remote Control Battery Installation:** Open the battery compartment on the remote control. Insert 2 AAA batteries, ensuring correct polarity. Close the compartment.
10. **Initial Charge:** Before first use, fully charge the vehicle's battery for the recommended duration (typically 8-12 hours). Refer to the charging section for details.



Image: Product overview with labeled components and dimensions.

Operating Instructions

Power On/Off

Locate the main power button on the dashboard. Press it to turn the vehicle on or off. The battery display will illuminate upon power-on.

Driving Modes

- **Manual Mode:** The child can operate the truck using the steering wheel and acceleration pedal. Use the gear shift lever for forward and reverse.
- **Remote Control Mode:** For younger children or parental supervision, use the provided remote control. Ensure the vehicle's mode switch is set to 'R/C' if applicable. The remote allows full control over steering, speed, and direction.

Speed Control

In manual mode, there are two adjustable speeds: 1.8 miles/h (low) and 3.1 miles/h (high). These can typically be selected via a switch on the dashboard. The remote control offers three adjustable speeds for more precise parental control.

Steering and Movement

Use the steering wheel to control direction. Press the acceleration pedal to move forward. Release the pedal to brake. Use the gear shift lever to switch between forward and reverse.

Electric Dump Bed Operation

The electric dump bed is controlled by a joystick or switch on the dashboard. Push the joystick to tilt the dump bed upwards to unload contents. Pull it back to lower the dump bed. An accompanying shovel is provided for interactive loading and unloading.



Image: How to control the electric dump bed.

Music and Bluetooth

The dashboard features buttons for music playback and Bluetooth connectivity. Follow the instructions on the dashboard panel to pair your device via Bluetooth and play music through the truck's speakers.

LED Lights

The truck is equipped with LED headlights. These can be turned on or off via a switch on the dashboard, enhancing visibility and realism.

Maintenance

Cleaning

Wipe the vehicle clean with a damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the plastic. Do not spray water directly onto electrical components.

Battery Care

Charge the battery fully before the first use (8-12 hours). After each use, recharge the battery for 8-12 hours. Do not overcharge the battery (do not exceed 18 hours). If the vehicle will not be used for an extended period, disconnect the battery and store it in a cool, dry place. Recharge the battery every 3 months to maintain its lifespan.

Tire and Component Inspection

Regularly inspect the tires for wear and tear. Check all nuts, bolts, and screws to ensure they are tight. Inspect wiring for any damage or loose connections. If any issues are found, discontinue use until repairs are made.

Troubleshooting

- **Vehicle does not move:** Check if the power switch is ON. Ensure the battery is connected and fully charged. Verify that the R/C (remote control) / Pedal switch is in the correct position. Check for any loose wiring connections.
- **Vehicle moves slowly:** The battery may be low and requires charging. The vehicle might be overloaded (exceeding 66 lbs). Check for any obstructions in the wheels or motor.
- **Remote control not working:** Ensure batteries are installed correctly in the remote and are not depleted. Check if the remote is paired with the vehicle according to the pairing instructions (usually involves holding a button on the remote while the vehicle is off, then turning the vehicle on).
- **Lights or music not working:** Check the battery level. Ensure all connections are secure. Some functions may have separate power switches.
- **Unusual noises:** Stop operation immediately. Inspect for loose parts, foreign objects caught in the wheels or motor, or damaged gears. Contact customer support if the issue persists.

Specifications

Feature	Detail
Product Dimensions	48.82 x 22.44 x 13.39 inches
Item Weight	51.1 pounds
Item Model Number	5PW7jztUdMBlIAB7RgXUag8E
Manufacturer Recommended Age	3 - 8 years
Maximum Load Capacity	66 lbs
Battery	12V (7AH x 2)
Drive System	4WD (2*35W Motors)

Speeds (Manual)	1.8 mph (low), 3.1 mph (high)
Speeds (Remote)	3 adjustable speeds
Release Date	October 6, 2024

Warranty and Support

For warranty information, technical support, or replacement parts, please contact Hetoy customer service. Keep your purchase receipt as proof of purchase for any warranty claims.
Contact information can typically be found on the product packaging or the official Hetoy website.

© 2025 Hetoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGLM5QK8

More documents and user manuals: **https://manuals.plus/**