

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Whirlpool](#) /

› [Whirlpool 8 Kg Fully Automatic Top Load Washing Machine with In-Built Heater User Manual](#)

Whirlpool 31673

Whirlpool 8 Kg Fully Automatic Top Load Washing Machine

USER MANUAL

Model: 31673

1. Product Overview

The Whirlpool 8 Kg 5 MAGIC CLEAN PRO SW H Fully Automatic Top Load Washing Machine is designed for efficient and convenient laundry care. This appliance features an in-built heater for enhanced cleaning, a robust stainless steel drum, and multiple wash programs to suit various fabric types and soil levels. It is suitable for medium to large-sized families and offers a 5-star energy rating for best-in-class efficiency.



IN-BUILT
HEATER

S T A I N W A S H

Figure 1: Front view of the Whirlpool 8 Kg Fully Automatic Top Load Washing Machine. This image displays the sleek design and top-loading access of the appliance.

2. Setup and Installation

Proper installation is crucial for the safe and efficient operation of your washing machine.


2.1 Unpacking


Carefully remove all packaging materials, including the base packaging and any protective films. Ensure all accessories listed in the "What's in the Box" section are present.

- Washing Machine
- Inlet Pipe
- Detergent Cup
- Rat Mesh
- Drain Pipe
- Drain Hose with Clamp

2.2 Positioning

Place the washing machine on a firm, level surface, away from direct sunlight and heat sources. Ensure there is adequate space around the machine for ventilation and maintenance. The machine is designed for freestanding installation.





The image shows an energy consumption label for a Whirlpool washing machine. At the top, there is a circular logo featuring a stylized figure. Below this, a green banner displays the energy consumption value **0.0104*** in white text, with **KWh/kg/cycle** written below it. A label period is specified as **1st January 2024 to 31st December 2026**. A table lists the following specifications:

Appliance	: Washing Machine
Brand	: Whirlpool
Model / Year	: VA A 80 5S / 2024
Type	: Top Load
Load Capacity	: 8.0 Kg
Water Consumption	: 16.02 L / Kg / Cycle

At the bottom, the BEE logo is displayed, featuring a lightning bolt and the text "Energy is Life, Conserve It". Below the logo, the BEE registration number **BEE/Whi/21/4/19** is shown. A disclaimer at the very bottom states: ***Under test conditions, when tested in accordance with latest IEC 60456 standards. Actual energy consumption will depend on how the appliance is being used.**

Figure 2: Front view of the washing machine, illustrating its compact footprint suitable for various spaces.

2.3 Leveling the Machine

Adjust the leveling feet at the bottom of the machine to ensure it is perfectly stable and level. An unlevel machine can cause excessive vibration and noise during operation.

2.4 Water and Drainage Connection

Connect the inlet pipe to a cold water tap and the designated inlet on the machine. Securely attach the drain hose to the machine's drain outlet and route it to a suitable drainage point, ensuring it is not kinked or blocked.

No. 1 in Cleaning Performance

Comes with an in-built heater for allergen free wash.

3 Hot Water Modes




Figure 3: Rear view of the washing machine, highlighting the water inlet and drain hose connections. Ensure these are securely fastened to prevent leaks.

2.5 Electrical Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage and frequency match the specifications of your washing machine. Do not use extension cords or adapters.

3. Operating Instructions

Familiarize yourself with the control panel and various wash programs to achieve optimal washing results.

3.1 Control Panel Overview

The control panel features push buttons for program selection, start/pause, and various options. The digital display shows cycle status and remaining time.

12 Wash Programs

Pre programmed wash options that cater to all your garments.



Figure 4: Close-up of the washing machine's control panel, showing the various buttons and display for program selection and settings.

3.2 Loading Laundry

Open the top lid and load clothes loosely into the drum. Do not overload the machine; ensure there is enough space for clothes to tumble freely. The maximum capacity is 8 kg.

3.3 Adding Detergent

Add the appropriate amount of detergent to the dispenser drawer according to the detergent manufacturer's instructions and the load size.

3.4 Washing Programs

This washing machine offers 12 pre-programmed wash options to cater to all your garments:

- **Woolens:** Gentle wash for delicate wool garments.
- **Bedsheets:** Optimized for larger items like bedsheets.
- **Daily:** Standard wash for everyday clothes.
- **Delicates:** Extra gentle cycle for fragile fabrics.
- **Eco Wash:** Energy-efficient wash cycle.
- **Heavy:** Powerful wash for heavily soiled items.
- **Stainwash+:** Specialized program for tough stain removal.

- **Whites:** Designed for white fabrics to maintain brightness.
- **Anti Bac:** Uses hot water to sanitize and remove bacteria.
- **Rinse+Dry:** Rinses and spins clothes.
- **Dry Only:** Spin cycle for drying clothes.
- **Wash Only:** Washes clothes without rinsing or spinning.



Figure 5: Visual representation of the 12 distinct wash programs available on the washing machine, offering versatility for different laundry needs.

3.5 Special Features

- **In-Built Heater:** Removes up to 50 tough stains and offers 3 hot water modes:
 - **Allergen Free:** For sanitizing clothes and removing allergens.
 - **Hot:** For heavily soiled items and whites.
 - **Warm:** For general washing and color care.



Figure 6: Illustration of the in-built heater feature, demonstrating its ability to sanitize clothes and remove tough stains using various hot water modes.

- **Hard Water Wash Program:** Adapts the wash cycle to soften hard water, ensuring effective cleaning even in

areas with high mineral content.



Figure 7: Depiction of the Hard Water Wash Technology, which optimizes washing performance in hard water conditions.

- **Zero Pressure Fill (ZPF) Technology:** Fills the wash tub effortlessly even when the water pressure is low, ensuring consistent performance.



Figure 8: Visual explanation of the Zero Pressure Fill Technology, showing how the machine fills efficiently even with low water pressure.

- **6th Sense Technology:** Senses wash requirements and automatically adjusts wash settings to suit your needs, optimizing water and energy consumption.



Figure 9: Diagram illustrating the 6th Sense Technology, which intelligently adapts wash cycles for optimal results.

- **Express Wash:** A quick wash cycle for lightly soiled clothes.
- **Delay Wash:** Allows you to set a delayed start time for your wash cycle.
- **Auto Tub Clean:** Automatically cleans the washing machine tub to prevent odor and residue buildup.

- **Spiro Wash:** Provides a superior wash experience with advanced wash motion.

4. Maintenance and Care

Regular maintenance ensures the longevity and optimal performance of your washing machine.

4.1 Cleaning the Detergent Dispenser

Periodically remove and clean the detergent dispenser drawer to prevent detergent residue buildup. Rinse it under running water and dry thoroughly before reinserting.

4.2 Cleaning the Lint Filter

Locate and clean the lint filter regularly to ensure efficient lint removal and prevent drainage issues. Refer to your machine's specific design for filter location.

4.3 Tub Cleaning

Utilize the **Auto Tub Clean** feature regularly to keep the washing machine drum clean and free from mold and mildew, which can cause unpleasant odors.

4.4 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.

5. Troubleshooting

Before contacting customer service, please refer to the following table for common issues and their potential solutions.

Problem	Possible Cause	Solution
Machine does not start	Power cord not plugged in; Lid not closed properly; Program not selected.	Check power connection; Ensure lid is fully closed; Select a wash program and press Start/Pause.
Excessive vibration/noise	Machine is not level; Shipping bolts not removed; Overloaded drum.	Adjust leveling feet; Ensure all shipping bolts are removed; Reduce laundry load.
Water not filling	Water tap is off; Water inlet hose kinked/blocked; Low water pressure.	Open water tap; Straighten hose; ZPF technology should handle low pressure, but check supply.
Water not draining	Drain hose kinked/blocked; Drain filter clogged.	Straighten drain hose; Clean drain filter.
Clothes not clean	Incorrect program selected; Too much/too little detergent; Overloaded.	Select appropriate program; Use correct detergent amount; Do not overload.

6. Technical Specifications

Specification	Value
Model Number	31673
Capacity	8 Kilograms
Operation Mode	Fully Automatic
Energy Star Rating	5 Star
Annual Energy Consumption	0.0104 KWh/Kg/cycle
Maximum Rotational Speed	740 RPM
Product Dimensions (LxWxH)	58D x 54W x 101H Centimeters
Item Weight	29 kg
Drum Material	Stainless Steel
Special Features	Inbuilt Heater, Hard Water Wash Program, ZPF Technology, Express Wash, Delay Wash, Auto Tub Clean, Spiro Wash
Number of Washing Cycles	12
Controls Type	Push Button
Manufacturer	Whirlpool
Country of Origin	India

6th Sense Technology

Senses wash requirements & automatically adjusts wash settings to suit your needs.



Figure 10: The Power Savings Guide label, indicating the 5-star energy efficiency rating and annual energy consumption of the washing machine.

7. Warranty and Support

7.1 Warranty Information

Your Whirlpool Washing Machine comes with a **2 Years Comprehensive Warranty**. Additionally, there is a **10 years additional warranty on the Motor & Prime Mover**, ensuring long-term reliability for key components. Please retain your purchase receipt for warranty claims.

7.2 Customer Support

For any queries, service requests, or technical assistance, please contact Whirlpool customer support. You can find contact details on the official Whirlpool website or through your local authorized service center.

For more information and to explore other Whirlpool products, visit the official [Whirlpool Store on Amazon](#).

