

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZdalaMit](#) /

› [ZdalaMit Non-Voice Remote Control for Realme Android FHD UHD OLED TV \(Model rmt108\)](#)

ZdalaMit rmt108

ZdalaMit Non-Voice Remote Control for Realme Android FHD UHD OLED TV (Model rmt108)

Brand: ZdalaMit | Model: rmt108

INTRODUCTION

This manual provides instructions for the ZdalaMit Non-Voice Remote Control, designed for use with various Realme Android FHD, UHD, and OLED TV models. This remote offers essential control functions without voice command capabilities, focusing on ease of use and durability.

PRODUCT FEATURES

- **Non-Voice Functionality:** Designed without voice command features, this remote provides simple and reliable control for your Realme TV.
- **Wide Compatibility:** Compatible with Realme Android FHD, UHD, and OLED TV models, ensuring seamless integration and full functionality.
- **User-Friendly & Ergonomic Design:** Designed for comfortable use with an intuitive layout, this lightweight remote ensures easy access to all essential functions.
- **Durable Construction:** Made with high-quality materials for long-lasting durability, this remote is built to withstand everyday wear and tear.
- **IR Connectivity:** Operates using Infrared (IR) technology, requiring a direct line of sight to the TV's IR receiver.

- Made from Superior Quality Material
- Long Range of Upto 28 Feet
- Electronically Tested To Ensure Quality
- IR Connectivity (No Bluetooth)



Image: Two ZdalaMit remote controls showcasing their design and highlighting features like superior quality material, long range, electronic testing, and IR connectivity.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch to open it.
3. Insert two (2) AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. **Note:** While some images may suggest AAA, this model typically uses AA batteries. Please verify the battery type indicated inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.



Image: The remote control with its battery cover removed, illustrating the correct placement for two AA batteries.

2. Initial Pairing (Automatic)

This ZdalaMit remote control is designed for automatic pairing with compatible Realme Android FHD, UHD, and OLED TVs. Once batteries are correctly installed, the remote should function immediately with your TV without additional programming steps. Simply point the remote at your TV and press the Power button to test functionality.



Image: The remote control positioned on a table in front of a television, demonstrating the simple setup process and direct access buttons for popular streaming services like Netflix and YouTube.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons on your ZdalMit remote control for optimal use.

Button	Function
Power ()	Turns the TV on or off.
Mute ()	Mutes or unmutes the TV sound.
Volume Up (+) / Down (-)	Adjusts the TV volume.
Navigation Ring (Up, Down, Left, Right)	Navigates through menus and content.
OK / Select (Center Button)	Confirms selections or opens items.
Back (←)	Returns to the previous screen or menu.
Home ()	Goes to the TV's home screen.

Button	Function
Menu (≡)	Opens the TV's main menu or settings.
Netflix, YouTube, Prime Video (Dedicated Buttons)	Direct access to these streaming applications.



Image: The remote control positioned on a wooden surface, with a television screen showing various application icons in the background, emphasizing the convenience of channel shortcuts.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

TROUBLESHOOTING

Problem	Solution
Remote not responding.	<ul style="list-style-type: none"> ◦ Check if the batteries are inserted correctly with the correct polarity. ◦ Replace old batteries with new AA alkaline batteries. ◦ Ensure there is a clear line of sight between the remote and the TV's IR receiver. ◦ Move closer to the TV.
Buttons are sticky or unresponsive.	<ul style="list-style-type: none"> ◦ Clean the remote control surface with a dry cloth. ◦ Ensure no debris is lodged around the buttons.
Remote range is reduced.	<ul style="list-style-type: none"> ◦ Replace the batteries. ◦ Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

SPECIFICATIONS

Feature	Detail
Brand	ZdalaMit
Model	rmt108
Compatible Devices	Realme Android FHD, UHD, OLED Televisions
Special Features	Ergonomic, Lightweight, Non-Voice
Connector Type	Infrared (IR)
Batteries Required	Yes (2x AA Alkaline, not included)
Product Dimensions	Approximately 10 x 10 x 10 cm (as per product data, may vary slightly)
Item Weight	Approximately 50 g

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video demonstrating the features and compatibility of the ZdalaMit Non-Voice Remote Control for Realme TVs. This video highlights the remote's design, button layout, and ease of use.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the seller's policy or contact ZdalaMit customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.