

[Manuals.plus](#) /

> [Lil' Jumbl](#) /

> Lil' Jumbl Kids Wooden Blue Kitchen Set Instruction Manual

Lil' Jumbl LIJUMKTCHSBLU

Lil' Jumbl Kids Wooden Blue Kitchen Set Instruction Manual

Model: LIJUMKTCHSBLU | Brand: Lil' Jumbl

[Overview](#) [Safety](#) [Contents](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

1. PRODUCT OVERVIEW

The Lil' Jumbl Kids Wooden Blue Kitchen Set is an all-in-one play set designed to provide engaging and educational entertainment for children. This interactive kitchen features lifelike cooking and cleaning essentials, encouraging imaginative play and kinesthetic learning.



Image 1: The complete Lil' Jumbi Kids Wooden Blue Kitchen Set, showcasing its various components.

Key Features:

- Realistic working sink with real running water.
- Stovetop with lights and sounds.
- Microwave with interactive buttons.
- Audible range hood with light.
- Refrigerator, freezer, oven, and washer/dryer compartments.
- Includes a full accessory set for immediate play.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep small parts away from children before and during assembly.
- **Choking Hazard:** Small parts. Not for children under 3 years.
- **Water Safety:** The working sink uses real water. Supervise children during water play to prevent spills and ensure proper use.
- **Battery Safety:** Requires AA and AAA batteries (not included). Follow battery installation instructions carefully. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries if the product is not used for an extended period.
- **Stability:** Ensure the kitchen set is placed on a flat, stable surface to prevent tipping.
- **Material Care:** This product is made of wood. Avoid excessive moisture to prevent damage.

3. WHAT'S IN THE BOX

Carefully unpack all components and verify that all items listed below are present and undamaged.

- Kitchen Parts (wooden panels, plastic components)
- Hardware (screws, dowels, hinges, handles)
- Accessories (pot with lid, frying pan, spatula, whisk, pretend food, cleaning supply, tableware)
- User Guide

4. SETUP AND ASSEMBLY

Assembly is required for this kitchen set. All necessary hardware and a step-by-step instruction booklet are included. A screwdriver is required (not included).

STEP-BY-STEP INSTRUCTION BOOKLET

ALL HARDWARE INCLUDED




Image 2: The included step-by-step instruction booklet and hardware for assembly.

Assembly Instructions:

1. Refer to the included instruction booklet for detailed, step-by-step assembly.
2. Ensure all wooden panels are correctly oriented before securing with screws and dowels.
3. Attach handles and hinges as indicated in the manual.
4. Install batteries in the designated compartments for electronic features (AA and AAA batteries required, not included).

Assembly Video:

For visual guidance, please refer to the assembly video below. While this video may feature a slightly different model or brand, the assembly principles are generally applicable.

Video 1: A detailed assembly guide for a kids' kitchen playset. This video demonstrates the general steps and techniques for putting together a similar wooden play kitchen, including identifying parts and using hardware.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the various interactive features of the kitchen set.

SUPER FUN, INTERACTIVE KITCHEN FOR YOUR CHILD TO EXPLORE




Image 3: An overview of the kitchen set with key features labeled, including the range hood, microwave keypad, utensil hanging knobs, dish rack, faucet, stovetop, tableware, oven door, oven knobs, washing machine door, washing machine, and large cabinet space.

5.1. Realistic Working Sink

The sink features a battery-operated faucet that dispenses real water for a true sensory experience. A removable basin is included for easy water filling and circulation.

A QUALITY SINK THAT KEEPS THINGS RUNNING!

*REQUIRES
AA BATTERIES
(NOT INCLUDED)



BATTERY-POWERED FAUCET
FOR CONTINUOUS CIRCULATION



REMOVABLE BASIN FOR
EASY WATER FILLING

Image 4: A close-up view of the battery-powered faucet in the sink, showing water circulation and the removable basin for easy refilling. Requires AA batteries (not included).

Caution: Splashing water on wooden parts can cause damage. Keep the kitchen dry after use.

CAUTION:

KEEP KITCHEN DRY!

SPLASHING WATER ON KITCHEN CAN DAMAGE WOODEN PARTS



Image 5: A visual warning to keep the wooden kitchen dry, as splashing water can damage wooden components.

5.2. Stovetop, Microwave, and Range Hood

Experience realistic lights and sounds with the stovetop, microwave, and range hood.

FEEL IMMERSSED WITH REALISTIC LIGHTS & SOUNDS!



MICROWAVE
MICROWAVE FEATURES
START/STOP BUTTONS*



STOVETOP

LIGHT UP THE
SOUND-MAKING STOVETOP



RANGE HOOD

BRIGHTEN UP YOUR STATION
WITH THE AUDIBLE RANGE HOOD

*REQUIRES AAA BATTERIES (NOT INCLUDED)

Image 6: Detailed view of the microwave with start/stop buttons, the stovetop with light-up burners and sound, and the range hood with an audible fan and light. Requires AAA batteries (not included).

- **Stovetop:** Place cookware on the burners to activate realistic lights and cooking sounds. Turn the oven knobs for clicking sounds.
- **Microwave:** Press the start/stop buttons on the microwave keypad to activate lights and sounds.
- **Range Hood:** The range hood features an audible fan and light for an immersive play experience.

5.3. Ice Dispenser

The refrigerator includes a battery-operated ice dispenser for added realism.

5.4. Washer/Dryer

The washer/dryer unit features an opening door, allowing children to pretend to do laundry.

5.5. Accessories

The kitchen set comes with a variety of bonus tools and accessories to enhance playtime.



Image 7: A collection of included accessories, such as cookware (pot, frying pan), pretend food (fruits, vegetables), tableware (cups, plates, utensils), and cleaning supplies (bottle, brush).

- **Cookware:** Use the pot and frying pan on the stovetop.
- **Pretend Food:** Engage in imaginative cooking with the included food items.
- **Tableware:** Serve meals using the cups and utensils.
- **Cleaning Supplies:** Practice cleaning up with the provided cleaning accessories.

6. MAINTENANCE

6.1. Cleaning

- Wipe down all surfaces with a soft, damp cloth.
- Avoid using abrasive cleaners or harsh chemicals, as they may damage the finish.
- For the working sink, ensure the area is thoroughly dried after each use to prevent water damage to wooden components.

6.2. Battery Replacement

- When electronic features (sink, stovetop, microwave, range hood, ice dispenser) begin to lose functionality or sound/light weakens, replace the batteries.
- Refer to the assembly manual for specific battery compartment locations and types (AA and AAA).
- Always use new batteries and dispose of old batteries responsibly.

7. TROUBLESHOOTING

If you encounter any issues with your Lil' Jumb! Kids Wooden Blue Kitchen Set, please refer to the following common solutions:

Problem	Possible Cause	Solution
Electronic features (lights, sounds) not working.	Dead or incorrectly installed batteries.	Check battery orientation and replace with fresh AA/AAA batteries.
Working sink not dispensing water.	Low water level in the basin or dead batteries.	Ensure the basin is filled with water and replace batteries if necessary.
Doors not closing properly.	Misaligned hinges or magnetic latches.	Inspect hinges for proper installation. Adjust or re-secure magnetic latches if loose.
Loose or wobbly parts.	Screws may have loosened over time.	Periodically check and tighten all screws. Avoid overtightening.

8. SPECIFICATIONS

- **Product Dimensions:** 11.6 x 41.3 x 35.2 inches
- **Item Weight:** 40.8 pounds
- **Item Model Number:** LIJUMKTCHSBLU
- **Manufacturer Recommended Age:** 36 months - 15 years
- **Manufacturer:** Lil' Jumb!

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact Lil' Jumb! customer service. Refer to the contact information provided on the product packaging or the official Lil' Jumb! website.