havit TW976

Havit TW976 True Wireless Earbuds User Manual

Model: TW976 | Brand: Havit

Introduction

Welcome to the user manual for your Havit TW976 True Wireless Earbuds. These earbuds are designed to provide a superior audio experience with stereo sound, smart touch controls, and extended playtime. This manual will guide you through the setup, operation, and maintenance of your new earbuds to ensure optimal performance and longevity.



Image: Havit TW976 True Wireless Earbuds in their charging case.

Package Contents

Please check the box for the following items:

- Havit TW976 True Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the components of your Havit TW976 earbuds and charging case.



Image: Top view of the earbuds within the charging case, showing the charging contacts and indicator light.

Earbud Components:

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **Microphone:** For hands-free calls.
- **Charging Contacts:** Connects with the charging case.
- **LED Indicator:** Shows pairing status and battery level.

Charging Case Components:

- **Earbud Slots:** Securely holds and charges the earbuds.
- **Battery Indicator LED:** Shows the charging case's battery status.
- **USB Type-C Charging Port:** For charging the case.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated, and the charging contacts align.
2. Connect the USB Type-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The indicator light on the charging case will show the charging status. Once fully charged, the light may change or turn off.
4. Charging the earbuds takes approximately 2 hours. The case provides up to 25 hours of total playtime.

2. Pairing with a Device

The Havit TW976 earbuds utilize Bluetooth 5.3 for stable and fast connections.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode, and their LED indicators will flash (e.g., white and green alternately).
3. On your device (smartphone, tablet, PC), enable Bluetooth.
4. Search for "HAVIT TW976" in the list of available Bluetooth devices.
5. Select "HAVIT TW976" to connect. Once connected, the earbud LED indicators will stop flashing and may turn off or show a steady light.
6. If pairing fails, place the earbuds back into the case, close the lid, wait a few seconds, then open it again and repeat the steps.

Operating Instructions

The Havit TW976 earbuds feature smart touch controls for easy operation.

Power On/Off:

- **Power On:** Open the charging case, or long-press the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch control area on both earbuds for 5 seconds.

Music Playback:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap the **right** earbud.
- **Previous Track:** Double tap the **left** earbud.
- **Volume Up:** Triple tap the **right** earbud.
- **Volume Down:** Triple tap the **left** earbud.

Call Management:

- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Long-press either earbud for 2 seconds during an incoming call.

Voice Assistant:

- **Activate Voice Assistant (Siri, Google Assistant, etc.):** Long-press either earbud for 2 seconds when not on a call.

Maintenance

Proper care will extend the life of your Havit TW976 earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Charging Contacts:** Periodically clean the charging contacts on both the earbuds and the case with a dry cotton swab to ensure proper charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Extreme Conditions:** Do not expose the earbuds to extreme temperatures, humidity, or liquids.

Troubleshooting

If you encounter issues with your earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting.	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "HAVIT TW976" from your device's Bluetooth list and re-pair. Place earbuds back in case, close lid, wait 5 seconds, then open and try pairing again.
Only one earbud working.	Ensure both earbuds are charged. Place both earbuds back into the charging case, close the lid, then open it again. They should re-sync. Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise a full re-pairing often works).
Low volume or poor sound quality.	Adjust volume on both earbuds and your connected device. Ensure earbuds are clean and free of debris. Check for interference from other wireless devices.
Earbuds not charging.	Ensure the charging cable is securely connected. Try a different USB port or power adapter. Clean the charging contacts on both earbuds and the case.

Specifications

Feature	Detail
Model Number	TW976

Feature	Detail
Bluetooth Version	5.3
Playtime (Earbuds)	Up to 5 hours (at moderate volume)
Talk Time (Earbuds)	Up to 3.5 hours
Total Playtime (with Charging Case)	Up to 25 hours
Charging Time (Earbuds)	Approx. 2 hours
Charging Port	USB Type-C
Wireless Range	Up to 10 meters
Weight (Earbuds)	Approx. 3.4g per earbud
Impedance	32 Ohm
Compatibility	iOS, Android, PC

Warranty and Support

Warranty Information:

Havit products are manufactured to the highest quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Havit website. Keep your proof of purchase for warranty claims.

Customer Support:

If you have any questions, require technical assistance, or experience issues not covered in this manual, please contact Havit customer support through their official website or the retailer from whom you purchased the product. Provide your product model number (TW976) and details of the issue for faster service.

© 2024 Havit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question