

[Manuals.plus](#) /

› [JOYIN](#) /

› JOYIN 24 PCS Multistyle Bouncy Balls Instruction Manual

JOYIN 17255

JOYIN 24 PCS Multistyle Bouncy Balls Instruction Manual

Model: 17255

INTRODUCTION

Thank you for choosing JOYIN Multistyle Bouncy Balls. This manual provides important information for the safe and enjoyable use of your product. Please read this manual carefully before use and retain it for future reference.

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years. Adult supervision recommended.

These bouncy balls are designed for recreational play and are suitable for various activities and occasions.

SETUP AND UNPACKING

Follow these steps to prepare your JOYIN Bouncy Balls for use:

1. Carefully open the product packaging.
2. Remove all 24 bouncy balls and the included mesh storage bag.
3. Inspect each ball for any visible defects or damage. If any are found, do not use and contact customer support.
4. Dispose of all packaging materials responsibly.



Image: A collection of 24 JOYIN Multistyle Bouncy Balls in various designs and colors, along with a white mesh storage bag.

OPERATING INSTRUCTIONS

The JOYIN Multistyle Bouncy Balls are simple to use and provide hours of entertainment. Ensure a clear play area free from obstacles and breakable items.

Basic Bouncing

- Hold a bouncy ball firmly in your hand.
- Gently drop or throw the ball onto a hard, flat surface such as a floor or pavement.
- Observe the ball's bounce. Different surfaces may yield varying bounce heights and trajectories.

High elasticity Good quality



Image: Two children playing with bouncy balls indoors, demonstrating the high elasticity and fun of the product.

Play Environment

- These balls are suitable for both indoor and outdoor play.
- Avoid playing on rough or abrasive surfaces, as this may damage the balls or reduce their lifespan.
- Always supervise young children during play to ensure safety and proper use.



Image: Three children happily playing with bouncy balls and confetti, illustrating the product's use in a celebratory setting.

CARE AND MAINTENANCE

Proper care will help maintain the quality and longevity of your bouncy balls.

Cleaning

- To clean the bouncy balls, wipe them with a damp cloth.
- If necessary, use a small amount of mild soap. Rinse thoroughly with clean water.
- Allow the balls to air dry completely before storing or reusing.
- Do not use harsh chemicals, abrasive cleaners, or expose to extreme temperatures, as these can damage the material and designs.

Storage

- Store the bouncy balls in the provided mesh storage bag when not in use.
- Keep them in a cool, dry place away from direct sunlight and heat sources.
- Proper storage helps preserve their elasticity and vibrant appearance.



Image: A white mesh storage bag filled with bouncy balls, next to several individual bouncy balls, highlighting the storage solution and variety.

TROUBLESHOOTING

If you encounter any issues with your JOYIN Bouncy Balls, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Ball does not bounce well.	Soft or uneven playing surface.	Ensure the ball is bounced on a hard, flat surface.

Problem	Possible Cause	Solution
Ball appears dirty or sticky.	Accumulation of dirt or residue from play.	Clean the ball according to the 'Care and Maintenance' section.
Ball shows signs of damage (cracks, deformities).	Excessive force, sharp objects, or prolonged exposure to harsh conditions.	Discontinue use of damaged balls. Contact customer support for assistance.

PRODUCT SPECIFICATIONS

- **Quantity:** 24 Pieces
- **Styles:** 6 assorted styles
- **Individual Ball Diameter:** Approximately 1.26 inches (32mm)
- **Material:** Durable, high-quality rubber
- **Model Number:** 17255
- **Manufacturer Recommended Age:** 3 years and up
- **Product Dimensions (Packaging):** 6.5 x 6.34 x 1.34 inches
- **Item Weight (Packaging):** 10.6 ounces

24 Pcs 6 Styles

Spliced two-tone bouncy ball *4

Transparent star bouncy ball *4

Polyhedral bouncy ball *4

Galactic bouncy ball *4

Colorful cloud elastic ball *4

Sparkling bouncy ball *4



Storage bag *1



Image: An image showing the packaging details of the 24 Pcs Multistyle Bouncy Balls, highlighting 6 styles and the 1.26 inch size.

WARRANTY INFORMATION

JOYIN products are manufactured with quality and safety in mind. While specific warranty details are not provided in this manual, for any concerns regarding manufacturing defects or product performance, please contact customer support. Please retain your proof of purchase for any potential warranty claims or returns.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your JOYIN Multistyle Bouncy Balls, please contact JOYIN customer support.

You can typically find contact information through the official JOYIN Store on Amazon or via the contact details provided with your purchase.

JOYIN Official Store: [Visit the JOYIN Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DGPLRT4C>

More documents and user manuals: <https://manuals.plus/>