

[Manuals.plus](#) /

> [BesLowe](#) /

> BesLowe 18.1-inch 2-Light Outdoor Wall Light Fixture (Model 9046) Instruction Manual

## BesLowe 9046

# BesLowe 18.1-inch 2-Light Outdoor Wall Light Fixture

MODEL: 9046

Instruction Manual

## 1. Important Safety Information

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or other hazards that could cause injury or property damage.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Use only UL or ETL listed wire connectors.
- This fixture is designed for outdoor use and is waterproof. Ensure all connections are sealed properly to maintain waterproof integrity.
- Do not exceed the maximum wattage specified for the bulbs.

## 2. Package Contents

Verify that all components are present before proceeding with installation:

- BesLowe 18.1-inch Outdoor Wall Light Fixture (1 unit)
- Mounting Hardware (screws, wire nuts, mounting plate)







Image 2.1: Main view of the BesLowe 18.1-inch 2-Light Outdoor Wall Light Fixture.

### 3. Specifications

Feature	Specification
Brand	BesLowe
Model Name	9046
Color	Matte Black
Material	Glass, Metal
Product Dimensions (L x W x H)	6.8" x 5.9" x 18.1"
Number of Light Sources	2
Bulb Base	E12
Max Wattage per Bulb	40 Watts
Voltage	120 Volts
Power Source	Hard-wired
Indoor/Outdoor Usage	Outdoor
Water Resistance Level	Waterproof



Image 3.1: Visual representation of product dimensions and key electrical specifications.

#### 4. Installation Instructions

This fixture comes pre-assembled with mounting accessories for a straightforward installation. Professional installation is recommended if you are not familiar with electrical wiring.

1. **Prepare for Installation:** Turn off power at the circuit breaker or fuse box to avoid electrical shock.
2. **Mounting Plate Installation:** Attach the mounting plate to the junction box using the provided screws. Ensure the plate is securely fastened.
3. **Wiring:** Connect the fixture's wires to the house wires. Typically, black to black (live), white to white (neutral), and green or bare copper to ground. Use the provided wire nuts and ensure all connections are tight and secure.
4. **Secure Fixture:** Align the fixture with the mounting plate and secure it using the provided screws or nuts. Ensure the fixture is flush against the wall and stable.
5. **Install Bulbs:** Insert E12 base bulbs (not included) into the sockets. Do not exceed 40W per bulb. The open bottom design allows for easy access.

6. **Restore Power:** Turn the power back on at the circuit breaker or fuse box.



Image 4.1: Key features for installation and maintenance, including the decorative top, sturdy glass, and open bottom.



Image 4.2: The fixture is compatible with various E12 base bulbs (max 40W), which are not included.

## 5. Operating Instructions

---

Once installed and powered, the BesLowe Outdoor Wall Light Fixture operates as a standard hard-wired light. It does not feature integrated smart controls or sensors.

- **Power On/Off:** Control the light fixture using your existing wall switch connected to the circuit.
- **Bulb Type:** Use E12 base bulbs. Compatible types include LED, CFL, incandescent, and halogen bulbs.
- **Wattage Limit:** Ensure the wattage of each installed bulb does not exceed 40W.

## 6. Maintenance

---

Regular maintenance ensures optimal performance and longevity of your outdoor wall light fixture.

- **Cleaning:** To clean the fixture, turn off the power at the circuit breaker. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Bulb Replacement:** Turn off power before replacing bulbs. The open bottom design allows for easy access to the E12 sockets. Carefully unscrew the old bulb and screw in a new E12 bulb, ensuring it does not exceed 40W.
- **Inspection:** Periodically inspect the fixture for any signs of wear, damage, or loose connections. Address any issues promptly to prevent potential hazards.



Image 6.1: The fixture is designed to be weather-resistant, with features for waterproof, heat, storm, and snow protection.

## 7. Troubleshooting

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	<ol style="list-style-type: none"> <li>1. Power is off</li> <li>2. Loose wiring connection</li> <li>3. Faulty bulb</li> <li>4. Faulty wall switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check circuit breaker/fuse</li> <li>2. Verify all wiring connections are secure (power off first)</li> <li>3. Replace bulb</li> <li>4. Test or replace wall switch</li> </ol>
Light flickers	<ol style="list-style-type: none"> <li>1. Loose bulb</li> <li>2. Loose wiring connection</li> <li>3. Incompatible dimmer switch (if applicable)</li> </ol>	<ol style="list-style-type: none"> <li>1. Tighten bulb</li> <li>2. Check wiring connections (power off first)</li> <li>3. Ensure dimmer switch is compatible with bulb type</li> </ol>

Water inside fixture	1. Improper sealing during installation 2. Damaged glass or seals	1. Re-seal mounting area with outdoor-grade sealant 2. Inspect for damage; contact support if necessary
----------------------	--	--

## 8. Warranty and Support

---

This BesLowe product comes with an extended warranty. For specific warranty details, claims, or technical support, please refer to the warranty card included with your purchase or contact BesLowe customer service.

For further assistance, you may visit the official BesLowe store or contact their customer support channels.

Online Support: [BesLowe Store on Amazon](#)

