

AAOBOSI 1.5 L

AAOBOSI 1.5L Ice Cream Maker with Compressor - Instruction Manual

Model: 1.5 L

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Do not use the appliance outdoors.
- Ensure the appliance is placed on a stable, level surface during operation.
- Avoid contact with moving parts.
- Do not place hands or other objects into the ice cream maker while it is operating.

2. PRODUCT OVERVIEW

The AAOBOSI 1.5L Ice Cream Maker is an automatic appliance designed for preparing homemade ice cream, yogurt, smoothies, and granitas. It features a powerful compressor for efficient cooling without pre-freezing, an intuitive LCD screen, and a durable cooling function.

Components:

- Main Unit with Compressor
- Removable Ice Cream Bucket (Aluminum)

- Mixing Paddle
- Transparent Lid with Ingredient Opening
- Cleaning Brush
- Ice Cream Scoop



Figure 2.1: Product components including the main unit, manual, recipe book, scoop, and cleaning brush.

3. SETUP AND INITIAL USE

Before first use, clean all removable parts thoroughly.

Assembly:

1. Place the removable ice cream bucket into the main unit.
2. Insert the mixing paddle into the center of the bucket, ensuring it is securely seated.
3. Place the transparent lid onto the main unit, aligning it properly and twisting to lock if applicable.



Figure 3.1: Step-by-step assembly of the ice cream maker's removable parts.

4. OPERATING INSTRUCTIONS

Follow these steps to prepare your desired frozen treats:

1. **Prepare Ingredients:** Ensure your ingredients are properly mixed and chilled according to your recipe.
2. **Add Ingredients:** Pour the prepared mixture into the removable ice cream bucket through the ingredient opening in the lid. Do not fill above the MAX fill line to allow for expansion.
3. **Close Lid:** Securely close the transparent lid.
4. **Select Mode:** Plug in the appliance. Use the **MENU** button on the control panel to cycle through the available modes (Ice Cream, Yogurt, Smoothie).
5. **Set Time:** Use the **TIME+** and **TIME-** buttons to adjust the processing time as needed. Recommended times are: Ice Cream (40 mins), Yogurt (60 mins), Smoothie (30 mins).
6. **Start Operation:** Press the **START/STOP** button to begin the process. The LCD screen will display the remaining time.
7. **Keep Warm/Cool Function:** After the cycle completes, the machine may automatically switch to a 'keep cool' function to maintain the consistency of your frozen treat.
8. **Serve:** Once the cycle is complete, use the provided scoop to remove your freshly made treat.

Figure 4.1: Operational steps for making ice cream.



Figure 4.2: Detailed view of the control panel and its functions.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your ice cream maker.

Cleaning Steps:

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Remove the transparent lid, mixing paddle, and the ice cream bucket from the main unit.
3. **Wash Removable Parts:** Hand wash the lid, mixing paddle, and ice cream bucket with warm, soapy water. Rinse thoroughly and dry completely. **Important: The interior of the aluminum ice cream bucket should not be scrubbed with a brush to avoid damage.**
4. **Clean Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
5. **Store:** Ensure all parts are dry before reassembling or storing the appliance.



Figure 5.1: Steps for disassembling and cleaning the removable parts.

6. TROUBLESHOOTING

If you encounter issues with your AAOBOSI Ice Cream Maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
Ingredients are not freezing.	Mixture not cold enough; too much mixture; lid not properly closed; ambient temperature too high.	Pre-chill ingredients before adding. Do not exceed the MAX fill line. Ensure the lid is securely closed. Operate in a cool environment.
Mixing paddle is not turning.	Paddle not installed correctly; mixture too thick; motor malfunction.	Check if the paddle is correctly seated. Ensure mixture consistency is appropriate for the machine. If the issue persists, contact customer support.
Unusual rattling noise during operation.	Loose internal component; foreign object.	Unplug the unit immediately. Inspect for any visible obstructions. If the noise continues, contact customer support.

7. SPECIFICATIONS

Detailed technical specifications for the AAOBOSI 1.5L Ice Cream Maker:

Feature	Detail
Brand	AAOBOSI
Model Number	1.5 L
Capacity	1.5 Liters
Compressor Power	150 W

Feature	Detail
Heating Power (for Yogurt)	85 W
Material	Stainless Steel
Special Features	Integrated Compressor, LCD Screen, Extra Long Cooling Function, Intuitive User Interface
Dimensions (L x W x H)	Approx. 45.5 x 30.5 x 23.9 cm (17.9 x 12.0 x 9.4 inches)
GTIN (UPC)	724087118594



Informations sur le produit

Numéro de modèle	SU-I82-Y	SU-I51-Y
Capacité	2L/2.11QT	1.5L/1.59QT
Tension	220-240V~50Hz	
Puissance	La puissance de refroidissement est de 150 W la puissance de chauffage de 85 W	
Dimension	455x305x239mm/17.9*12.0*9.4inch	

Figure 7.1: Product specifications including capacity, power, and dimensions.

8. WARRANTY AND SUPPORT

AAOBOSI products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official AAOBOSI website. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question