Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gevi Household GIMN-1000C

Gevi Household V2.0 Countertop Gemi Nugget Ice Maker

Model: GIMN-1000C

Introduction

Thank you for choosing the Gevi Household V2.0 Countertop Gemi Nugget Ice Maker. This appliance is designed to provide you with soft, chewable nugget ice, also known as pellet ice or Chewblet ice, directly from your countertop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new ice maker.



Image: The Gevi Household V2.0 Countertop Gemi Nugget Ice Maker, showcasing its stainless steel finish and a pile of nugget ice.

The Gevi nugget ice maker features a self-cleaning function, durable stainless steel housing, and a compact design that fits under most wall cabinets. It offers both manual and automatic water refill options for convenience.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury when using your ice maker, follow these basic safety precautions:

- Read all instructions before use.
- Connect to properly grounded outlets only.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.

- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for other than intended use.
- Ensure proper ventilation around the unit. Maintain at least 6 inches of clearance on both sides and the rear.

What's in the Box

Upon unpacking your Gevi Nugget Ice Maker, ensure all the following components are present:

- Gevi Nugget Ice Maker Unit
- Ice Scoop
- Ice Basket
- 10ft 1/4" Hose (for auto-refill)
- User Manual (this document)

Setup

Unpacking and Initial Placement

Carefully remove all packaging materials. Inspect the ice maker for any signs of damage. Place the unit on a flat, stable, and level surface, away from direct sunlight and heat sources. Ensure there is adequate ventilation, maintaining at least 6 inches of clearance on both sides and the rear of the appliance.

Water Filling Options

Your Gevi ice maker supports two methods for water supply:



Image: Illustration of the two water filling methods: manual pouring into the top reservoir and connecting a hose for automatic refill.

- **Manual Refill:** Open the lid and pour potable water directly into the water reservoir. The anti-drip design helps prevent spills.
- **Auto Refill:** Connect the included 10ft 1/4" hose to a water supply line. This allows for continuous water supply without manual refilling. Ensure the connection is secure to prevent leaks.

Operation

First Use and Initial Cleaning

Before first use, it is recommended to run a cleaning cycle. Fill the water reservoir, then press the "Clean" button on the control panel. This will circulate water to clean the internal components. Drain the water after the cycle is complete.

Making Ice

Once the unit is set up and filled with water, press the "On/Off" button to start the ice making process. The ice maker can produce up to 30 lbs of ice in 24 hours, with ice ready in as little as 15 minutes. The ice basket has a capacity of 4.8 lbs,

and the water reservoir holds 2.8L (3 quarts).



Image: The Gevi ice maker with its ice basket full of nugget ice, demonstrating its quick ice making and large daily production capacity.

Control Panel

The intuitive touch panel provides easy control and status indication:




Image: A detailed view of the ice maker's touch control panel, highlighting the On/Off and Clean buttons, and indicators for Making, Cleaning, Add Water, and Ice Full.

- **On/Off Button:** Powers the unit on or off.
- **Clean Button:** Initiates the self-cleaning cycle.
- **Indicators:** Lights for "Making" (ice production), "Cleaning" (self-cleaning in progress), "Add Water" (water reservoir low), and "Ice Full" (ice basket is full).

Ice Storage

The Gevi ice maker is designed with thick material insulation and double-layer space insulation to help retain ice for longer. It boasts an 80% ice retention rate at 80°F ambient temperature for 12 hours.



Image: A cutaway view of the ice maker highlighting the 1-inch thick material insulation and double-layer space insulation designed to keep ice cold.

Note: The ice basket does not have a refrigeration system. For long-term storage of ice, transfer the nugget ice to a freezer.

Maintenance

Regular cleaning and maintenance are crucial for the longevity and optimal performance of your ice maker.

Daily Cleaning

After each use, or daily, empty any remaining water from the reservoir and wipe down the interior with a soft, damp cloth. Ensure the ice basket is clean and dry before replacing it.

Self-Cleaning Function

The ice maker features an automatic self-cleaning function to ensure fresh ice and help remove limescale buildup. To activate, ensure the water reservoir is filled, then press the "Clean" button. The cycle will run automatically.



Image: An internal view of the ice maker illustrating the water circulation during the auto self-cleaning function, designed to ensure fresh ice and remove limescale.

Descaling

Limescale buildup can affect ice quality and machine performance. It is recommended to descale your ice maker once a month, or more frequently if you live in an area with hard water. Descaler is required for effective limescale removal.




Image: A map indicating water hardness levels across the United States, with recommendations for descaling frequency (monthly for moderately hard water, every two-three weeks for hard to very hard water).

Follow the instructions provided with your descaling solution. Typically, this involves adding the descaler to the water reservoir and running a cleaning cycle, followed by several rinse cycles with fresh water.

Long-Term Storage

If the ice maker will not be used for an extended period, drain all water from the reservoir and internal components. Run a cleaning cycle with fresh water, then drain completely. Dry the interior thoroughly with a soft cloth. Store the unit in a cool, dry place.

Troubleshooting

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir; Power not connected; Ambient temperature too high.	Fill water reservoir; Ensure unit is plugged in; Place unit in a cooler environment.
"Add Water" indicator is on.	Water level is low.	Add water to the reservoir.
"Ice Full" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice tastes strange or has odor.	Unit needs cleaning; Stale water; Poor water quality.	Run self-cleaning cycle; Replace water; Use filtered water.
Loud noise during operation.	Unit not level; Internal components need cleaning/descaling; Fan obstruction.	Ensure unit is on a level surface; Perform thorough cleaning and descaling; Check for obstructions around fan vents.
Ice is not nugget-shaped or is clumping.	Water quality issues; Unit needs descaling.	Use filtered water; Perform descaling as per maintenance section.

If the problem persists after attempting these solutions, please contact Gevi Household customer support.

Specifications

Feature	Detail
Brand	Gevi Household
Model Name	GIMN-1000C
Product Dimensions (D x W x H)	17.3" x 9.7" x 16.7" (44CM x 24.6CM x 42.5CM)
Capacity (Ice Production)	Max 30 lbs in 24 hours
Water Reservoir Capacity	2.8L / 3 quarts
Ice Basket Capacity	4.8 lbs
Wattage	170 watts
Voltage	120 Volts
Refrigerant	R600a
Material	Stainless Steel
Item Weight	38 pounds
UPC	767791978146

Warranty and Support

Warranty Information

Every Gevi product purchased via an official or authorized channel is entitled to a**12-Month warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

Technical Support

Gevi is committed to customer satisfaction and provides lifetime technical support for its products. If you encounter any issues with your Gevi ice maker, require assistance with setup, operation, or troubleshooting, please do not hesitate to contact our support team.

For support, please refer to the contact information provided on the Gevi Household official website or your purchase documentation. Please have your model number (GIMN-1000C) and purchase date ready when contacting support.

© 2024 Gevi Household. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGQG5RW4

More documents and user manuals: **https://manuals.plus/**