Loakdsa Compatible with Innovair AC models: WOE36C2DB2, HO10C2MR13, WO13C2DB2, HO13C2MR13, HOE36C2MR2, WO10C1DB2, HO10C1MR13, WO

Loakdsa Replacement Air Conditioner Remote Control User Manual

For Innovair AC Models: WOE36C2DB2, HO10C2MR13, WO13C2DB2, HO13C2MR13, HOE36C2MR2, WO10C1DB2, HO10C1MR13, WO13C1DB2, HO13C1MR13, WO10C2DB2, WO18C2DB2, HO18C2MR13

1. Introduction

This manual provides instructions for the proper setup, operation, and maintenance of your Loakdsa replacement remote control for Innovair air conditioning units. This remote is designed to function as a direct replacement, offering essential controls for your AC system.



Image 1.1: Front view of the Loakdsa replacement remote control, displaying temperature and mode settings.

2. Setup

2.1 Battery Installation

The remote control requires new batteries for operation. Please follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: This remote control does not require any programming or setup. It is ready for use immediately after battery installation.



Image 2.1: Rear view of the remote control with the battery cover removed, showing the battery compartment.

3. Operating Instructions

Point the remote control directly towards the infrared receiver on your air conditioning unit. Ensure there are no obstructions between the remote and the AC unit.



Image 3.1: Close-up of the remote control's display and buttons.

3.1 Button Functions

- **ON/OFF:** Press to turn the air conditioner unit on or off.
- **MODE:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TEMP ▲ / ▼:** Increases or decreases the set temperature.
- **SLEEP:** Activates or deactivates the sleep mode, which adjusts temperature for comfort during sleep.
- **SWING:** Controls the vertical louver swing function.
- **DIRECT:** Adjusts the horizontal louver direction.
- **TURBO:** Activates maximum cooling or heating for rapid temperature change.
- **LED:** Turns the display light on or off on the AC unit.
- **SHORT CUT:** Recalls a favorite or previously saved setting.
- **TIMER ON:** Sets a timer for the AC unit to turn on automatically.

- **TIMER OFF:** Sets a timer for the AC unit to turn off automatically.

4. Maintenance

To ensure the longevity and proper functioning of your remote control, please observe the following maintenance guidelines:

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display dims. Always use new batteries of the specified type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Avoid Exposure:** Keep the remote control away from direct sunlight, high temperatures, and moisture.

5. Troubleshooting

If your remote control is not functioning as expected, please try the following troubleshooting steps:

- **No Response from AC Unit:**
  - Ensure new batteries are correctly installed.
  - Check if the remote control is pointed directly at the AC unit's receiver.
  - Remove any obstructions between the remote and the AC unit.
  - Verify that the AC unit is powered on and receiving electricity.
- **Remote Display Not Working:**
  - Replace the batteries with new ones.
  - Check for any physical damage to the remote.
- **Incorrect Functionality:**
  - Ensure the remote control model is compatible with your specific Innovair AC unit model.
  - If the issue persists, contact customer support.

6. Specifications

Feature	Detail
Brand	Loakdsa
Special Feature	Universal Replacement
Compatible Devices	Innovair Air Conditioner
Connectivity Technology	Infrared
Maximum Number of Supported Devices	1
Controller Type	Infrared

Maximum Range	10 Feet
Batteries Required	AAA batteries (not included)
UPC	764965550429
ASIN	B0DGQTXZ6T

7. Warranty and Support

7.1 Return Policy

This product is subject to a 30-day return policy for refund or replacement, as per the seller's terms.

7.2 Customer Support

For any questions or concerns regarding your order or the product, please contact the seller directly. Customer inquiries are typically addressed within 24 hours.

© 2026 Loakdsa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question