

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Sanag](#) /
- › [Sanag B60S Bone Conduction Headphones User Manual](#)

Sanag B60S PRO

Sanag B60S Bone Conduction Headphones User Manual

Model: B60S PRO

1. INTRODUCTION

Thank you for choosing the Sanag B60S Bone Conduction Headphones. These open-ear, IPX8 waterproof headphones are designed for various activities, including swimming, running, and cycling, offering both Bluetooth 5.3 connectivity and a built-in 64GB MP3 player. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

2. WHAT'S IN THE BOX

- Sanag B60S Bone Conduction Headphones
- Magnetic Charging Cable

3. PRODUCT OVERVIEW

The Sanag B60S headphones feature an ergonomic, open-ear design for comfort and situational awareness. Key controls are located on the right side of the headset for easy access.



Image: Sanag B60S Bone Conduction Headphones in Beige.



Image: Diagram illustrating the button layout and functions on the Sanag B60S headphones.

Button Functions:

Button/Action	Function
Power On/Off	Long press for 3 seconds
Play/Pause Music	Short press (center button)
MP3 Mode Switch	Double press (center button)
Volume Reduction	Short press (volume down button)
Volume Increase	Short press (volume up button)
Previous Song	Short press twice (volume down button)
Next Song	Short press twice (volume up button)
Answer/Hang Up Call	Short press (center button)

Button/Action	Function
Reject Call	Long press for 1 second (center button) or long press (volume down button)
One-Touch Siri (Voice Assistant)	Long press for 1 second (volume up button)

4. SETUP

4.1 Charging the Headphones

Before first use, fully charge your Sanag B60S headphones. Use the provided magnetic charging cable. Connect the magnetic end to the charging port on the headphones and the USB end to a compatible USB power source (e.g., computer USB port, wall adapter). A full charge takes approximately 2 hours and provides up to 10 hours of playback time.

IPX8 Waterproof for Swimming




Image: Illustration of magnetic charging and battery life details.

The headphones feature built-in overcharge protection. Charging will not occur if the voltage exceeds 5V.

Overcharge Protection

Built-in 28V voltage OVP protection, charging is not possible if the voltage is greater than 5V



Image: Diagram showing the overcharge protection feature.

4.2 Loading MP3 Files (for MP3 Mode)

The Sanag B60S has a built-in 64GB memory for MP3 playback, allowing you to listen to music without a connected device, especially useful for swimming where Bluetooth signals cannot transmit underwater.

1. Connect the headphones to your computer using the magnetic charging cable.
2. The headphones will appear as a removable disk drive on your computer.
3. Drag and drop your desired MP3 audio files directly into the headphone's storage folder.
4. Safely eject the device from your computer once files are transferred.

Simple operation

Introduction to key functions

Volume Reduction: short press
Reject Call: long press (when a call comes in)
Previous Song: short press twice

Power On/Off: long press for 3 seconds
Hang Up/Answer a call: short press
Play/Pause music: short press
MP3 Mode: double press
Volume Reduction: short press
Reject Call: long press for 1 second

One-Touch Siri: long press for 1 second
Volume Increase: short press
Next Song: short press twice




Image: Headphones connected to a laptop for downloading audio files.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Long press the center button for 3 seconds.
- **To Power Off:** Long press the center button for 3 seconds.

5.2 Bluetooth Pairing

The Sanag B60S features Bluetooth 5.3 for stable and fast connections.

1. Ensure the headphones are powered on.
2. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
3. Select "Sanag B60S" from the list to pair. The headphones will indicate successful pairing.

MAGNETIC Quick charge



Image: Visual representation of the Bluetooth 5.3 chip for high-speed connection.

5.3 Switching Between Bluetooth and MP3 Mode

The headphones can operate in two modes: Bluetooth (for wireless connection to devices) and MP3 (for playing stored music). Bluetooth signals cannot transmit underwater, so MP3 mode is essential for swimming.

- To switch between Bluetooth and MP3 mode, **double press the center button.**

Leak-Free Private Listening

With the driver's decoupled design ensuring independent functionality, your audio remains private




Image: Diagram showing the difference between Bluetooth mode (no memory card needed) and MP3 mode (with 64GB memory).

5.4 Music Playback and Call Management

Refer to the