

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KLIM](#) /

› [KLIM Chroma Wireless Gaming Keyboard RGB - Instruction Manual](#)

KLIM KLIM Chroma

KLIM Chroma Wireless Gaming Keyboard RGB - Instruction Manual

Model: KLIM Chroma | Brand: KLIM

INTRODUCTION

The KLIM Chroma Wireless Gaming Keyboard RGB is designed for an optimal typing and gaming experience, offering instant connectivity, long-lasting battery life, and vibrant RGB backlighting. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.



Figure 1: KLIM Chroma Wireless Gaming Keyboard and USB receiver.

SETUP

The KLIM Chroma keyboard offers instant plug-and-play connectivity, requiring no driver installation.

1. **Unpack:** Carefully remove the keyboard and the USB receiver from the packaging.
2. **Connect USB Receiver:** Locate an available USB port on your computer (PC, Mac, PS5, PS4, Xbox, Laptop, Tablet). Insert the small USB receiver into the port.
3. **Power On:** Ensure the keyboard is powered on. The keyboard should automatically connect to the receiver.
4. **Initial Charge:** For optimal performance, it is recommended to fully charge the keyboard before first use. Connect the keyboard to a USB power source using the provided charging cable.



Figure 2: The keyboard offers instant plug-and-play connectivity via its USB receiver.

OPERATING INSTRUCTIONS

Backlighting Control

The KLIM Chroma keyboard features stunning rainbow RGB backlighting.

- **Modes:** You can switch between static and breathing light modes. Refer to the keyboard's function keys (often

indicated by an FN key combined with other keys) for specific controls.

- **On/Off:** The backlighting can be turned off completely if preferred.
- **Note:** The colors of the rainbow backlighting are not customizable.



BRING YOUR DESKTOP TO LIFE

STUNNING RGB EFFECTS

Figure 3: The keyboard features stunning RGB lighting effects.

Battery Management

The keyboard is equipped with a high-quality built-in rechargeable battery.

- **Charging:** Connect the keyboard to a USB power source using the provided cable when the battery indicator shows low charge.
- **Battery Life:** The long-lasting battery provides extended usage time between charges.

SUPER EXTENDED BATTERY LIFE



UP TO
17 HOURS



RECHARGEABLE

Figure 4: The keyboard features a super extended rechargeable battery life.

Typing Performance

The keyboard's membrane keys are designed for quick, quiet, and accurate typing.

- **Key Travel:** Short key travel distance allows for rapid keystrokes.
- **Wireless Performance:** A new generation wireless transmitter ensures performance comparable to a wired keyboard.

OUTSTANDING PERFORMANCE



FAST RESPONSE TIME



IMPROVED TYPING SPEED



QUIET AND ACCURATE

Figure 5: The keyboard offers outstanding performance with fast response and quiet, accurate typing.

MAINTENANCE

To ensure the longevity and optimal performance of your KLIM Chroma keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the keyboard surface regularly. For deeper cleaning, a slightly damp cloth can be used, ensuring no liquid enters the key switches.
- **Spill Resistance:** The keyboard is designed with water resistance. In case of accidental spills, gently wipe away the liquid immediately. Avoid submerging the keyboard in water.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

ULTRA DURABLE SPILL PROOF



Figure 6: The keyboard is ultra-durable and spill-proof.

TROUBLESHOOTING

If you encounter issues with your KLIM Chroma keyboard, try the following steps:

- **No Connection:**

- Ensure the USB receiver is securely plugged into a working USB port.
- Verify the keyboard is powered on and fully charged.
- Try plugging the USB receiver into a different USB port.
- Restart your computer or device.

- **Backlighting Not Working:**

- Check if the backlighting is turned off. Use the designated function keys to toggle it on/off or change modes.
- Ensure the keyboard has sufficient battery charge.

- **Keys Not Responding:**

- Check the connection as described under "No Connection."
- Ensure the keyboard is not in a locked mode (e.g., gaming mode that disables certain keys).
- Clean around the affected keys to remove any debris.

- **Interference:**

- Ensure there are no major obstructions between the keyboard and the USB receiver.
- Move the keyboard closer to the receiver (within 30 feet / 10 meters).
- Avoid placing the receiver near other wireless devices that might cause interference.

SPECIFICATIONS

Feature	Detail
Model Name	KLIM Chroma
Product Dimensions	17.6 x 5.68 x 1.32 inches
Item Weight	1.26 pounds
Number of Keys	104
Keyboard Type	Membrane
Connectivity Technology	USB Wireless (2.4 GHz)
Compatible Devices	PC, Mac, PS5, PS4, Xbox, Laptop, Tablet
Battery Type	1 Lithium Ion (included)
Backlighting	Rainbow RGB (static/breathing modes)
Durability	Highly-resistant ABS plastic, unique keycap coating, water resistant

KEYBOARD SIZE



17.36"




Figure 7: Keyboard dimensions for reference.



2.4 GHZ



33FT/10M*

***THERE SHOULD BE NO OBSTRUCTIONS OR INTERFERENCE FOR CONNECTIVITY**

Figure 8: Wireless connectivity details including 2.4 GHz frequency and 33ft/10m range.



PC



MAC OS



PS4



PS5



XBOX ONE



XBOX X SERIES

WIDE COMPATIBILITY
FOR WORK & PLAY

Figure 9: Wide compatibility across multiple platforms.

WARRANTY AND SUPPORT

The KLIM Chroma Wireless Gaming Keyboard comes with an unbeatable **5-year assurance**.

- **Warranty Coverage:** This assurance covers manufacturing defects and ensures the product's quality and durability for five years from the date of purchase.
- **Customer Support:** KLIM provides **24/7 support** to assist with any questions or issues you may encounter. For warranty claims or technical assistance, please refer to the contact information provided on the KLIM official website or product packaging.

