

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Nyeekey](#) /
- › [Nyeekey 6-in-1 Toddler Slide and Swing Playset Instruction Manual](#)

Nyeekey 1130

Nyeekey 6-in-1 Toddler Slide and Swing Playset

Model: 1130

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Nyeekey 6-in-1 Toddler Slide and Swing Playset. Please read all instructions carefully before assembly and use. Retain this manual for future reference.



Image: The complete Nyeekoy 6-in-1 Toddler Slide and Swing Playset, featuring a slide, swing, basketball hoop, football goal, and ring toss game.

SAFETY GUIDELINES

WARNING: Adult supervision is required at all times. Failure to follow these instructions may result in serious injury.

- **Age Recommendation:** Suitable for toddlers aged 1-8 years.
- **Weight Limits:** Maximum weight for the slide is 132 lbs (60 kg). Maximum weight for the swing is 88 lbs (40 kg).
- **Assembly:** Ensure all parts are correctly assembled and securely fastened before use. Regularly check for loose connections.
- **Placement:** Place the playset on a level, soft surface such as grass or a play mat. Avoid hard surfaces like concrete or asphalt. Ensure adequate clear space around the playset.
- **Hazards:** Keep children away from potential hazards such as ropes, cords, or sharp objects. Do not allow children to wear loose clothing or jewelry that could get caught.
- **Weather Conditions:** Do not use the playset in extreme weather conditions (e.g., strong winds, heavy

rain, snow). If used outdoors, protect from prolonged sun exposure to prevent material degradation.

- **Inspection:** Before each use, inspect the playset for any damage, wear, or missing parts. Discontinue use if any issues are found and contact customer support.

Multifunctional Adjustable Football Stand



Image: Close-up view of the playset's protective pedals and easy-grip handrails, designed for child safety during climbing.

PRODUCT OVERVIEW

The Nyeekoy 6-in-1 Toddler Playset offers multiple activities to engage children, promoting physical development and fun. It includes a slide, a swing, a climbing structure, a basketball hoop, a football goal, and a ring toss game.



Image: Diagram illustrating the six distinct play features: Slide, Swing, Climber, Basketball Hoop, Football Hoop, and Ring Toss.

Your browser does not support the video tag.

Video: A product overview demonstrating the various features of the toddler slide and playset, including children interacting with the slide, swing, and sports elements.

ASSEMBLY INSTRUCTIONS

The Nyeekoy 6-in-1 Playset is designed for tool-free assembly. Follow these general steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not provided in this manual, refer to packaging for full list).
2. **Assemble Base Structure:** Connect the main support frames for the slide and swing using the provided interlocking mechanisms. Ensure all connections click securely into place.
3. **Attach Slide:** Secure the slide section to the main climbing structure. Confirm it is firmly attached and stable. The slide features an acceleration zone, deceleration zone, and an extended buffer stop zone for safety.
4. **Install Swing:** Attach the swing seat to the swing frame using the ropes and hooks. Ensure the swing

hangs freely and is balanced.

5. **Set Up Sports Elements:** Assemble the basketball hoop, football goal, and ring toss stand. These components are typically adjustable and can be positioned as desired.
6. **Stabilize:** For added stability, the base of the playset can be filled with water or sand (refer to specific instructions on the product for fill points).
7. **Final Check:** Before allowing children to play, perform a thorough check of all connections, ensuring they are tight and secure.



Image: Detailed view of the slide, highlighting its acceleration, deceleration, and extended buffer stop zones, and confirming its construction from safe HDPE material.

OPERATING YOUR PLAYSET

This playset offers multiple ways for children to play and develop motor skills.

- **Slide:** Children should climb the steps carefully, hold onto the handrails, and slide down feet first. Ensure the landing area is clear.
- **Swing:** Always ensure the child is securely seated in the swing with the safety bar in place. Push gently and maintain a safe distance.

- **Basketball Hoop:** Encourage children to practice shooting the ball into the hoop. The hoop height may be adjustable on some models.
- **Football Goal:** Use the small football to practice kicking and scoring goals.
- **Ring Toss:** Practice throwing rings onto the designated pegs to improve hand-eye coordination.
- **Climber:** Children can use the steps and side structures to climb, enhancing their leg strength and coordination.



Image: Close-up of the multifunctional adjustable football stand, also featuring a ring toss game, demonstrating its versatility.

CARE AND MAINTENANCE

Regular maintenance will extend the life of your playset and ensure continued safety.

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all bolts, screws, and connections for tightness. Tighten as necessary. Inspect plastic parts for cracks, breaks, or sharp edges.
- **Storage:** If used outdoors, consider moving the playset indoors or covering it during prolonged periods of

non-use or harsh weather to prevent fading and material degradation.

- **Disposal:** When the playset is no longer usable, dispose of it responsibly according to local regulations.

TROUBLESHOOTING

If you encounter any issues with your playset, refer to the following common solutions:

- **Playset feels unstable:** Ensure all connections are fully engaged and tightened. Check that the playset is on a level surface. If applicable, ensure the base is filled with water or sand for stability.
- **Parts do not fit:** Double-check the assembly steps and ensure you are using the correct parts for each section. Do not force parts together.
- **Missing parts:** Review the parts list provided with your product. If parts are genuinely missing, contact customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Nyeekoy
Model Number	1130
Color	Green
Material	Plastic (High-Density HDPE)
Product Dimensions (D x W x H)	75.5" x 72" x 48.5"
Item Weight	25.9 Pounds
Maximum Weight Recommendation (Slide)	132.2 Pounds
Maximum Weight Recommendation (Swing)	88 Pounds
Required Assembly	Yes
Recommended Age	1-8 years



Image: A diagram showing the overall dimensions of the Nyeekoy 6-in-1 Toddler Playset, including height, width, and depth measurements for the slide, swing, and basketball stand.

WARRANTY INFORMATION

Nyeekoy products are manufactured with quality and safety in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact customer support. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Nyeekoy customer support. Contact information can typically be found on the product packaging or the official Nyeekoy website.

We are committed to providing a safe and enjoyable experience for your child.

