

[Manuals.plus](#) /

› [SABALON](#) /

› SABALON Model 3649 Nordic Simple Floor Lamp Instruction Manual

SABALON 3649

SABALON Model 3649 Nordic Simple Floor Lamp Instruction Manual

Model: 3649

1. INTRODUCTION

Thank you for purchasing the SABALON Model 3649 Nordic Simple Floor Lamp. This manual provides essential information for the safe and efficient use of your new floor lamp. Please read these instructions carefully before installation and operation, and retain them for future reference.



The SABALON Model 3649 Nordic Simple Floor Lamp, featuring a minimalist design with a fabric shade and metal frame.

2. SAFETY INSTRUCTIONS

- Ensure the lamp is unplugged from the power outlet before cleaning, changing the bulb, or performing any maintenance.
- Do not operate the lamp with a damaged cord or plug. If damaged, contact qualified personnel for repair.
- Avoid placing the lamp in areas with high humidity or direct exposure to water.
- Use only the specified bulb type and wattage to prevent overheating.
- Keep the lamp away from flammable materials.
- Ensure the lamp base is stable on a flat, level surface to prevent tipping.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all components are present and undamaged:

- 1 x SABALON Model 3649 Floor Lamp (includes metal frame, fabric shade, and electrical components)

Note: Light bulb is typically sold separately unless specified on packaging.

4. SETUP AND ASSEMBLY

The SABALON Model 3649 Floor Lamp is designed for minimal assembly. Follow these steps for initial setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a clean, soft surface to prevent scratches.
2. **Position the Base:** Place the heavy metal base on a stable, level floor surface where you intend to use the lamp. Ensure the power cord can reach an outlet without being stretched or obstructed.
3. **Install Light Bulb:** Gently screw a compatible light bulb (not included) into the lamp's socket. Do not overtighten. Refer to the specifications section for recommended bulb type and wattage.



A top-down view illustrating the fabric shade and the bulb socket for installation.

4. **Connect to Power:** Plug the lamp's power cord into a standard electrical outlet.



The floor lamp positioned in a living room, demonstrating typical placement.

5. OPERATING INSTRUCTIONS

To operate your SABALON floor lamp:

- Locate the inline switch on the power cord.
- Press the switch to the 'ON' position to illuminate the lamp.
- Press the switch to the 'OFF' position to turn off the lamp.



A detailed view of the beige fabric lampshade, which diffuses light for a soft glow.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your floor lamp.

- **Cleaning:** Disconnect the lamp from power. Use a soft, dry cloth to wipe the metal frame. For the fabric shade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely. Unscrew the old bulb counter-clockwise and screw in a new, compatible bulb clockwise.
- **Cord Inspection:** Periodically check the power cord for any signs of damage, fraying, or kinks. If damage is found, discontinue use and seek professional repair.

7. TROUBLESHOOTING

If you encounter issues with your floor lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on	<ul style="list-style-type: none"> Lamp is not plugged in Light bulb is loose or burnt out Power outlet is not functioning Switch is faulty 	<ul style="list-style-type: none"> Ensure the lamp is securely plugged into a working outlet. Tighten or replace the light bulb. Test the outlet with another appliance. Contact customer support if the switch is suspected to be faulty.
Light flickers	<ul style="list-style-type: none"> Loose bulb connection Incompatible bulb Faulty wiring 	<ul style="list-style-type: none"> Tighten the light bulb. Ensure the bulb wattage and type are compatible with the lamp. If flickering persists, discontinue use and consult a qualified electrician.

8. SPECIFICATIONS

- **Brand:** SABALON
- **Model Name:** 3649
- **Product Dimensions:** 28 cm (11.02 in) x 28 cm (11.02 in) x 175 cm (68.89 in)
- **Item Weight:** 1.76 ounces (50 Grams)
- **Material:** Metal frame, Fabric shade
- **Shade Color:** Beige
- **Color:** One Color (Frame)
- **Number of Items:** 1
- **Assembly Required:** No
- **Manufacturer:** SABALON




Diagram showing the dimensions of the SABALON floor lamp: 28cm (11.02in) width and 175cm (68.89in) height.

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your SABALON Model 3649 Floor Lamp, please refer to the documentation provided at the point of purchase or contact your retailer. You may also visit the official SABALON website for further assistance.

