

Manuals.plus /

› CARPETNAL /

› CARPETNAL 7-Drawer White Dresser with Gold Handles (Model FH0033WH) - Instruction Manual

CARPETNAL FH0033WH

CARPETNAL 7-Drawer White Dresser with Gold Handles (Model FH0033WH) - Instruction Manual

Brand: CARPETNAL | Model: FH0033WH

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your CARPETNAL 7-Drawer White Dresser. Please read these instructions carefully before beginning assembly or use to ensure safe and proper functionality of the product.



Image 1: The CARPETNAL 7-Drawer White Dresser, showcasing its modern design and gold handles.

2. SAFETY INFORMATION

- **Tip-Over Hazard:** Furniture tip-overs can cause serious or fatal injuries. Always secure this dresser to the wall using the provided anti-tip kit.
- **Assembly:** Assemble the product on a soft, clean surface to prevent scratches. Ensure all parts are correctly installed and fasteners are tightened before use.
- **Weight Capacity:** Do not overload drawers or the top surface. Refer to specifications for weight limits.
- **Children:** Do not allow children to climb on drawers or the dresser. Keep small parts away from children during assembly.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Dresser panels (top, bottom, sides, back)
- 7 Drawer fronts, sides, and bottoms
- Gold metal handles (7 sets)
- Drawer slides (7 sets)
- Wooden tapered legs
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip kit
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is required. Follow the illustrated instructions provided in the package. It is recommended to have two adults for assembly.

1. **Prepare Workspace:** Clear a spacious area and lay out all components on a soft, clean surface to prevent damage.
2. **Assemble Frame:** Attach the side panels to the base and top panel using the provided hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Securely attach the drawer slides to the inner sides of the dresser frame.
4. **Assemble Drawers:** Construct each of the 7 drawers by attaching the sides, front, and bottom panels. Install the gold metal handles onto the drawer fronts.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots on the dresser frame.
6. **Attach Legs:** Secure the wooden tapered legs to the bottom of the dresser.
7. **Install Anti-Tip Kit:** For safety, attach the anti-tip kit to the back of the dresser and secure it to a wall stud.

For a visual guide, please refer to the official product video:

Your browser does not support the video tag.

Video 1: Official product showcase of the CARPETNAL 7-Drawer White Dresser, demonstrating its features and design.



Image 2: Close-up of the elegant gold metal knobs and the smooth metal drawer slides, highlighting the quality of the hardware and ease of cleaning the solid tabletop.

5. OPERATING INSTRUCTIONS

- **Drawer Use:** Open and close drawers smoothly using the handles. Avoid forcing drawers, especially when heavily loaded.
- **Storage:** Utilize the 7 spacious drawers for organizing clothing, accessories, or other personal items. The large top surface can be used for decorative items or as a TV stand.



Image 3: The dresser with multiple drawers open, illustrating the ample storage capacity and smooth operation of the drawers.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining. The waterproof desktop offers protection against moisture.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.
- **Drawer Slides:** If drawers become stiff, apply a small amount of silicone lubricant to the slides.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Misaligned slides, debris in tracks, or dry slides.	Check alignment of slides, clean tracks, or apply silicone lubricant.
Dresser feels unstable.	Loose fasteners or uneven floor.	Tighten all assembly hardware. Adjust leg levelers if applicable. Ensure anti-tip kit is installed.
Missing parts during assembly.	Packaging error.	Contact CARPETNAL customer service for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	CARPETNAL
Model Name	7 drawer dresser-33
Item Model Number	FH0033WH
Product Dimensions	15.75"D x 55"W x 30.9"H
Color	White
Material	Engineered Wood
Finish Type	Lacquered
Number of Drawers	7
Item Weight	94.2 Pounds
Assembly Required	Yes



Image 4: Visual representation of the dresser's overall dimensions and individual drawer measurements for planning and storage.

9. WARRANTY AND SUPPORT

CARPETNAL products are designed for quality and durability. For any questions, concerns, or assistance with your product, please contact CARPETNAL customer service. Refer to your purchase documentation for specific warranty details.

Customer Service: Please refer to the contact information provided with your purchase or visit the official CARPETNAL website.