

[manuals.plus](#) /

› [IINE](#) /  
› [IINE Professional Taiko Drum Controller Pro Max User Manual](#)

**IINE Taiko Drum Controller Pro Max**

# IINE Professional Taiko Drum Controller Pro Max User Manual

Model: Taiko Drum Controller Pro Max

Brand: IINE

## 1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your IINE Professional Taiko Drum Controller Pro Max. Designed for an immersive Taiko drumming experience, this controller is compatible with multiple gaming platforms.



Image 1: The IINE Professional Taiko Drum Controller Pro Max, featuring a large white drum surface and two wooden drumsticks.

## 2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- Drum x 1
- Drumsticks x 2
- Bracket side panel x 2
- Bracket cross plate x 1
- User Manual x 1

## 3. SETUP INSTRUCTIONS

Follow these steps to assemble your Taiko Drum Controller:

1. **Assemble the Drum Rack and Baseplate:** Ensure the bottom plate's logo is facing upwards. Connect the two side panels to the cross plate.
2. **Install Both Sides of the Drum Rack:** Securely attach the assembled side panels to the baseplate.

3. Place the Drum Body onto the Drum Rack: Carefully position the drum body onto the assembled rack to complete the installation.



Image 2: Visual guide illustrating the three-step assembly process for the drum controller stand.

Your browser does not support the video tag.

Video 1: An unboxing and assembly demonstration of the IINE Drum Controller Pro Max, showing how to put together the stand and place the drum.

## 4. OPERATING INSTRUCTIONS

The IINE Professional Taiko Drum Controller Pro Max is designed for responsive and accurate gameplay. Connect the controller to your gaming device via the provided USB cable.

- Drum Surface:** The 13.7-inch high-resilience silicone drum surface provides excellent rebound and reduces wrist fatigue.
- Drumsticks:** Use the solid wood drumsticks to strike the drum surface.
- Sensitivity:** The high-sensitivity vibration sensor and upgraded core chip ensure precise detection of every strike, minimizing delay.
- Control Panel:** Utilize the integrated control panel on the drum for in-game navigation and

selections.



Image 3: A close-up view of the 35cm drum surface being struck by drumsticks, highlighting its size and responsiveness.

Your browser does not support the video tag.


Video 2: A demonstration of the IINE Taiko Drum Controller Pro Max in action, showing gameplay and the responsiveness of the drum.

## 5. MULTI-PLATFORM COMPATIBILITY

The controller offers broad compatibility, allowing you to enjoy Taiko games across various systems:

- Nintendo Switch (NS1, NS2)
- PlayStation 4 (PS4) - *Supports PS4 version of Taiko no Tatsujin only*
- PlayStation 5 (PS5)
- PC

## Plug and Play, Compatible with Multiple Platforms



For Switch

For PS4/PS5

(Only support the PS4 version of Taiko no Tatsujin)

For PC

Image 4: The drum controller displayed alongside a Nintendo Switch, PlayStation 5, and a PC monitor, illustrating its multi-platform compatibility.

## 6. MAINTENANCE

To ensure the longevity and optimal performance of your drum controller, please follow these maintenance guidelines:

- **Cleaning:** Wipe the drum surface and body with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Drumsticks:** Inspect drumsticks periodically for wear. Replace if damaged to prevent potential injury or damage to the drum surface.
- **Cable Care:** Avoid sharp bends or kinks in the connection cable. Store the cable neatly when not in use.

## 7. TROUBLESHOOTING

If you encounter any issues with your IINE Professional Taiko Drum Controller Pro Max, please refer to the

following common solutions:

- **Controller Not Responding:**

- Ensure the USB cable is securely connected to both the controller and your gaming device.
- Try connecting the controller to a different USB port.
- Restart your gaming device.

- **Inconsistent Hit Detection:**

- Verify that the drum body is securely seated on its stand.
- Ensure the drum surface is clean and free of debris.
- Check for any physical damage to the drum surface or internal components.

- **Platform Compatibility Issues:**

- Confirm that your game is compatible with the controller on your specific platform (e.g., PS4 version of Taiko no Tatsujin).
- Ensure your gaming device's software is up to date.

If the problem persists, please contact IINE customer support for further assistance.

## 8. SPECIFICATIONS

Feature	Detail
Drum Surface Diameter	13.7 inches (approx. 35 cm)
Drum Surface Material	High-resilience silicone
Drumstick Material	Solid wood (Beech)
Sensor Type	High-sensitivity vibration sensor with upgraded core chip
Connection Cable Length	2 meters
Compatibility	Nintendo Switch (NS1, NS2), PS4 (Taiko no Tatsujin only), PS5, PC
Product Dimensions	14.45 x 14.33 x 5.08 inches
Item Weight	8.38 pounds



Image 5: A comparative diagram highlighting the larger 35cm drum surface, imported high-density wood board, vibration sensor, 2m cable, solid wood drumsticks, anti-ghosting algorithm, and super high sensitivity of the IINE Professional Taiko Drum Pro Max.

# Structural Upgrade

Achieving a Qualitative Leap in Functionality




Image 6: An exploded view diagram showing the internal components and structural upgrades, including the food-grade silicone material, imported high-density wood board, vibration sensor, shock-absorbing screws, core processing chip, and high-strength plastic bottom shell.

## 9. WARRANTY AND SUPPORT

IINE is committed to providing high-quality products and customer satisfaction. For any product-related inquiries, technical support, or warranty claims, please contact IINE customer service. The IINE team provides 24-hour service.

Please retain your proof of purchase for warranty purposes.

**Related Documents - Taiko Drum Controller Pro Max**

	<p><a href="#">IINE Athena Wireless Controller: Setup, Features, and Usage Guide</a></p> <p>Comprehensive guide to the IINE Athena Wireless Controller (Model L969). Learn about button layout, compatibility, connection methods for Switch, PC, and mobile, advanced settings like macros and turbo fire, charging, maintenance, and troubleshooting.</p>
	<p><a href="#">IINE L617 Wireless Controller for Nintendo Switch: User Manual &amp; Features</a></p> <p>Comprehensive guide to the IINE L617 Wireless Controller for Nintendo Switch and Switch OLED, covering connection, turbo functions, LED controls, vibration, and FCC compliance.</p>
	<p><a href="#">IINE Mini Retro Ananke Controller User Manual and Specifications</a></p> <p>Comprehensive guide for the IINE Mini Retro Ananke Controller, covering setup, connection, features, troubleshooting, and maintenance for Nintendo Switch, PC, and mobile devices.</p>
	<p><a href="#">FCC Confidentiality Request for Dongguan Liangzhi Electronic Co., Ltd. - FCC ID: 2BGZI-L1041</a></p> <p>Confidentiality request submitted by Dongguan Liangzhi Electronic Co., Ltd. to the FCC for application certification of FCC ID: 2BGZI-L1041, seeking to protect proprietary information such as block diagrams and schematics.</p>
	<p><a href="#">Mayflash MAGIC-NS Wireless Controller Adapter User Manual</a></p> <p>User manual for the Mayflash MAGIC-NS Wireless Controller Adapter, detailing setup and usage for various gaming consoles including Nintendo Switch, PS3, PC, NEOGEO mini, and PS Classic. Covers wired and wireless controller connections, button mapping, and software updates.</p>
	<p><a href="#">Taiko no Tatsujin Drum Controller Instruction Manual for PS5, PS4, and PC</a></p> <p>Official instruction manual for the HORI Taiko no Tatsujin Drum Controller, covering setup, gameplay, compatibility, troubleshooting, and specifications for PlayStation 5, PlayStation 4, and Windows PC.</p>