

[manuals.plus](#) /

› [ShanWan](#) /

› [ShanWan Wireless Switch Controller User Manual - Model Q35-BLACK](#)

ShanWan Q35-BLACK

ShanWan Wireless Switch Controller User Manual

Model: Q35-BLACK

1. INTRODUCTION

This manual provides detailed instructions for the ShanWan Wireless Switch Controller, Model Q35-BLACK. This controller is designed for use with Nintendo Switch, Switch Lite, and Switch OLED consoles, offering an enhanced gaming experience with advanced features such as adjustable turbo, dual vibration, and a 6-axis gyro sensor. Please read this manual carefully before use to ensure proper operation and to maximize your gaming enjoyment.

2. PACKAGE CONTENTS

- ShanWan Wireless Switch Controller (Q35-BLACK)
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW



Front view of the ShanWan Wireless Switch Controller, Model Q35-BLACK, showcasing its ergonomic design and button layout.

The ShanWan Wireless Switch Controller (Q35-BLACK) features an ergonomic design for comfortable extended gameplay. Key features include:

- **Perfect Compatibility:** Fully compatible with Nintendo Switch, Switch Lite, and Switch OLED consoles.
- **Powerful Function:** Equipped with dual vibration motors for haptic feedback and a 6-axis gyro sensor for precise motion control.
- **Turbo Function:** Adjustable auto or manual turbo mode with three speed settings (25Hz, 12.5Hz, 6.25Hz). Customizable turbo buttons (A/B/X/Y/L/ZL/R/ZR).
- **Ergonomic & Non-Slip Design:** Designed to fit comfortably in hands with a non-slip surface for stable control.
- **High-Performance Battery:** Built-in 600mAh battery provides approximately 10 hours of game time with a charging time of 2-3 hours.




An overhead view of the ShanWan controller displaying its dimensions (15.9cm / 6.26inch width, 10.5cm / 4.134inch height) and icons representing wireless connection, turbo function, screenshot, long battery life, vibration feedback, and wake-up function.

4. SETUP AND PAIRING

Follow these steps to pair your ShanWan Wireless Switch Controller with your Nintendo Switch console:

1. From the Nintendo Switch HOME Menu, select the "Controllers" menu.
2. Select "Change Grip/Order".
3. On the ShanWan controller, press and hold the "Pair" button (usually a small button on the top edge of the controller) for a few seconds until the indicator lights begin to flash rapidly.
4. Once successfully paired, the LED indicator on the controller will remain ON, and the controller will be displayed on the Switch host screen.

Bluetooth Connection



Step-by-step guide for pairing the ShanWan controller via Bluetooth to a Nintendo Switch console, showing navigation through the 'Controllers' menu, 'Change Grip/Order', pressing the 'Pair' button, and LED indicator confirmation.

5. OPERATING INSTRUCTIONS

5.1. Turbo Function

The controller supports both auto TURBO and manual TURBO modes. To activate or adjust the turbo function:

- Setting Turbo:** Press and hold the desired button (A/B/X/Y/L/ZL/R/ZR) and then press the "T" (Turbo) button simultaneously. The button will now repeatedly input as long as it's held down.
- Setting Auto Turbo:** Repeat the above step. The button will now repeatedly input without needing to be held down.
- Adjusting Turbo Speed:** While in Turbo mode, press the "T" button and move the Right Analog Stick Up or Down to cycle through the three speeds: 25Hz (fast), 12.5Hz (medium), and 6.25Hz (slow).
- Clearing Turbo:** To clear a single button's turbo setting, repeat the initial turbo setting process (button + T) until the turbo function is deactivated. To clear all turbo settings, press and hold the "T" button for 5 seconds.

5.2. Vibration Feedback

The controller features dual vibration motors that provide haptic feedback during gameplay, enhancing immersion. The intensity of the vibration is typically controlled by the game itself.



Image highlighting the real-time vibration feedback feature of the ShanWan controller, with blue waves indicating haptic responses during gameplay.

5.3. 6-Axis Gyro Sensor

The integrated 6-axis gyro sensor detects the controller's tilt and orientation, allowing for precise motion control in compatible games. This provides a realistic and responsive gaming experience.

6-AXIS GYRO SENSOR

Detect the inclination of the controller and give a quick response.



Illustration demonstrating the 6-axis gyro sensor functionality of the ShanWan controller, showing how tilting the controller translates to in-game movements (front/back, left/right, up/down).

5.4. Battery and Charging

The controller is equipped with a 600mAh rechargeable battery. To charge the controller, connect it to a USB power source (e.g., Nintendo Switch dock, computer, or USB wall adapter) using the provided USB-C cable. The charging time is approximately 2-3 hours, providing up to 10 hours of gameplay on a full charge.



Diagram illustrating the battery life and charging capabilities of the ShanWan controller, showing a USB-C charging port and indicators for 8 hours playing time and 2 hours charging time.

6. MAINTENANCE

To ensure the longevity and optimal performance of your controller, please follow these maintenance guidelines:

- Keep the controller clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping the controller or subjecting it to strong impacts.
- Do not attempt to disassemble or modify the controller, as this will void the warranty.

7. TROUBLESHOOTING

7.1. Controller Does Not Connect/Pair

- Ensure the controller is sufficiently charged.

- Verify that the Nintendo Switch console is updated to the latest system software.
- Follow the pairing instructions in Section 4 carefully.
- Try restarting both the Nintendo Switch console and the controller.
- If multiple controllers are paired, try disconnecting others to avoid interference.

7.2. Input Lag or Disconnections

- Ensure there are no significant obstacles between the controller and the Switch console.
- Move closer to the Switch console to improve signal strength.
- Check for other wireless devices that might cause interference (e.g., Wi-Fi routers, other Bluetooth devices).
- Re-pair the controller with the Switch console.

7.3. Buttons or Joysticks Not Responding

- Ensure the controller is properly connected and charged.
- Test the controller in different games or the Switch's controller test menu to determine if the issue is game-specific.
- Perform a factory reset on the controller (refer to manufacturer's website if not specified in manual).

8. SPECIFICATIONS

Model Number	Q35-BLACK
Compatibility	Nintendo Switch, Switch Lite, Switch OLED
Connectivity	Wireless (Bluetooth)
Battery Capacity	600mAh
Play Time	Up to 10 hours
Charging Time	2-3 hours
Charging Port	USB-C
Motion Sensor	6-Axis Gyro
Vibration	Dual Motors
Dimensions	4.3 x 2.7 x 6.2 inches (10.9 x 6.9 x 15.7 cm)
Weight	11.1 ounces (314.7 grams)

9. WARRANTY AND SUPPORT

ShanWan products are designed for reliability and performance. For warranty information, technical support, or any inquiries regarding your controller, please refer to the official ShanWan website or contact customer service through your point of purchase. Please retain your proof of purchase for warranty claims.

Related Documents - Q35-BLACK

	<p>Wireless Switch Pro Controller User Manual</p> <p>This manual provides instructions for using the Wireless Switch Pro Controller for Nintendo Switch, Switch Lite, and Switch OLED. It covers features such as wireless connectivity, programmable buttons, motion control, vibration, turbo function, and wakeup capabilities.</p>
	<p>ShanWan Q17 Game Controller User Manual and Bluetooth Connection Guide</p> <p>Comprehensive guide for the ShanWan Q17 Game Controller, covering setup, Bluetooth pairing with Nintendo Switch, button functions, turbo features, charging, troubleshooting, and FCC compliance.</p>
	<p>ShanWan Q36 Pro Wireless Gaming Controller User Manual</p> <p>Comprehensive user guide for the ShanWan Q36 Pro Wireless Gaming Controller, covering setup, connectivity for Android, iOS, Windows, and Nintendo Switch, PS4 compatibility, firmware updates, and technical specifications.</p>
	<p>ShanWan Q11A Retractable Gamepad User Manual</p> <p>User manual for the ShanWan Q11A retractable gamepad, detailing its features, connectivity options (Bluetooth, USB), compatibility with various platforms (Android, iOS, PC, PS3/PS4, Switch), operation instructions, and specifications.</p>
	<p>ShanWan Q36 Wireless Game Controller: User Guide and Connection Modes</p> <p>Comprehensive guide to the ShanWan Q36 wireless game controller. Learn how to connect to Android, iOS, Windows, Nintendo Switch (Pro and Joycon modes), and PS4. Includes setup, firmware updates, and technical specifications.</p>
	<p>Q37 Wireless Gaming Controller User Guide and Specifications</p> <p>Detailed guide for the Shenzhen ShanWan Technology Q37 wireless gaming controller, covering setup, connectivity for Android, iOS, Switch, and PS4, button functions, firmware updates, and technical specifications.</p>