

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Portronics](#) /

› [Portronics Freedom 6 15W Wireless Charger User Manual](#)

Portronics POR-2130

Portronics Freedom 6 15W Wireless Charger

Model: POR-2130 | Brand: Portronics

1. INTRODUCTION

The Portronics Freedom 6 is a versatile 5-in-1 wireless charging station designed to simplify your charging experience. It allows simultaneous wireless charging for up to three devices: smartphones, smartwatches, and earbuds. Beyond its charging capabilities, the Freedom 6 integrates a digital alarm clock and a night light, making it a multi-functional addition to any space. This device supports 15W fast charging for compatible smartphones and features a convenient Type-C input.

15W

Wireless Charging



Note : Use at least an 18W adapter or higher for optimal performance

Image: The Portronics Freedom 6 wireless charger demonstrating its 15W charging capability for a smartphone, smartwatch, and earbuds.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Portronics Freedom 6 Wireless Charger
- USB Type-C Charging Cable
- User Manual

Note: A power adapter is not included. For optimal performance, use a power adapter with a minimum output of 18W or higher.

3. PRODUCT LAYOUT

Familiarize yourself with the different components of your Portronics Freedom 6 wireless charger:

Stay Charged With Freedom 6



Image: Detailed diagram of the Portronics Freedom 6, highlighting its various parts.

- **Watch Charging Area:** For compatible smartwatches.
- **Mobile Charging Area:** For Qi-enabled smartphones (up to 15W).
- **Earbud Charging Area:** For Qi-enabled earbuds (up to 5W).
- **Digital Clock Display:** Shows time and alarm status.
- **Light Button:** Controls the night light function.
- **'+' Button:** Increases values for time/alarm settings.
- **'-' Button:** Decreases values for time/alarm settings.
- **Mode Button:** Switches between time, alarm, and 12H/24H modes.
- **Earbud Charging Indicator:** LED light indicating earbud charging status.
- **Mobile Charging Indicator:** LED light indicating smartphone charging status.
- **Small Item Storage Area:** A designated space for small accessories.



USB A
Output Port



Type C
Input Port

Image: Close-up of the Type-C Input Port and USB-A Output Port.

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the Portronics Freedom 6 and all accessories from the packaging.
2. **Connect Power:** Insert the provided USB Type-C charging cable into the Type-C Input Port on the back of the Freedom 6. Connect the other end of the cable to a compatible power adapter (**minimum 18W recommended for optimal performance**).
3. **Placement:** Place the charging station on a stable, flat surface, away from direct sunlight or heat sources.
4. **Initial Power On:** Once connected to power, the digital clock display will illuminate.

5. OPERATING INSTRUCTIONS

5.1. Charging Devices

The Freedom 6 supports wireless charging for Qi-enabled devices. Ensure your device is compatible before placing it on the charging areas.

- **Smartphones:** Place your Qi-enabled smartphone on the Mobile Charging Area. The Mobile Charging Indicator LED will light up to confirm charging. For best results, remove thick phone cases.

- **Earbuds:** Place your Qi-enabled earbud case on the Earbud Charging Area. The Earbud Charging Indicator LED will light up to confirm charging.
- **Smartwatches:** Place your compatible smartwatch on the Watch Charging Area. Ensure it is properly aligned.

Important: For fast charging, ensure your power adapter is 18W or higher. Lower wattage adapters may result in slow charging or no charging for multiple devices simultaneously.

5.2. Digital Clock and Alarm

1. Setting Time:

- Press the **Mode Button** once to enter time setting mode. The hour digits will flash.
- Use the '+' and '-' buttons to adjust the hour.
- Press the **Mode Button** again to set the minutes. The minute digits will flash.
- Use the '+' and '-' buttons to adjust the minutes.
- Press the **Mode Button** a third time to confirm and exit time setting.

2. **12H/24H Format:** While in time display mode, press and hold the **Mode Button** to switch between 12-hour (with AM/PM indicator) and 24-hour formats.

3. Setting Alarm:

- Press the **Mode Button** twice to enter alarm setting mode. The alarm hour digits will flash.
- Use the '+' and '-' buttons to adjust the alarm hour.
- Press the **Mode Button** again to set the alarm minutes. The alarm minute digits will flash.
- Use the '+' and '-' buttons to adjust the alarm minutes.
- Press the **Mode Button** a third time to confirm and exit alarm setting.
- To activate/deactivate the alarm, press the '-' button while in alarm display mode. An alarm icon will appear/disappear on the display.

5.3. Night Light Function

The Freedom 6 features a built-in night light for ambient illumination.

Night Light

Set the Light for a Good Sleep



Image: The Portronics Freedom 6 with its night light activated.

- Press the **Light Button** once to turn on the night light.
- Press the **Light Button** repeatedly to cycle through different brightness levels (e.g., Low, Medium, High).
- Press the **Light Button** again after the highest brightness to turn off the night light.

5.4. Display Brightness

The digital clock display has adjustable brightness levels.

Digital Alarm Clock

12/24 Hours Format



Image: Visual representation of the four display brightness levels.

To adjust the display brightness, press the **Light Button** while the night light is off. Each press will cycle through the available brightness levels (Dim, Low, Medium, Full) for the digital clock display.

6. COMPATIBILITY

The Portronics Freedom 6 is designed for broad compatibility with Qi-enabled devices. Refer to the following for specific device support:

Universal Compatibility



| | | | |
|---|--|---|--|
|  For AirPods 3W MAX | 2/3/Pro/Pro 2 Note: Not work for Air-Pods with Lighting charging case! |  For Galaxy 10W MAX | S23/S22/S21/S20 series S10/S8/S7/S6 series Z Flip/Fold series Note 20/10/9/8 series |
|  For Apple Watch 2.5W MAX | S9/8/7/6/5/4/Ultra /Ultra 2/SE Note: Not work for Apple Watch 1 and other brands watch! |  | And other cellphone of qi standard that support Wireless Charging Note: Not work for Google Pixel 5A/4A/3A |
|  For iPhone 7.5W MAX | 15/Pro/Plus/Pro Max 14/Pro/Plus/Pro Max 13/mini/Pro/Pro Max 12/mini/Pro/Pro Max 11/Pro/Pro Max X/XR/XS/XS Max 8/8 Plus/SE2/SE3 | | |

Image: Compatibility chart for various devices with the Freedom 6.

- **For iPhones (7.5W Max):** Compatible with iPhone 15/Pro/Plus/Pro Max, 14/Pro/Plus/Pro Max, 13/mini/Pro/Pro Max, 12/mini/Pro/Pro Max, 11/Pro/Pro Max, X/XR/XS/XS Max, 8/8 Plus/SE2/SE3 series.
- **For Samsung Galaxy (10W Max):** Compatible with S23/S22/S21/S20 series, S10/S8/S7/S6 series, Z Flip/Fold series, Note 20/10/9/8 series.
- **For AirPods (3W Max):** Compatible with AirPods 2/3/Pro/Pro 2. **Note:** Not compatible with AirPods without a lighting charging case.
- **For Apple Watch (2.5W Max):** Compatible with Apple Watch S9/8/7/6/5/4/Ultra/Ultra 2/SE. **Note:** Not compatible with Apple Watch Series 1 and other brands of smartwatches.
- **Other Qi-enabled Cellphones:** Supports other Qi standard wireless charging phones. **Note:** Not compatible with Google Pixel 5A/4A/3A.

7. MAINTENANCE

Proper care and maintenance will ensure the longevity of your Portronics Freedom 6 wireless charger.

- **Cleaning:** Disconnect the device from power before cleaning. Use a soft, dry, lint-free cloth to wipe the surface. Do not use liquid cleaners, aerosols, or harsh chemicals, as these may damage the

device.

- **Storage:** When not in use for extended periods, store the device in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid:** Do not expose the device to water, moisture, or high humidity. Avoid dropping the device or subjecting it to strong impacts.

8. TROUBLESHOOTING

If you encounter issues with your Portronics Freedom 6, please refer to the following common solutions:

1. Device Not Charging:

- Ensure the charging station is properly connected to a power source.
- Verify that the power adapter used is at least 18W or higher.
- Check if your device (smartphone, earbuds, smartwatch) is Qi-enabled and compatible with the charger.
- Ensure the device is correctly aligned on the respective charging area.
- Remove any thick phone cases (over 5mm) or metallic objects between the device and the charging surface.

2. Slow Charging Speed:

- Confirm that you are using an 18W or higher power adapter. Lower wattage adapters will result in slower charging.
- Ensure no other devices are drawing excessive power from the same adapter if it's a multi-port adapter.

3. Smartwatch Not Charging:

- Verify that your smartwatch is a compatible Apple Watch model (Series 4 or newer). The charger is not compatible with Apple Watch Series 1 or other brands.
- Ensure the watch is correctly placed and aligned on the watch charging stand.

4. Device Overheating:

- It is normal for devices to warm up slightly during wireless charging. However, if a device becomes excessively hot, remove it immediately.
- Ensure there is adequate ventilation around the charging station and the device being charged.
- Avoid charging in direct sunlight or hot environments.

5. Digital Clock/Alarm Not Functioning:

- Ensure the device is powered on.
- Refer to Section 5.2 for detailed instructions on setting the time and alarm.

9. SPECIFICATIONS

| Feature | Detail |
|----------------------------|--------------------|
| Model Number | POR-2130 |
| Product Dimensions (LxWxH) | 9 x 22.4 x 22.3 cm |
| Item Weight | 310 g |

| | |
|-------------------|--|
| Input Voltage | 5 Volts |
| Wattage (Max) | 15 Watts (Phone), 5 Watts (Earbuds), 2.5 Watts (Watch) |
| Output Current | 3 Amps |
| Connectivity | Wireless |
| Special Features | Alarm Clock, Type-C Input, Night Light |
| Colour | Black |
| Country of Origin | China |

10. WARRANTY INFORMATION

Portronics products are covered by a limited warranty from the date of purchase. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official Portronics website. Keep your purchase receipt as proof of purchase for warranty claims.

11. CUSTOMER SUPPORT

For any queries, technical assistance, or support regarding your Portronics Freedom 6 wireless charger, please contact our customer service team:

- **Email:** help@portronics.com
- **Phone:** +91 9555-245-245
- **Manufacturer Address:** First Floor Property No D 8 Upper Basement Sector 8 Noida Uttar Pradesh 201301

Please have your product model number (POR-2130) and purchase details ready when contacting support.