

manuals.plus /

- › [boAt](#) /
- › [boAt Rockerz 430 Wireless Over-Ear Headphones User Manual](#)

boAt Rockerz 430

boAt Rockerz 430 Wireless Over-Ear Headphones User Manual

Model: Rockerz 430

1. INTRODUCTION

Welcome to the user manual for your boAt Rockerz 430 Wireless Over-Ear Headphones. This guide provides detailed instructions on how to set up, operate, and maintain your headphones to ensure optimal performance and longevity. Please read this manual carefully before using your device.



Image: boAt Rockerz 430 Wireless Over-Ear Headphones, Black Sabre.

2. WHAT'S IN THE BOX

Upon unboxing your boAt Rockerz 430 headphones, you should find the following items:

- boAt Rockerz 430 Wireless Over-Ear Headphones
- Charging Cable (Type-C)
- User Manual

3. PRODUCT OVERVIEW AND FEATURES

The boAt Rockerz 430 headphones are designed to deliver a superior audio experience with advanced features for convenience and performance.

3.1. 40mm Drivers with boAt Signature Sound

Experience powerful and clear audio with the 40mm high-performance drivers, delivering boAt Signature Sound with exceptional clarity and depth.

boAt Hearables App



Stream Top Tracks



Listen to Audiobooks



User Help Guide





Image: User wearing boAt Rockerz 430 headphones, illustrating the audio experience.

3.2. BEAST Mode (40ms Low Latency)

Engage BEAST Mode for a low latency gaming experience, synchronizing visuals and sound with a 40ms response time for uninterrupted gameplay.

40mm Drivers
boAt Signature Sound



Easy Access
Controls



40 Hours
Total Playback



Type-C Interface

Image: User engaged in gaming with boAt Rockerz 430 headphones, demonstrating BEAST Mode.

3.3. Extended Playtime

Enjoy up to 40 hours of continuous audio playback on a single charge, ensuring long-lasting entertainment.




Image: boAt Rockerz 430 headphones, highlighting 40 hours of battery life.

3.4. Adaptive Fit

The headphones feature an adaptive fit design with a snug headband for heightened comfort during extended listening sessions.




Image: User wearing boAt Rockerz 430 headphones, demonstrating adaptive fit.

3.5. ENx Technology

Integrated ENx Technology ensures clear voice calls by minimizing background noise, making conversations hassle-free in various environments.

3.6. Quick Access Controls

Manage audio playback, calls, and activate gaming mode directly from the headphones using easily accessible control buttons.

40mm Drivers

boAt Signature Sound



Image: Close-up of the quick access control buttons on the boAt Rockerz 430.

3.7. Type-C Interface

The Type-C charging port allows for effortless and convenient charging.

BEAST™ Mode

40ms Low Latency Gaming



Image: Close-up of the Type-C charging port on the boAt Rockerz 430.

3.8. Bluetooth v5.4 Connectivity

Enjoy stable and efficient wireless connectivity with Bluetooth v5.4, allowing seamless pairing with compatible devices.

3.9. Instant Voice Assistant Activation

Activate your device's voice assistant (Google Assistant or Siri) with a simple command or button press for hands-free control.

4. SETUP INSTRUCTIONS

4.1. Charging the Headphones

1. Connect the provided Type-C charging cable to the charging port on your headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. A full charge takes approximately 2 hours.
4. Once fully charged, the headphones provide up to 40 hours of playtime.

4.2. Bluetooth Pairing

1. Ensure your headphones are charged.
2. Press and hold the Power button on your headphones until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, laptop, etc.), enable Bluetooth and search for available devices.
4. Select "boAt Rockerz 430" from the list of available devices.
5. Once connected, the LED indicator will flash blue periodically, and you will hear an audible confirmation.
6. The headphones will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

5. OPERATING INSTRUCTIONS

5.1. Basic Controls

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Press the Multi-function button once.
- **Volume Up:** Press the Volume Up (+) button.
- **Volume Down:** Press the Volume Down (-) button.
- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button.

5.2. Voice Assistant Activation

To activate your device's voice assistant (Google Assistant or Siri), press the dedicated Voice Assistant button once.

5.3. BEAST Mode (Low Latency Gaming)

To activate or deactivate BEAST Mode for low latency gaming, press the dedicated Gaming Mode button. This mode optimizes audio synchronization for gaming.

6. MAINTENANCE

To ensure the longevity and optimal performance of your boAt Rockerz 430 headphones, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headphones are water-resistant. However, avoid submerging them in water or exposing them to heavy rain.
- **Cable Care:** Handle the charging cable gently to prevent damage.

7. TROUBLESHOOTING

If you encounter any issues with your boAt Rockerz 430 headphones, refer to the following common solutions:

Problem	Possible Solution
Headphones not turning on	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair with device	Make sure the headphones are in pairing mode (flashing blue and red LED). Ensure Bluetooth is enabled on your device and it's within 10 meters of the headphones. Forget previous pairings on your device and try again.
No sound	Check the volume levels on both the headphones and your connected device. Ensure the headphones are properly paired. Try playing different audio sources.
Poor sound quality	Ensure there are no obstructions between the headphones and your device. Move closer to your device. Check the audio quality of the source material.
Microphone not working	Ensure the headphones are properly connected and selected as the input device on your phone/computer. Check for any mute functions on your device.

8. SPECIFICATIONS

Here are the detailed specifications for the boAt Rockerz 430 Wireless Over-Ear Headphones:

- **Model Name:** Rockerz 430
- **Connectivity Technology:** Bluetooth v5.4
- **Wireless Communication Technology:** Bluetooth
- **Audio Driver Type:** Dynamic Driver
- **Driver Size:** 40 mm
- **Impedance:** 32 Ohms
- **Sensitivity:** 102 dB
- **Bluetooth Range:** 10 Metres
- **Battery Life:** Up to 40 Hours
- **Charging Time:** Approximately 2 Hours
- **Charging Interface:** Type-C
- **Battery Cell Composition:** Lithium Polymer
- **Item Weight:** 120 Grams
- **Product Dimensions:** 6 x 2 x 5 cm
- **Material:** Plastic, Polyurethane (PU)
- **Ear Placement:** Over Ear
- **Control Method:** Push Button
- **Water Resistance Level:** Water Resistant
- **Special Features:** 40 ms Low Latency BEAST™ Mode, ENx Technology, Adaptive Fit, Instant Voice Assistant Activation
- **Compatible Devices:** Smartphone, Laptop

9. WARRANTY AND SUPPORT

Your boAt Rockerz 430 headphones come with a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For further assistance or to register your product, you can download the boAt Hearables App.



Image: QR code to download the boAt Hearables App.

You can also access the app via this link: [boAt Hearables App](#)

© 2026 boAt. All rights reserved.