

Manuals.plus /

› Fastrack /

› Fastrack Fpods FX101 TWS Earbuds User Manual

Fastrack FX101

Fastrack Fpods FX101 TWS Earbuds User Manual

Model: FX101 (FT11GNA03)

1. INTRODUCTION

Welcome to the user manual for your new Fastrack Fpods FX101 TWS Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Bluetooth 5.4 connectivity, extended playtime, clear calls with Quad Mic ENC, and a low-latency gaming mode. Please read this manual carefully to ensure proper use and maintenance of your device.

2. WHAT'S IN THE BOX

- Fastrack Fpods FX101 TWS Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Eartips (various sizes)
- User Manual

3. PRODUCT OVERVIEW



Image: Fastrack Pods FX101 TWS Earbuds in their green charging case, showcasing the sleek design.

Key Features

- **Bluetooth v5.4:** Ensures seamless and uninterrupted connectivity.
- **40 Hours Playtime:** Enjoy extended audio playback on a single charge.
- **10mm Dynamic Bass Drivers:** Delivers rich, deep bass and clear sound.
- **Quad Mic ENC:** Enhanced Environmental Noise Cancellation for crystal clear calls.
- **50ms Ultra-Low Latency:** Provides a responsive and immersive gaming experience.
- **NitroFast Charging:** Quick charging capability for minimal downtime.
- **IPX6 Water Resistance:** Protects against sweat and splashes, ideal for workouts and outdoor use.
- **Voice Assistant Support:** Activate your device's voice assistant with a simple tap.



Image: An infographic detailing the Fastrack Fpods FX101's main features, including 40 hours of playtime, Quad mic ENC, 50ms low latency, 10mm deep bass drivers, IPX6 water resistance, and NitroFast Charge.

4. SETUP

4.1 Initial Charge

Before first use, fully charge your Fastrack Fpods FX101 and their charging case. Place the earbuds into the charging case and connect the USB charging cable to the case and a power source. The indicator light on the case will show charging status. A full charge for the case takes approximately 2 hours.

4.2 Pairing with Your Device

1. Ensure the earbuds are in the charging case and the case has sufficient charge.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. Select "Fastrack Fpods FX101" from the list.
5. Once connected, the LED indicator on the earbuds will stop flashing or change to a steady light, depending

on the model.

- The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

5. OPERATING INSTRUCTIONS

5.1 Touch Controls

The Fastrack Fpods FX101 feature intuitive touch controls on each earbud. The specific functions may vary slightly, but common controls include:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (2 seconds)	Reject Call
Long Press (Right Earbud)	Increase Volume
Long Press (Left Earbud)	Decrease Volume

Note: Refer to the specific product packaging or Quick Start Guide for any model-specific variations in touch controls.

5.2 Gaming Mode

To activate the 50ms ultra-low latency gaming mode, typically a specific touch gesture is required (e.g., a triple tap on a designated earbud or a long press). This mode reduces audio delay, providing a more synchronized audio-visual experience for gaming. Deactivate the mode using the same gesture when not gaming to conserve battery life.

5.3 Voice Assistant

Your Fastrack Fpods FX101 support voice assistant activation. A specific touch control (e.g., triple tap) will activate your device's default voice assistant (Siri, Google Assistant, etc.), allowing you to issue commands hands-free.

6. MAINTENANCE AND CARE

- Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- Eartips:** Remove and clean the eartips periodically to prevent wax buildup. You can gently wash them with water and mild soap, ensuring they are completely dry before reattaching.
- Charging Ports:** Keep the charging contacts on the earbuds and inside the case clean and free of debris.
- Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Water Resistance:** While IPX6 rated (resistant to strong water jets), avoid submerging the earbuds in water. Dry them thoroughly if they get wet from sweat or splashes.

- **Temperature:** Avoid exposing the earbuds to extreme temperatures (hot or cold) or high humidity.

7. TROUBLESHOOTING

If you encounter issues with your Fastrack Fpods FX101, try the following solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close the lid, wait a few seconds, then open to re-enter pairing mode. Forget the device on your phone's Bluetooth settings and try pairing again.
Only one earbud working	Check if both earbuds are charged. Place both back in the case, close and open the lid. If the issue persists, try resetting the earbuds (refer to product-specific reset instructions if available).
Low volume or poor sound quality	Clean the eartips and speaker mesh. Adjust volume on both your device and the earbuds. Ensure earbuds are properly seated in your ears.
Earbuds not charging	Ensure the charging cable is securely connected. Clean the charging contacts on both earbuds and the case. Try a different USB port or power adapter.
Bluetooth connection unstable	Ensure your device is within the 10-meter Bluetooth range. Avoid obstacles between the earbuds and your device. Turn off and on Bluetooth on your device.

8. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	FX101
Item Model Number	FT11GNA03
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	Up to 10 meters
Battery Life (Earbuds + Case)	Up to 40 Hours
Charging Time (Case)	Approx. 2 Hours
Carrying Case Battery Capacity	300 mAh
Audio Driver Size	10 mm Dynamic Driver
Audio Latency	50 Milliseconds (Gaming Mode)
Microphone	Quad Mic with ENC
Water Resistance	IPX6
Control Type	Touch Control
Item Weight	37 Grams
Product Dimensions	6.1 x 2.5 x 4.6 cm
Material	Plastic
Manufacturer	Titan Company Limited
Country of Origin	China

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your Fastrack Fpods FX101 TWS Earbuds come with a limited manufacturer's warranty. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and issues arising from normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

9.2 Customer Support

For any product-related queries, technical assistance, or warranty claims, please contact Fastrack customer support:

- **Manufacturer:** Titan Company Ltd
- **Address:** Titan Company Limited no- 03 Sipcot Industries complex Hosur - 635126
- **Customer Care:** 1800-266-0123
- **Email:** customercare@titan.co.in

