

## PUSOKEI PUSOKEI25udkgyfho-11

# PUSOKEI Speaker Bar Model PUSOKEI25udkgyfho-11 User Manual



## INTRODUCTION

Welcome to the user manual for your PUSOKEI Speaker Bar. This document provides essential information for setting up, operating, and maintaining your device. Please read it carefully to ensure optimal performance and longevity of your speaker bar.

## PRODUCT OVERVIEW

The PUSOKEI Speaker Bar is designed to deliver an immersive audio experience with versatile playback options and dynamic RGB lighting. Key features include:

- **Immersive Sound Experience:** Dual 4Ω 5W speakers provide stereo sound.
- **Multicolor RGB Light:** Dynamic RGB light effects synchronize with music rhythm.
- **Multi-Mode Connection:** Supports Bluetooth (BT), USB, AUX, and small memory card playback.
- **HD Sound and Low Distortion:** Wide frequency response (20Hz-20KHz) with high signal-to-noise ratio ( $\geq 75\text{db}$ ) and low distortion ( $\leq 0.1\%$ ).
- **Battery Powered:** Built-in 1500mAh lithium-ion battery for portable use.



*Image: Front view of the PUSOKEI Speaker Bar, showcasing its sleek design.*

## SETUP

### Initial Power On

To begin using your PUSOKEI Speaker Bar, simply turn it on and connect via Bluetooth.

### Charging the Device

The speaker bar features a built-in 1500mAh lithium-ion battery. Connect the provided data cable to the charging port on the speaker bar and a compatible USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will typically show charging status.



*Image: The PUSOKEI Speaker Bar shown with its included data cable for charging.*

## OPERATING INSTRUCTIONS

### Bluetooth (BT) Mode

1. Power on the speaker bar.
2. The speaker bar will automatically enter Bluetooth pairing mode (indicated by a flashing light or voice prompt).
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "PUSOKEI Speaker Bar" (or similar name) from the list to pair.
5. Once paired, you can play audio from your device through the speaker bar.

### USB Playback Mode

Insert a USB flash drive containing audio files into the USB port on the speaker bar. The speaker bar will automatically switch to USB mode and begin playing audio.

## AUX Mode

Connect an audio source (e.g., MP3 player, computer) to the AUX input port on the speaker bar using a 3.5mm audio cable (not included). The speaker bar will switch to AUX mode, and audio will be played from the connected device.

## Memory Card Playback Mode

Insert a small memory card (up to 64GB, not included) containing audio files into the designated memory card slot. The speaker bar will automatically switch to memory card mode and play audio.

## RGB Light Control

The speaker bar features multicolor RGB light effects that change with the rhythm of the music. Specific controls for the RGB light (e.g., on/off, mode change) would typically be found on the device's control panel. Refer to the physical buttons on your speaker bar for light control options.



*Image: The PUSOKEI Speaker Bar displaying its RGB light effects in a home setting.*

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker bar. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is discharged	Charge the speaker bar using the provided data cable.
No sound	Volume too low; Incorrect input mode; Device not paired (Bluetooth)	Increase volume on both speaker bar and connected device; Select correct input mode (BT, USB, AUX, Memory Card); Re-pair Bluetooth device.
Bluetooth pairing failure	Speaker bar not in pairing mode; Device too far; Interference	Ensure speaker bar is in pairing mode; Move devices closer; Turn off other Bluetooth devices.
RGB lights not working	Light feature turned off; Malfunction	Check if there's a button to activate/deactivate RGB lights; If problem persists, contact support.

## SPECIFICATIONS

Feature	Detail
Model Name	PUSOKEI25udkgyfho-11
Playback Type	Bluetooth (BT), USB, AUX, Memory Card (up to 64GB)
Bluetooth Distance	Approx. 10m / 32.8ft
Speaker Configuration	4Ω 5W x 2
Frequency Response	20Hz-20KHz
Signal to Noise Ratio	≥75db
Distortion	≤0.1%
Battery Type	1500mAh Lithium Ion Battery (Built-in)
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black







Feature	Detail
Package Dimensions	12.6 x 2.76 x 2.36 inches
Item Weight	1.14 pounds


# WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official PUSOKEI website. Keep your proof of purchase for warranty claims.



## Related Documents - PUSOKEI25udkgyfo-11

	<p><a href="#">Sony SF Series SD/SDHC Memory Card Operating Instructions and Limited Warranty</a></p> <p>Official operating instructions and limited warranty information for Sony SF Series SD and SDHC memory cards, including technical specifications, regulatory compliance, and usage precautions.</p>
	<p><a href="#">Philips Soundbar 8000 Series TAB8947 User Manual</a></p> <p>This document provides instructions and safety information for the Philips Soundbar 8000 Series TAB8947. Learn how to set up, connect, and use your soundbar for an enhanced audio experience.</p>
	<p><a href="#">Sony Memory Stick PRO Duo MS-MT Series Operating Instructions</a></p> <p>User manual and operating instructions for Sony Memory Stick PRO Duo MS-MT Series flash memory cards, detailing safety precautions, FCC compliance, specifications, and limited warranty information.</p>
	<p><a href="#">JBL Bar 9.1 True Wireless Surround Software Release Notes &amp; Upgrade Guide (v21.23.11.80)</a></p> <p>Official software release notes and manual upgrade instructions for the JBL Bar 9.1 True Wireless Surround soundbar system. Update to version 21.23.11.80 for improved performance and compatibility.</p>

<p>INSTRUCTION</p> <p>TOGUARD COLOR TFT-LCD MONITOR</p> <p>MIC, VGA &amp; HDMI INPUT</p>	<p><a href="#">TOGUARD 11.6-inch TFT-LCD Monitor User Manual</a></p> <p>User manual for the TOGUARD 11.6-inch TFT-LCD monitor, covering setup, menu operations, specifications, package contents, and troubleshooting for MIC, VGA, and HDMI inputs.</p>
 <p>The image shows the front cover of the 'HALCON Memory Management' book. At the top, the HALCON logo is displayed with the tagline 'a product of MVTec'. Below the logo, the title 'HALCON Memory Management' is printed. The central part of the cover features a vibrant, abstract image of a sunset or sunrise over a body of water, with a large, glowing, circular structure resembling a tunnel or a large eye in the sky. At the bottom left, the MVTec logo is visible, and at the bottom right, there is a small text box that says 'Building Vision for Business'.</p>	<p><a href="#">HALCON Memory Management Guide</a></p> <p>A technical guide detailing HALCON's memory management, including image, global, and temporary memory caches, superblocks, and strategies for handling suspected memory leaks.</p>