

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [YESHOMY](#) /

> [YESHOMY Farmhouse Coffee Table \(Model YH-COT0505-0BG\) Instruction Manual](#)

### YESHOMY YH-COT0505-0BG

# YESHOMY Farmhouse Coffee Table Instruction Manual

Model: YH-COT0505-0BG



Image: The YESHOMY Farmhouse Coffee Table, showcasing its design with a brown top and black base, and an open storage shelf.

## INTRODUCTION

Thank you for purchasing the YESHOMY Farmhouse Coffee Table. This manual provides essential information for the safe assembly, proper use, and effective maintenance of your new coffee table. Please read these instructions carefully before assembly and retain them for future reference.

## SAFETY INFORMATION

To ensure safe use and prevent damage, please observe the following safety guidelines:

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 90 pounds (40.8 kg) for the tabletop.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Avoid placing hot items directly on the tabletop without protective coasters.
- Do not stand or sit on the coffee table.
- This product is designed for indoor use only.

## PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
A	Tabletop	1
B	Side Panels (with X-design)	2
C	Bottom Shelf Slats	Multiple
D	Hardware Pack (Screws, dowels, Allen wrench)	1
E	Assembly Guide	1

## SETUP AND ASSEMBLY

Assembly typically takes approximately 30 minutes with one person. For optimal safety and ease, two people are recommended for certain steps. A screwdriver is recommended for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the "Package Contents" section are present.
2. **Attach Side Panels to Bottom Shelf:** Connect the bottom shelf slats (C) to the side panels (B) using the provided hardware. Ensure the slats are evenly spaced and securely fastened.

3. **Attach Tabletop:** Carefully align the tabletop (A) with the assembled base. Secure the tabletop to the side panels using the appropriate screws from the hardware pack (D).
4. **Tighten All Fasteners:** Once all components are in place, gently tighten all screws and fasteners. Do not overtighten.
5. **Final Placement:** Carefully move the assembled coffee table to its desired location.



*Image: The reinforced structure of the coffee table, highlighting the sturdy X-shaped side panels for enhanced stability.*

## OPERATING INSTRUCTIONS

The YESHOMY Farmhouse Coffee Table is designed for versatile use in your living space.

### Double Storage Space

This coffee table features a spacious tabletop and an open bottom shelf, providing ample storage and display options.

- **Tabletop:** Use the top surface for beverages, books, decorative items, or as a temporary workspace.
- **Bottom Shelf:** The slatted bottom shelf is ideal for organizing magazines, remote controls, blankets, or other living room essentials.




Image: Illustration of the dual storage space, demonstrating how the bottom shelf can accommodate various items like books, bottles, and decorative pieces.

## MAINTENANCE

Proper care will extend the life and appearance of your coffee table.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Promptly wipe up any spills to prevent staining, as the table is not stain-resistant.
- **Heat Protection:** Always use coasters under hot mugs or dishes to protect the tabletop from heat marks.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

## TROUBLESHOOTING

If you encounter any issues with your coffee table, please refer to the following common solutions:

Problem	Possible Cause	Solution
Table is wobbly	Loose fasteners or uneven floor.	Check and tighten all screws. Ensure the table is on a level surface. Use furniture pads if needed.
Scratches on surface	Contact with sharp objects or abrasive cleaning.	Use furniture polish or touch-up pens for minor scratches. Always use coasters and avoid dragging items across the surface.

Problem	Possible Cause	Solution
Parts missing during assembly	Packaging error.	Review the "Package Contents" section. Contact customer support with your model number and a description of the missing part.

## SPECIFICATIONS



Image: Detailed product dimensions of the coffee table, including width, depth, height, and tabletop thickness.

Feature	Detail
Model Number	YH-COT0505-0BG
Brand	YESHOMY
Dimensions (D x W x H)	21.7"D x 39.4"W x 17.1"H (55.1cm x 100.1cm x 43.4cm)
Item Weight	38.3 Pounds (17.37 kg)

Feature	Detail
Maximum Weight Recommendation	90 Pounds (40.8 kg)
Frame Material	Wood
Color	Brown & Black
Shape	Rectangular
Required Assembly	Yes
Recommended Number of People for Assembly	2
Product Care Instructions	Wipe with Dry Cloth
Is Stain Resistant	No

## OFFICIAL PRODUCT VIDEO

---

Watch this video for an overview of the YESHOMY Farmhouse Coffee Table's features and design.

Your browser does not support the video tag.

*Video: "Choose Your YESHOMY Farmhouse Coffee Table!" - This video showcases the coffee table's storage capabilities, reinforced design, and various uses in a home setting.*

## WARRANTY AND SUPPORT

---

For warranty information, replacement parts, or technical support, please contact YESHOMY customer service through the retailer where the product was purchased or visit the official YESHOMY website.

Please have your model number (YH-COT0505-0BG) and purchase date available when contacting support.