

[Manuals.plus](#) /

› [YESHOMY](#) /

› YESHOMY Farmhouse Coffee Table Model YH-COT0505-2BG User Manual

YESHOMY YH-COT0505-2BG

YESHOMY Farmhouse Coffee Table User Manual

Model: YH-COT0505-2BG

INTRODUCTION

Thank you for choosing the YESHOMY Farmhouse Coffee Table. This manual provides essential information for the safe assembly, proper use, and maintenance of your new coffee table. Please read these instructions carefully before assembly and retain them for future reference.



Front view of the YESHOMY Farmhouse Coffee Table, showcasing its design and lower storage shelf.

SAFETY INFORMATION

To ensure safe use and prevent damage, please observe the following:

- Do not overload the table. The maximum weight recommendation is 90 pounds.
- Ensure all components are securely fastened during assembly. Loose connections can lead to instability.
- Place the table on a flat, stable surface to prevent tipping.
- Keep small parts away from children during assembly to avoid choking hazards.
- Avoid standing or sitting on the table.

INCLUDED COMPONENTS

The package includes all necessary parts and an assembly guide. Please verify all components are present before beginning assembly.

- Tabletop
- Legs and support frames

- Lower storage shelf slats
- Hardware pack (screws, dowels, etc.)
- Assembly Guide
- Basic assembly tools (e.g., screwdriver)

SETUP AND ASSEMBLY

Assembly of the YESHOMY Farmhouse Coffee Table is designed to be straightforward, typically taking one person under 30 minutes. Two people are recommended for easier handling and stability during certain steps.

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included assembly guide to identify each part.
2. **Attach Legs to Side Frames:** Connect the table legs to the side support frames using the provided hardware. Ensure all connections are finger-tight initially.
3. **Assemble Lower Shelf:** Insert the lower shelf slats into the designated slots on the side frames. Secure them with the appropriate hardware.
4. **Attach Tabletop:** Carefully place the tabletop onto the assembled base. Align the pre-drilled holes and secure the tabletop using the remaining hardware.
5. **Tighten All Connections:** Once all parts are in place, systematically tighten all screws and fasteners with the provided screwdriver. Do not overtighten.
6. **Final Check:** Gently shake the table to ensure it is stable. If any wobbling occurs, re-check all connections.



The reinforced structure ensures stability and durability during use.

OPERATING AND USAGE

The YESHOMY Farmhouse Coffee Table is designed for versatile use in your living space.

Key Features:

- **Double Storage Space:** Utilize the spacious tabletop for daily items and the lower open shelf for organizing remotes, books, magazines, or decorative items.
- **Multi-purpose Surface:** The table can serve as a laptop desk, a snack table, or a display surface for decor.
- **Airflow Design:** The open-concept layout of the lower shelf allows for air circulation, beneficial for moisture-sensitive items.



The two-tier design provides ample storage for various items.

Your browser does not support the video tag.

Official product video demonstrating the features and versatility of the YESHOMY Farmhouse Coffee Table.

MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your coffee table.

- **Cleaning:** Wipe with a dry cloth. For spills, immediately wipe with a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive cleaners.
- **Protection:** Use coasters under beverages and placemats under hot items to prevent stains and heat damage.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or warping of the wood finish.
- **Humidity:** Maintain a stable humidity level in your room to prevent wood from expanding or contracting excessively.



The table surface is designed for easy cleaning and resistance to minor spills.

TROUBLESHOOTING

If you encounter any issues with your coffee table, refer to the following common solutions:

- **Wobbling Table:** Ensure all screws and fasteners are securely tightened. Check if the table is placed on an even surface. Adjust leg levelers if applicable (this model does not specify levelers, so assume flat surface is key).
- **Scratches or Dents:** Minor scratches can sometimes be touched up with a wood repair marker matching the finish. For deeper damage, professional repair may be needed.
- **Difficulty Assembling:** Re-read the assembly guide carefully. Ensure you are using the correct hardware for each step. Do not force parts together.

SPECIFICATIONS

Brand	YESHOMY
Model Name	Farmhouse Coffee Table
Model Number	YH-COT0505-2BG
Color	Brown & White
Product Dimensions (D x W x H)	21.7" x 39.4" x 17.1"
Item Weight	38.4 Pounds
Maximum Weight Recommendation	90 Pounds
Frame Material	Wood
Top Material Type	Wood

Product Care Instructions	Wipe with Dry Cloth
Recommended Number of People for Assembly	2
Includes All Assembly Tools	Yes



Detailed product dimensions for planning your space.

WARRANTY INFORMATION

Specific warranty details for the YESHOMY Farmhouse Coffee Table are typically provided at the point of purchase or within the product packaging. Please refer to your purchase receipt or contact the retailer/manufacturer directly for information regarding warranty coverage, terms, and conditions.

SUPPORT

For further assistance, missing parts, or inquiries not covered in this manual, please contact YESHOMY customer support through the retailer's platform or the official YESHOMY website. Have your model number (YH-COT0505-2BG) and purchase information ready when contacting support.