

[manuals.plus](#) /› [Bewinner](#) /› [Bewinner Video Music Player User Manual - 1.8in Color Screen MP3 MP4 Player \(Model: Bewinnerwtf9mg3kug-11\)](#)

Bewinner Bewinnerwtf9mg3kug-11

Bewinner Video Music Player User Manual

Model: Bewinnerwtf9mg3kug-11

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Bewinner Video Music Player. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. This device is designed for portable entertainment, offering music, video, photo, and e-book playback, along with voice recording capabilities.

2. PRODUCT OVERVIEW

The Bewinner Video Music Player is a compact, multifunctional device featuring a 1.8-inch color screen. It supports various audio and video formats and offers expandable storage up to 128GB. The player includes independent volume control and can function as a memory card reader or file storage device.

2.1. Key Features

- 1.8-inch Color Screen for clear visual experience.
- HiFi Lossless Sound Quality with built-in powerful box speaker.
- Expandable memory up to 128GB via memory card (not included).
- Supports MP3, WMA, APE, FLAC, WAV, OGG audio formats.
- Supports AMV video format (converted video).
- Supports JPG, JPEG, BMP, GIF image formats.
- Supports TXT e-book format.
- Noise-canceling voice recording function.
- High-speed Mini USB 2.0 for data transfer.
- Up to 10 hours of music playback on a single charge.

2.2. Device Components

Familiarize yourself with the player's layout:



Image: Front view of the Bewinner Video Music Player, showing the 1.8-inch color screen, navigation buttons (MENU, VOL, Play/Pause, Skip), and a music note icon on the screen.



Image: Close-up view of the bottom edge of the player, highlighting the Mini USB port for charging and data transfer, and the 3.5mm headphone jack.



Image: The Bewinner Video Music Player displayed alongside its standard accessories: a Mini USB charging/data cable and a pair of white wired earphones.

3. SETUP

3.1. Charging the Device

Before first use, fully charge the player. Connect the provided Mini USB cable to the player's USB port and the other end to a USB power adapter (not included) or a computer's USB port. A full charge typically takes 1 to 2 hours. The battery indicator on the screen will show charging status.

3.2. Inserting a Memory Card

The player's memory can be expanded up to 128GB using a memory card (not included). Locate the memory card slot on the side of the device. Gently insert the memory card into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.

3.3. Connecting to a Computer

To transfer files, connect the player to your computer using the Mini USB cable. The device will be recognized as a removable disk. You can then drag and drop music files, videos, photos, or e-books directly into the player's storage or the inserted memory card's folders.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

Press and hold the power button (usually located on the side or top) for a few seconds to turn the device on or off.

4.2. Basic Navigation

Use the central navigation buttons to move through menus and select options:

- **MENU Button:** Access the main menu or go back to the previous screen.
- **VOL Button:** Adjust the volume level.
- **Left/Right Arrows:** Navigate between menu items or skip tracks/chapters.
- **Center Button:** Confirm selection or Play/Pause during media playback.

4.3. Music Playback

1. From the main menu, select 'Music'.
2. Browse your music library by artist, album, or folder.
3. Select a song and press the center button to play.
4. Use the left/right arrows to skip tracks. Use the VOL button to adjust volume.

4.4. Video Playback

1. Ensure your video files are in AMV format. Convert other formats if necessary.
2. From the main menu, select 'Video'.
3. Browse and select your desired video file.
4. Press the center button to play.

4.5. Photo Viewing

1. From the main menu, select 'Pictures' or 'Photos'.
2. Browse your image files (JPG, JPEG, BMP, GIF).
3. Select an image to view it on the screen.

4.6. E-book Reading

1. Ensure your e-book files are in TXT format.
2. From the main menu, select 'E-book'.
3. Browse and select your desired TXT file to begin reading.

4.7. Voice Recording

1. From the main menu, select 'Recorder' or 'Voice Record'.
2. Follow the on-screen prompts to start, pause, and save recordings.
3. The device features noise-canceling for clearer recordings.

Video: A short demonstration of the Bewinner Video Music Player's features, including its compact size, color screen, and navigation buttons. This video provides a visual overview of the product in use.

5. MAINTENANCE

- Keep the device dry. Moisture can damage electronic components.
- Avoid extreme temperatures.
- Clean the screen and body with a soft, dry cloth. Do not use harsh chemicals.
- Protect the screen from scratches.
- Avoid dropping or subjecting the device to strong impacts.

6. TROUBLESHOOTING

6.1. Device Does Not Turn On

- Ensure the battery is charged. Connect to a power source and try again.
- Press and hold the power button for an extended period (5-10 seconds).

6.2. Cannot Transfer Files

- Check the USB cable connection to both the player and the computer.
- Try a different USB port on your computer.
- Ensure the player is in data transfer mode if prompted.

6.3. No Sound

- Check the volume level using the VOL button.
- Ensure headphones are properly connected if using them.
- Test with different audio files to rule out file corruption.

6.4. Video Files Not Playing

- Verify that the video files are in AMV format. Other formats are not supported.
- Ensure the file is not corrupted.

7. SPECIFICATIONS

Feature	Specification
Model Name	Bewinnerwtf9mg3kug-11
Screen Size	1.8 Inch Color Screen
Battery Type	Built-in 180mAh Lithium Ion Battery
Charging Time	1 to 2 hours

Music Playback Time	Up to 10 hours (lossless music)
Memory Card Support	Maximum 128GB (not included)
Music Formats	MP3, WMA, OGG, APE, FLAC, WAV, etc.
Video Format	AMV (Converted Video)
Image Formats	JPG, JPEG, BMP, GIF
E-book Format	TXT
Special Feature	Voice Recorder
Connectivity	USB (Mini USB 2.0)
Item Weight	3.1 ounces
Package Dimensions	5.12 x 4.72 x 1.18 inches


8. WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the packaging or the seller's website for specific warranty terms and conditions. Keep your proof of purchase for any warranty claims.

9. SUPPORT

For technical assistance, troubleshooting beyond this manual, or customer service inquiries, please contact Bewinner customer support through the retailer's platform or the official Bewinner website. Please have your model number (Bewinnerwtf9mg3kug-11) and purchase details ready.

Related Documents - Bewinnerwtf9mg3kug-11

 Portable Tri-Screen for Laptop USER GUIDE (15 inch) <small>Adaptive Sync, FHD, 1000nit, 100% sRGB</small>	<u>Bewinner Portable Tri-Screen for Laptop User Guide (15 inch)</u> User guide for the Bewinner Portable Tri-Screen for Laptop (15 inch), covering setup, connection methods, display configuration, OSD settings, and technical specifications. Compatible with 15-17 inch laptops.
 DVR Inch Smart Screen Player <small>User Manual</small>	<u>11.26-inch Smart Screen Player User Manual</u> User manual for the 11.26-inch Smart Screen Player, detailing its features, specifications, installation, and operation for enhanced car infotainment and connectivity. Covers CarPlay, Android Auto, screen mirroring, audio modes, and device settings.

	<p>Philips AZ 4000 MP3-CD Soundmachine User Manual Comprehensive user manual for the Philips AZ 4000 MP3-CD Soundmachine, detailing setup, controls, playback functions for MP3-CDs and CDs, tuner operation, power supply, sound adjustment, maintenance, and troubleshooting.</p>
	<p>iRiver Clix User Guide User's guide for the iRiver Clix portable media player, covering setup, basic operations, and additional features.</p>
	<p>JMCQ 11.26-inch Smart Screen Player User Manual Comprehensive user manual for the JMCQ 11.26-inch Smart Screen Player, detailing its features, installation, operation, and settings for enhanced car audio and video experience.</p>
	<p>NovaStar TU15 Pro LED Playback Control Processor Specifications and Features Detailed specifications, features, and technical information for the NovaStar TU15 Pro LED Playback Control Processor, including inputs, outputs, system functions, dimensions, media decoding capabilities, and installation notes.</p>