NICESOUL EC

NICESOUL Double Egg Chair (Model EC) Instruction Manual

Indoor Outdoor Double Egg Chair with Footstools & Thick Cushions

Introduction

Thank you for choosing the NICESOUL Double Egg Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read all instructions carefully before use and retain this manual for future reference.

Safety Information

- Always follow the assembly instructions provided to ensure proper setup and stability.
- Keep the chair away from direct heat sources and sharp objects to prevent damage to the frame and fabric.
- Do not exceed the maximum weight capacity of **600 lbs (272 kg)**. This chair is designed for two adults.
- Keep the chair clean and dry to maintain its water-resistant properties and prolong its lifespan.
- Ensure the chair is placed on a stable, level surface to prevent tipping.

Package Contents

Verify that all components are present before beginning assembly. Your package should include:

- 1 Stationary Egg Chair Frame
- 2 Footrests
- 3 Cushions (for chair and footrests)
- 2 Head Support Pillows
- 1 Rain Cover
- Accessory Kit (hardware for assembly)
- Instruction Manual

Note: The chair, footrests, and cover may arrive in separate packages. Please wait for all packages before starting assembly.



Image: Illustration showing two separate packages for the chair and footrests, with a note about potential staggered delivery.

Setup and Assembly

Assembly of your NICESOUL Double Egg Chair is designed to be straightforward. It typically takes approximately 40 minutes with two people. A socket wrench set is recommended for easier tightening of bolts.

1. Unpack all components and verify against the package contents list.
2. Follow the step-by-step instructions provided in the included assembly manual.
3. Ensure all connections are secure but avoid overtightening bolts to prevent stripping.
4. If you encounter minor alignment issues, slightly loosen the screws for the affected parts, adjust them into position, and then re-tighten all screws evenly.
5. Once the frame is assembled, place the cushions and head support pillows into the chair and on the footrests.




Image: Diagram illustrating the dimensions of the double egg chair and its accompanying footstools, including height, width, depth, and weight capacity.

Assembly Video

Your browser does not support the video tag.

Video: Official NICESOUL video demonstrating the assembly process and features of the Stationary Wicker Egg Chair for indoor and outdoor use.

Operating Instructions (Usage)

Your NICESOUL Double Egg Chair is designed for versatile use and comfort.

- **Seating:** The chair comfortably accommodates two people, making it ideal for shared relaxation.
- **Footstools:** Use the included footstools for enhanced leg support while lounging. They can also serve as additional seating or small side tables.
- **Versatile Placement:** This chair is suitable for various indoor and outdoor environments, including living rooms, gardens, patios, balconies, and sunrooms.
- **Relaxation:** Enjoy activities such as lounging, reading, relaxing, or napping in the comfortable, oversized design.



Image: A family of three relaxing comfortably on the double egg chair with footstools on an outdoor balcony, demonstrating its spacious design.



Image: A woman reading on an ottoman, another ottoman used as a coffee table, and a cat sleeping on a cushion, illustrating the multi-functional use of the ottomans.

Maintenance

Proper care will ensure the longevity and appearance of your NICESOUL Double Egg Chair.

- **Cleaning:** Wipe down the surfaces of the chair frame and cushions with a damp cloth. For stubborn stains on cushions, use a mild soap solution and rinse thoroughly.
- **Fabric Care:** The cushions are made from UV-resistant, water-repellent, and colorfast polyester fabric. While designed for outdoor use, prolonged exposure to harsh weather conditions should be avoided.
- **Frame Care:** The powder-coated alloy steel frame is rust-resistant. Inspect regularly for any signs of wear or damage.
- **Protection:** Use the included rain cover to protect the chair from rain, sun, wind, and snow when not in use or during adverse weather.



Image: Close-up view of the chair's cushion fabric with water droplets, highlighting its fade-resistant, UV-protected, and water-resistant properties.



Image: Four-panel image demonstrating the waterproof, UV-resistant, windproof, and snow-resistant features of the chair's protective cover.

Troubleshooting

If you encounter any issues, refer to the following common solutions:

Issue: Parts do not align during assembly.

Solution: Loosen all screws for the affected section slightly. Adjust the parts to align correctly, then gradually tighten all screws evenly. Avoid overtightening.

Issue: Cushion feels too thin or uncomfortable.

Solution: Consider adding an additional bench cushion or padding underneath the existing cushion for enhanced comfort. Ensure any added cushions do not compromise stability.

Issue: Cushion slides around.

Solution: Secure the cushion to the chair frame using tie-off straps or ribbons to prevent movement.

Specifications

Brand	NICESOUL
Model Name	Stationary Egg Chair with Footrest
Model Number	EC
Color	Brown
Size	Double Size With Footrest & Cover
Product Dimensions (D x W x H)	25.6"D x 57.1"W x 56.3"H
Seat Height	16.7 inches
Seat Depth	25.6 inches
Item Weight	47.7 pounds
Maximum Weight Recommendation	600 pounds
Material	All-Weather Hand-Woven PE Rattan, Alloy Steel, Strong Supportive Padded Cushion
Frame Material Type	Alloy Steel (Powder Coated)
Fabric Type	Polyester
Indoor/Outdoor Usage	Indoor, Outdoor
Included Components	1 Rain Cover, 1 Stationary Egg Chair, 2 Footrests, 3 Cushions with 2 Head Support Pillows, Accessory Kit



Image: Detailed view of the chair's heavy-duty alloy steel base with anti-rust protection and adjustable balancing feet, highlighting its 600 lbs support and all-weather protection.



Image: Close-up of the hand-woven PE rattan wicker, emphasizing its weather-resistant, crack-resistant, and UV-resistant qualities.

Warranty and Support

For any questions, concerns, or assistance with your NICESOUL Double Egg Chair, please contact NICESOUL customer support. Our team is committed to providing timely responses and support to ensure your satisfaction.

Please refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question