

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Miroir](#) /
- › [Miroir M200S Smart HD Portable Projector User Manual](#)

Miroir M200S

Miroir M200S Smart HD Portable Projector User Manual

Your comprehensive guide to setting up, operating, and maintaining your Miroir M200S projector.

1. PRODUCT OVERVIEW

The Miroir M200S is a compact and versatile smart HD portable projector designed for a wide range of entertainment and presentation needs. Featuring Android TV for direct streaming, auto-focus, and multiple connectivity options, it delivers a vibrant display up to 100 inches.



Figure 1: Front view of the Miroir M200S projector, showing the lens and speaker grille.

Key Features:

- **Smart Streaming with Android TV:** Access popular apps like Netflix, YouTube, and Disney+ directly.

- **Sharp HD Resolution:** Delivers crisp 720p HD visuals, supporting up to 1080p content.
- **Auto Focus & Vertical Keystone:** Ensures a clear, perfectly aligned picture automatically.
- **Compact & Portable:** Lightweight design for easy transport and use anywhere.
- **Integrated Audio:** Built-in 3W speaker for clear sound.
- **Flexible Connectivity:** Includes HDMI, USB-C, USB-A, Bluetooth, and Wi-Fi.
- **100" Display Capability:** Project a vibrant image up to 100 inches.

2. WHAT'S IN THE BOX

Upon unboxing your Miroir M200S projector, please ensure all the following items are present:

- Miroir M200S Smart HD Portable Projector
- Remote Control
- Power Adapter
- AV Cable
- User Manual (this document)

3. SETUP GUIDE

3.1. Physical Setup

1. **Choose a Location:** Place the projector on a stable, flat surface. Ensure there is adequate ventilation around the device. For optimal viewing, project onto a smooth, light-colored wall or a projector screen.
2. **Power Connection:** Connect the power adapter to the projector's power input port and then plug it into a wall outlet.
3. **Initial Power On:** Press the power button on the projector or the remote control to turn on the device.



Figure 2: Rear view of the Miroir M200S, highlighting the USB, HDMI, and USB-C ports.

3.2. Initial Configuration

1. **Language Selection:** Follow the on-screen prompts to select your preferred language.
2. **Network Connection:** Connect the projector to your Wi-Fi network. This is essential for accessing Android TV streaming services.
3. **Google Account Setup:** Sign in with your Google account to access the Google Play Store and personalize your Android TV experience.
4. **Auto Focus & Keystone Correction:** The M200S features automatic focus and vertical keystone correction. The projector will adjust the image clarity and shape automatically. If manual adjustment is needed, use the remote control.



Figure 3: Top view of the Miroir M200S, showing the integrated control panel.

4. OPERATING INSTRUCTIONS

4.1. Navigating Android TV

Use the included remote control to navigate the Android TV interface. The remote allows you to browse apps, select content, and adjust settings.



Figure 4: Illuminated control panel on the top of the Miroir M200S projector.

4.2. Connecting External Devices

The Miroir M200S offers various ports for connecting external devices:

- **HDMI:** Connect gaming consoles, Blu-ray players, laptops, or other HDMI-enabled devices.
- **USB-C:** Connect compatible smartphones, tablets, or laptops for video output and charging.
- **USB-A:** Connect USB drives for media playback or external peripherals.
- **Bluetooth:** Pair with external Bluetooth speakers or headphones for enhanced audio.
- **Wi-Fi:** Stream content wirelessly from your network or mirror your smartphone screen.

4.3. Adjusting Image and Sound

- **Focus:** The projector features auto-focus. If the image appears blurry, gently move the projector slightly or use the remote to trigger auto-focus again.
- **Keystone Correction:** Vertical keystone correction is automatic. For manual adjustments, refer to the settings menu in Android TV.
- **Volume:** Adjust the volume using the remote control. For louder audio, connect external Bluetooth

speakers.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Miroir M200S projector, follow these maintenance guidelines:

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or excessive force.
- **Cleaning the Exterior:** Wipe the exterior of the projector with a soft, dry cloth. Avoid using liquid cleaners directly on the device.
- **Ventilation:** Ensure the ventilation openings are clear of dust and obstructions to prevent overheating. Do not block the air vents during operation.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Miroir M200S projector, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
No image projected	Power issue; Input source not selected; Lens cap on	Check power connection; Select correct HDMI/USB input; Remove lens cap.
Image is blurry	Out of focus; Projector too close/far from surface	Allow auto-focus to adjust or manually adjust focus via remote. Adjust projection distance.
Image is distorted (trapezoid shape)	Incorrect keystone correction	The projector has auto vertical keystone. Ensure the projector is placed on a level surface. If needed, check settings for manual keystone adjustment.
No sound	Volume too low; External audio device not connected/paired	Increase volume; Check Bluetooth connection to external speakers; Ensure internal speaker is not muted.
Wi-Fi connection issues	Incorrect password; Router too far; Interference	Re-enter Wi-Fi password; Move projector closer to router; Restart router.

7. SPECIFICATIONS

Brand:	Miroir
Model:	M200S
Display Resolution:	1280 x 720 (HD), supports up to 1080p content
Connectivity Technology:	HDMI, USB-C, USB-A, Bluetooth, Wi-Fi
Special Features:	3D-Ready, Auto Focus, Built-In Wi-Fi, Digital Keystone Correction, Portable
Item Weight:	1.79 pounds
Product Dimensions:	4.6 x 4.6 x 1 inches
Color:	Black
Recommended Uses:	Indoor/Outdoor


8. WARRANTY AND SUPPORT



For warranty information and customer support, please refer to the official Miroir website or the documentation included with your purchase. You can also visit the [Miroir M200S product page](#) for additional resources and FAQs.

For further assistance, please contact Miroir customer service through their official channels.

© 2025 Miroir. All rights reserved.

Related Documents - M200S

	<p>Miroir L710S Pro 1080p Smart LCD Projector with SYNQ TV - Quick Start Guide & Specifications</p> <p>Get started with your Miroir L710S Pro 1080p Smart LCD Projector. This guide covers setup, remote control, connections, settings, projection modes, Wi-Fi, screen mirroring, ceiling installation, specifications, troubleshooting, and safety information.</p>
---	--

	<p>Miroir L500S Full HD 1080p Projector User Guide</p> <p>A comprehensive guide to the Miroir L500S Full HD 1080p projector, detailing its features, connections, wireless setup, image adjustments, troubleshooting steps, and FCC compliance information.</p>
	<p>Miroir M190 Mini Pro Projector: Quick Start Guide</p> <p>Get started quickly with the Miroir M190 Mini Pro Projector. This guide provides setup instructions, feature descriptions, and troubleshooting tips for your portable projector.</p>
	<p>Miroir DrivvPlay 7" CarPlay & Android Auto Quick Start Guide</p> <p>A quick start guide for the Miroir DrivvPlay, a 7-inch display unit that supports CarPlay and Android Auto, featuring voice control and Bluetooth audio. Includes setup instructions, product specifications, and safety information.</p>
	<p>Miroir M600 Full HD Pro Projector Quick Start Guide</p> <p>A quick start guide for the Miroir M600 Full HD Pro Projector, covering setup, troubleshooting, and device features in multiple languages.</p>
	<p>Miroir L300 Full HD Pro Projector Quick Start Guide</p> <p>A quick start guide for the Miroir L300 Full HD Pro Projector, detailing setup, connections, troubleshooting, and wireless connectivity for various devices.</p>