

TuTu TUV32FN1B

TuTu Smart TV 32 Inch Full HD LED Television User Manual

Model: TUV32FN1B

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your TuTu 32-inch Full HD Smart LED Television, Model TUV32FN1B. Please read this manual thoroughly before using the television and retain it for future reference.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent electric shock, fire, or injury:

- Do not expose the television to rain or moisture.
- Ensure proper ventilation around the unit.
- Do not block ventilation openings with items such as newspapers, tablecloths, or curtains.
- Do not place objects filled with liquids, such as vases, on the television.
- Protect the power cord from being walked on or pinched.
- Unplug the television during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- TuTu 32-inch Full HD Smart LED Television
- Remote Control (1)
- Batteries for Remote Control (2)
- Base Stands (2)
- Screws for Base Stands (4)

- Quick Start Guide
- User Manual (this document)




Image: Contents of the TuTu Smart TV package, including the television, remote control, stand, and accessories.

4. SETUP

4.1 Attaching the Stand

1. Carefully place the television face down on a soft, flat surface to prevent screen damage.
2. Align the base stands with the screw holes on the bottom of the television.
3. Secure each stand with the provided screws.

4.2 Wall Mounting (Optional)

The television supports VESA 100x100mm wall mounts. Ensure you use a compatible wall mount kit (sold separately) and follow the instructions provided with the mount. Remove the base stands before wall mounting.

VESA 100 x 100



Image: Television dimensions and VESA 100x100mm mounting compatibility.

4.3 Connecting Peripherals

Your TuTu Smart TV offers various connection options:

- **HDMI:** Connect up to three HDMI devices (e.g., game consoles, Blu-ray players).
- **USB:** Two USB ports for media playback or DVR functionality.
- **Antenna (RF):** Connect a terrestrial antenna for DVB-T/T2 channels.
- **Satellite (LNB IN):** Connect a satellite dish for DVB-S/S2 channels.
- **CI/CI+:** Insert a Common Interface module for encrypted channels.
- **LAN (RJ45):** For a wired internet connection.
- **Optical:** Digital audio output for soundbars or home theater systems.
- **AV:** Analog video and audio input.
- **Earphone:** 3.5mm audio output for headphones.



Image: Detailed view of the television's connectivity ports.




Image: Triple Tuner and CI+ slot for various channel reception methods.

4.4 Initial Power On and Setup Wizard

1. Connect the power cord to the television and a power outlet.
2. Press the power button on the remote control or the TV.
3. The initial setup wizard will guide you through language selection, network connection (Wi-Fi or LAN), and channel scanning.
4. For Wi-Fi setup, select your network and enter the password.
5. Perform an automatic channel scan for DVB-T/T2, DVB-C, or DVB-S/S2 channels based on your connection.

5. OPERATING THE TV

5.1 Remote Control Overview

The remote control provides access to all television functions. Insert the two provided batteries into the remote control, ensuring correct polarity.



Image: TuTu Smart TV remote control with key function indicators.

5.2 Basic Functions

- **Power:** Press the **Power** button to turn the TV on or off.
- **Volume:** Use **VOL +/-** buttons to adjust the volume.
- **Channel:** Use **CH +/-** buttons to change channels.
- **Input:** Press the **INPUT** button to select input sources (HDMI, AV, Tuner).
- **Navigation:** Use the arrow buttons and **OK** button to navigate menus.

5.3 Smart TV Features (VIDAA OS)

Your television runs on the VIDAA OS, providing access to a variety of smart features and applications.

- **App Store:** Access the integrated App Store to download and install applications such as Netflix, YouTube,

Disney+, Prime Video, and more.

- **Pre-installed Apps:** Quickly launch popular streaming services using dedicated buttons on your remote or through the VIDAA home screen.
- **Web Browser:** Browse the internet directly from your TV.




Image: VIDAA OS interface showing available applications.

5.4 Connectivity

- **Wi-Fi:** Connect wirelessly to your home network for internet access and streaming.
- **Bluetooth:** Pair Bluetooth-enabled devices such as headphones, soundbars, or game controllers.
- **Screen Mirroring:** Project content from your smartphone or tablet to the TV (compatibility may vary by device).



Image: Bluetooth 5.0 connectivity for various audio devices.

5.5 Media Playback and DVR

Insert a USB drive into one of the USB ports to play media files (photos, videos, music) or to record live TV programs (DVR function).

6. MAINTENANCE

- **Cleaning the Screen:** Gently wipe the screen with a soft, dry, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for televisions.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Software Updates:** The TV may receive automatic software updates via the internet. Ensure your TV is connected to the internet for optimal performance and security.

7. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No power	Check if the power cord is securely plugged into the TV and the wall outlet. Ensure the power outlet is active.
No picture, but sound is present	Ensure the correct input source is selected. Check cable connections to external devices.
No sound, but picture is present	Check volume level and mute status. Verify audio cable connections. If using external audio, ensure it's correctly configured.
Remote control not working	Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Ensure Wi-Fi is enabled on the TV. Verify Wi-Fi password. Restart your router.
Smart features are slow or unresponsive	Check internet connection speed. Close unused applications. Restart the TV.

If the problem persists, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	TuTu
Model	TUV32FN1B
Screen Size	32 Inches
Display Technology	LED
Resolution	1080p Full HD (1920x1080)
Operating System	VIDAA
Refresh Rate	60 Hz
Connectivity	Wi-Fi, Bluetooth, Ethernet (LAN)
Tuner Technology	DVB-T/T2 (Terrestrial), DVB-C (Cable), DVB-S/S2 (Satellite)
HDMI Ports	3
USB Ports	2
Audio Output	Optical, Earphone (3.5mm)
Special Features	USB Recording (DVR), Dolby Audio
VESA Compatibility	100x100mm
Dimensions (with stand)	78.4 x 16.4 x 46.4 cm (W x D x H)
Weight (with stand)	5.28 kg

9. WARRANTY AND SUPPORT

Your TuTu Smart TV is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact TuTu customer service through the contact information provided on the warranty card or the official TuTu website. For online resources and frequently asked questions, visit the official TuTu support page:[TuTu Official Store](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question