

[Manuals.plus](#) /

› [ROTTOGOON](#) /

› ROTTOGOON 12.8" Touch Control Table Lamp Instruction Manual

ROTTOGOON ROLP442AW2

ROTTOGOON 12.8" Touch Control Table Lamp

INSTRUCTION MANUAL

Introduction

Thank you for purchasing the ROTTOGOON 12.8" Touch Control Table Lamp. This modern and versatile lamp is designed to provide convenient lighting and charging solutions for your home or office. Featuring 3-way dimmable touch control, dual USB charging ports (Type-A and Type-C), and an included 5000K daylight LED bulb, it offers both functionality and style.

Important Safety Instructions

- Read all instructions carefully before assembly and use.
- Do not operate the lamp with a damaged cord or plug. If damaged, contact customer support.
- Ensure the power supply is disconnected before cleaning or replacing the bulb.
- This lamp is designed for indoor use only. Do not expose to water or high humidity.
- Keep away from flammable materials.
- Do not attempt to modify or disassemble the lamp beyond the instructions provided.
- Use only E26 base bulbs as specified.

Package Contents

Verify that all components are present:

- Lamp Base with integrated USB-A and USB-C ports
- Lamp Shade (White Flaxen Fabric)
- E26 Base 5000K Daylight LED Bulb
- Fixing Ring
- UL Plug Power Cord



Image: Key components of the lamp, showing the UL plug, touch switch, flaxen fabric lampshade, and the USB-A and USB-C ports on the base.

Setup Instructions

Follow these steps to assemble your ROTTOGOON table lamp:

1. **Unscrew the Fixing Ring:** Carefully unscrew the black fixing ring from the lamp holder on the base.
2. **Fix the Lamp Shade:** Place the fabric lamp shade onto the lamp holder, ensuring it sits securely.
3. **Tighten the Fixing Ring:** Screw the fixing ring back onto the lamp holder to secure the lamp shade in place.
4. **Install the Bulb:** Screw the provided E26 LED bulb into the lamp holder until it is firm. Do not overtighten.
5. **Connect to Power:** Plug the lamp's power cord into a standard electrical outlet.



Image: Visual guide demonstrating the four steps for assembling the lamp: unscrewing the fixing ring, placing the lampshade, tightening the fixing ring, and installing the LED bulb.

Your browser does not support the video tag.

Video: An official product video demonstrating the assembly process, 3-way dimming, and USB charging functionality of the ROTTOGOON Touch Control Table Lamp.

Operating Instructions

Your ROTTOGOON table lamp offers intuitive touch control and convenient charging features:

- **3-Way Dimmable Touch Control:** To turn the lamp on/off or adjust brightness, simply tap anywhere on the metal lamp base. Each tap cycles through three brightness levels: Low, Medium, and High. A fourth tap will turn the lamp off.
- **Dual USB Charging Ports:** The lamp base includes one USB-A port and one USB-C port. These ports can be used to charge smartphones, tablets, power banks, or other USB-powered devices. The charging function works whether the lamp is on or off, as long as the lamp is plugged into a power outlet.



3 Way Dimmable

simply touch any part of the base to adjust light level



Image: The lamp illustrating its 3-way dimmable functionality, showing the light output at low, medium, and high settings, controlled by touching the base.



Convenient to charge your electronics with dual USB ports no matter lamps are on or off



usb A



usb C



Humidifier



Kindle



Smartphone



Earphone

Image: A person utilizing the dual USB-A and USB-C charging ports on the lamp base to charge various electronic devices, highlighting the convenience of this feature.

Maintenance

- **Cleaning:** Disconnect the power before cleaning. Wipe the lamp base with a soft, dry cloth. For the fabric lampshade, use a lint roller or a soft brush to remove dust. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled down. Unscrew the old E26 bulb and replace it with a new E26 base LED bulb (maximum 60W equivalent).

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in. Bulb is loose or faulty. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check if the bulb is screwed in tightly. Replace the bulb if necessary. Test the outlet with another device.
Touch control is unresponsive.	Loose connection. Interference from other electronics.	Unplug the lamp, wait a few seconds, and plug it back in. Move the lamp away from other electronic devices that might cause interference.
USB ports are not charging.	Lamp not plugged in. Charging cable is faulty. Device incompatibility.	Ensure the lamp is plugged into a live power outlet. Try a different charging cable. Verify your device is compatible with standard USB charging.

Specifications

Brand:	ROTTOGOON
Model Number:	ROLP442AW2
Product Dimensions:	3.9"D x 3.9"W x 12.8"H
Base Material:	Wood
Shade Material:	Linen
Finish Type:	Brushed
Switch Type:	Touch Control
Light Source Type:	LED
Bulb Base:	E26
Included Bulb:	5000K Daylight LED (60W equivalent)
Dimmable:	3-Way (Low, Medium, High)
USB Ports:	1x USB-A, 1x USB-C
Power Source:	Corded Electric
Indoor/Outdoor Usage:	Indoor



Image: A detailed diagram illustrating the physical dimensions of the lamp and the specifications of the E26 base A15 LED 5W bulb.

Warranty and Support

ROTTOGOON strives to offer quality products and services. For any assistance needed regarding your modern touch lamp, please feel free to contact us. Refer to your purchase documentation for specific warranty details.

Manufacturer: ROLP442AW2

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question