Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Coleshome 140 cm

Coleshome L Shaped Desk with Drawers and File Cabinet, 140 cm - User Manual

Model: 140 cm L-Shaped Desk

Introduction

Thank you for choosing the Coleshome L Shaped Desk. This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your new desk. Designed for home office use, this 140 cm L-shaped desk features integrated drawers and a file cabinet, offering ample storage and a versatile workspace. Please read this manual carefully before beginning assembly and retain it for future reference.



Image: The Coleshome L Shaped Desk, white, set up in a home office environment, showcasing its spacious design and integrated storage.

Setup and Assembly

Before assembly, ensure all parts are present and undamaged. It is recommended to assemble the desk on a soft, clean surface to prevent scratches. Two people are recommended for assembly.

Package Contents:

- Desk panels (main tabletop, side tabletop, drawer panels, cabinet panels)
- Metal frame components
- Drawer slides and handles
- File cabinet rails
- Assembly hardware (screws, bolts, nuts, Allen wrench)
- Power outlet unit (pre-installed or separate)

Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and compare them with the parts list provided in your packaging.
2. **Assemble the Main Desk Frame:** Attach the metal legs and support beams to the main tabletop panel using the provided hardware. Ensure all connections are secure.
3. **Assemble the Drawer Unit:** Construct the drawer cabinet frame. Install the drawer slides onto the cabinet frame

and the sides of the drawers. Insert the drawers into the cabinet.

4. **Assemble the File Cabinet Unit:** Construct the file cabinet frame. Install the file hanging rails if applicable.
5. **Connect Desk Sections:** Attach the L-shaped extension to the main desk. The desk is reversible, allowing the drawer and file cabinet unit to be placed on either the left or right side according to your preference. Refer to the diagram for reversible configuration options.
6. **Install Power Outlets:** If the power outlet unit is separate, carefully install it into the designated cutout on the desk surface. Connect the power cable.
7. **Attach Handles:** Securely attach all drawer and cabinet handles.
8. **Final Check:** Ensure all screws are tightened and the desk is stable.




Image: Detailed product dimensions and a visual representation of the reversible design, illustrating how the desk can be configured with the storage unit on either side.

Operating Instructions

Using the Storage Drawers:

The desk includes multiple drawers for organizing office supplies and personal items. The fabric storage drawers are designed for smooth operation. Pull the handles gently to open and push to close. Avoid overloading drawers to ensure smooth functionality and prevent damage.



Image: A detailed view of the four-tier fabric storage drawers, highlighting their smooth sliding mechanism and capacity for various items.

Using the File Cabinet:

The integrated file cabinet is designed to accommodate letter and A4 size hanging files. Place your files on the designated rails within the drawer. Ensure files are evenly distributed to prevent tipping.



Image: A composite image illustrating the desk's versatile storage options, featuring an open storage shelf and a spacious file drawer capable of holding letter and A4 size documents.

Power Outlets for Charging:

The desk is equipped with built-in power outlets for convenient charging of electronic devices. It includes 2 AC outlets (110-240V) and 2 USB ports (5V/2A). Plug your devices directly into these outlets. Always ensure the desk's main power cable is securely connected to a wall outlet.



Image: A detailed view of the desk's integrated power strip, featuring two AC power outlets and two USB charging ports for electronic devices.

Maintenance

Cleaning:

- For general cleaning, wipe the desk surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- Promptly wipe up spills to prevent staining.

Care:

- Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- Avoid placing extremely hot or cold items directly on the desk surface without protective coasters.
- Do not stand or sit on the desk.
- Keep the desk away from direct sunlight and excessive moisture to prevent warping or discoloration.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Desk is wobbly.	Loose screws or uneven floor.	Check and tighten all assembly screws. Adjust leveling feet if present, or place shims under legs on uneven floors.
Drawers do not slide smoothly.	Overloaded drawers, misaligned slides, or debris.	Reduce drawer contents. Check if slides are properly aligned and free of obstructions. Ensure drawers are inserted correctly.
Power outlets not working.	Desk power cable not connected, or wall outlet issue.	Ensure the desk's power cable is securely plugged into a functional wall outlet. Test the wall outlet with another device.
Missing parts during assembly.	Packaging error.	Contact Coleshome customer support with your purchase details and a list of missing parts.

Specifications

- **Brand:** Coleshome
- **Shape:** L-Shape
- **Product dimensions:** 50D x 140W x 75H centimeters
- **Colour:** White
- **Style:** Modern
- **Special features:** Reversible
- **Number of drawers:** 5 (Includes fabric storage drawers and file cabinet drawers)
- **Recommended uses for product:** Home Office, Gaming
- **Item weight:** 18.55 Kilograms
- **Size:** 140cm
- **Power Outlets:** 2 AC (110-240V), 2 USB (5V/2A)

Warranty and Support

For warranty information, missing parts, or technical support, please refer to the contact information provided in your product packaging or visit the official Coleshome website. Please have your purchase receipt and product model number ready when contacting support.

© 2026 Coleshome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DGXXMC8P

More documents and user manuals: **https://manuals.plus/**