**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**KARDV P10**

# KARDV Cordless Vacuum Cleaner P10 User Manual

Model: P10

## 1. Important Safety Instructions

Please read all instructions carefully before using your KARDV P10 Cordless Vacuum Cleaner. Retain this manual for future reference.

- This appliance is for **indoor use only**. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.
- Turn off the appliance before connecting or disconnecting the battery pack, accessories, or performing any maintenance.
- Use only the charger supplied by the manufacturer to recharge.
- Store the appliance indoors in a cool, dry place.

## 2. Product Overview

The KARDV P10 Cordless Vacuum Cleaner is designed for versatile and efficient cleaning across various surfaces. It features a powerful 350W brushless motor and a 5-stage fully sealed cyclone filtration system.

### Key Features:

- **Powerful Suction:** Up to 36KPa in MAX mode for deep cleaning.
- **Long Runtime:** Up to 40 minutes in standard mode with a high-performance detachable battery.
- **Quick Charge:** Fully charges in approximately 4 hours.
- **Flexible LED Floor Brush:** Illuminates dark areas and maneuvers easily.

- **Multifunctional Accessories:** Adapts for floors, curtains, furniture, and car interiors.
- **Large Dust Cup:** 1L capacity for less frequent emptying, with one-click release.
- **High-Efficiency Filtration:** 5-stage system captures 99.99% of fine dust.

### Included Components:

- Cordless Vacuum Cleaner Mainframe
- Floor brush & Roller
- Telescopic Tube
- 2-in-1 Brush
- Long Crevice Nozzle
- Cleaning Tool
- Wall Mount Bracket
- Battery
- Recharger
- Instruction Manual




Figure 2.1: All components included with the KARDV P10 Cordless Vacuum Cleaner.

## 3. Setup

### 3.1 Assembly

1. Attach the telescopic tube to the main vacuum cleaner body until it clicks securely into place.
2. Connect the desired cleaning head (e.g., floor brush) to the other end of the telescopic tube, ensuring it locks.
3. For handheld use, attach accessories directly to the main body.



Figure 3.1: The KARDV P10 Cordless Vacuum Cleaner shown in its assembled stick form and as a handheld unit with various attachments.

## 3.2 Charging the Battery

The KARDV P10 features a detachable battery for convenient charging. Ensure the battery is fully charged before first use.

1. To detach the battery, press the release button and slide the battery pack out.
2. Connect the recharger to the battery pack or directly to the vacuum cleaner if the battery is attached.
3. Plug the recharger into a power outlet. The battery indicator lights will show charging status.
4. A full charge takes approximately 4 hours.




Figure 3.2: The detachable battery of the KARDV P10, highlighting its 2500mAh capacity, 25-40 minutes runtime, and 4-hour quick charge.

## 4. Operating Instructions

### 4.1 Power On/Off and Suction Modes

- Press the power button on the main unit to turn the vacuum cleaner on or off.
- Toggle between the two suction modes (Standard and MAX) using the mode selection button. Standard mode provides longer runtime, while MAX mode offers powerful 36KPa suction for stubborn dirt.

### 4.2 Cleaning Different Surfaces

The KARDV P10 is suitable for all floor types, including hardwood, tile, and carpet.

- **Hard Floors:** Use the standard suction mode for everyday dust and debris. The LED floor brush illuminates hidden particles.
- **Carpets:** Switch to MAX suction mode for deeper cleaning of carpets and rugs. The 2-in-1 floor & carpet brush is designed for effective agitation.

- **Upholstery & Curtains:** Use the 2-in-1 brush or long crevice nozzle for delicate surfaces and tight spaces.
- **Car Interiors:** The handheld configuration with the crevice tool is ideal for cleaning car seats, floor mats, and tight corners.




Figure 4.1: Demonstrating the powerful 36KPa suction of the KARDV P10 on a carpet, effectively removing dust, pet hair, debris, and pet food.




Figure 4.2: The flexible LED floor brush head, capable of 180° left/right and 90° up/down movement, with integrated LED headlights to reveal hidden dust.




Figure 4.3: The KARDV P10 used with different attachments for cleaning curtains, sofas, corners, and car interiors, showcasing its versatility.

### 4.3 Official Product Video: Functionality Overview

Your browser does not support the video tag.

Video 4.1: An overview of the KARDV P10 Cordless Vacuum Cleaner's functionality, demonstrating its features and ease of use for various cleaning tasks.

## 5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your KARDV P10 vacuum cleaner.

### 5.1 Emptying the Dust Cup

- The 1L dust cup can be emptied with a single click. Position the dust cup over a trash bin and press the release button.

### 5.2 Cleaning the Filters

The 5-stage filtration system includes washable filters. Regular cleaning is recommended.

- Remove the dust cup and separate the filters.
- Wash the filters under running water until clean.
- Allow filters to air dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters.

## 5.3 Cleaning the Roller Brush

The roller brush may accumulate hair and debris. Use the provided cleaning tool to remove tangled hair.

- Detach the floor brush from the telescopic tube.
- Open the brush cover and remove the roller brush.
- Use the hook end of the cleaning tool to cut and remove tangled hair from the roller.
- Reassemble the roller brush and cover.




Figure 5.1: Instructions for one-click dust cup emptying and washing the reusable filter components of the KARDV P10.




Figure 5.2: Detailed diagram illustrating the 5-stage high-efficiency filtration system, including the Cyclone Filter, Metal Dust Filter, Multi-cone Cyclonic Filter, Pre-Filter, and H10 HEPA filter.

## 6. Troubleshooting

If you encounter issues with your KARDV P10, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Vacuum does not turn on. | Battery is not charged or not properly installed. | Ensure battery is fully charged and securely clicked into place. |
| Low suction power. | Dust cup is full, filters are clogged, or attachments are blocked. | Empty dust cup, clean/wash filters, check for blockages in the tube or brush head. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Battery not charging. | Charger not connected properly or faulty charger/battery. | Ensure charger is securely connected to both the battery/vacuum and the power outlet. Try a different outlet. If problem persists, contact customer support. |
| Brush roll not spinning. | Hair or debris tangled in the brush roll. | Turn off the vacuum, remove the brush roll, and clear any obstructions using the cleaning tool. |

## 7. Specifications

| Feature | Detail |
|---|---|
| Brand | KARDV |
| Model Name | P10 |
| Suction Power | Up to 36KPa (MAX mode) |
| Motor | 350W Brushless Motor |
| Runtime | Max 40 minutes (Standard mode) |
| Charge Time | Approx. 4 hours |
| Dust Cup Capacity | 1L |
| Filtration System | 5-Stage Fully Sealed Cyclone Filtration (HEPA Filter) |
| Special Features | 2 Suction Modes, Flexible LED Floor Brushes, Multifunctional Accessories, Detachable Battery |
| Recommended Uses | All floors, upholstery, stairs, car interiors |
| Item Weight | 5 pounds |
| Product Dimensions | 7"L x 7"W x 47"H |
| Battery Type | 1 Lithium Ion battery (included) |

## 8. Warranty & Support

For warranty information, product registration, or technical support, please refer to the contact information provided on the product packaging or visit the official KARDV website. Keep your purchase receipt as proof of purchase.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0DGYQ4FSN**

More documents and user manuals: **https://manuals.plus/**