

[Manuals.plus](#) /

› [Best Choice Products](#) /

› Best Choice Products Kids 12V Electric Ride On UTV Car and Trailer Instruction Manual

Best Choice Products SKY8029

Best Choice Products Kids 12V Electric Ride On UTV Car and Trailer Instruction Manual

Model: SKY8029

SAFETY INFORMATION

To reduce the risk of injury, adult supervision is required. Never use on roadways, near motor vehicles, on or near steep inclines or steps, swimming pools or other bodies of water. Always wear shoes, and never allow more than one rider.



Choose High or Low Speed

Image: A child is shown securely fastened in the UTV seat with the adjustable safety harness, highlighting the child-friendly design for safety during operation.

PACKAGE CONTENTS

- 1x Kids 12V Electric Ride On UTV Car
- 1x Detachable Trailer
- 1x Parental Remote Control
- 1x Assembly Guide
- 1x Charger (not explicitly listed but implied for 12V electric ride-on)

ASSEMBLY

Assembly of the UTV and trailer is required. Please refer to the included Assembly Guide for detailed, step-by-step instructions. Ensure all components are securely fastened before use.

Child-Friendly Design



Image: A child stands beside the assembled UTV and its detachable trailer, providing a visual reference for the product's scale and components after assembly.

CHARGING THE BATTERY

Before first use, fully charge the 12V rechargeable battery. A full charge provides up to 60 minutes of continuous run time. Always use the provided charger and follow the instructions in the Assembly Guide for proper charging procedures. Do not overcharge the battery.

OPERATING INSTRUCTIONS

Driving the UTV

The UTV is operated by a foot pedal for acceleration and a steering wheel for direction. Ensure the child is seated correctly and secured with the seat harness before starting. The UTV features two driving speeds (high and low) to accommodate different skill levels.

Speed Selection

Use the speed selection button on the dashboard to switch between high and low speeds. Start with the low speed setting for new users to ensure familiarity and control.



Image: A close-up of a hand interacting with the UTV's dashboard, specifically pressing a button to select between high and low driving speeds.

Music Connectivity

The UTV includes a built-in Bluetooth sound system. Pair a compatible device to play music through the UTV's speakers. Refer to the Assembly Guide for detailed pairing instructions.

Perfectly Sized

3-5

Age
Limit

66lb

Weight
Limit



Image: A child is seated in the UTV, while a hand holds a smartphone displaying a music player interface, illustrating the Bluetooth music pairing feature.

PARENTAL REMOTE CONTROL

An included parental remote control allows an adult to operate the UTV, providing an override function for safety and assistance. This feature is particularly useful for younger children who are still learning to drive independently.

Connect. Play. DRIVE!



Bluetooth music pairing

Image: An adult holds the remote control, demonstrating the parental override feature, while a child is visible driving the UTV in the background.

PRODUCT FEATURES OVERVIEW

Your browser does not support the video tag.

Video: An overview of the 12 Volt UTV Ride-On Toy with Trailer, showcasing its key features and functionality.

Detachable Trailer

The UTV is equipped with a detachable trailer, allowing children to transport toys and other small items. The trailer connects and disconnects easily.



Image: The detachable trailer is shown attached to the UTV, loaded with a teddy bear, ball, and other toys, demonstrating its hauling capability.

Durable Wheels and LED Lights

The UTV features treaded plastic wheels designed for various terrains. Bright LED headlights enhance visibility and add to the realistic appearance.



Image: A detailed view of the UTV's robust, treaded plastic wheel, indicating its design for varied outdoor use.

MAINTENANCE

Regularly inspect the UTV for loose parts, damaged wiring, or worn components. Clean the vehicle with a damp cloth and mild soap. Do not use harsh chemicals. Store the UTV in a dry, covered area when not in use to protect it from weather elements. Ensure the battery is charged periodically during storage to maintain its lifespan.

TROUBLESHOOTING

If the UTV does not operate, check the battery charge level and ensure all electrical connections are secure. If the remote control is not functioning, verify its batteries and ensure it is properly paired with the UTV. For persistent issues, consult the detailed troubleshooting section in the Assembly Guide or contact customer support.

SPECIFICATIONS

Feature	Detail
Brand Name	Best Choice Products
Model Number	SKY8029

Manufacturer Minimum Age	36 Months
Manufacturer Maximum Age	72 Months
Weight Capacity Maximum	66 Pounds
Item Weight	39.3 Pounds
Item Dimensions (L x W x H)	61.5" x 26" x 27" (with Trailer)
Material Type	Polypropylene
Power Source	12V Electric Motor
Speeds	2 (High/Low)
Features	Detachable Trailer, Parental Remote Control, LED Headlights, Bluetooth Sound System

WARRANTY AND SUPPORT

This product comes with a 60-day warranty. All returns are shipped back to a Best Choice Products Return Center at the customer's expense within 60 days of delivery. However, a pre-paid return shipping label will be sent via email if the return is a result of our error. It is at the company's discretion to decide if the item may be returned to a Best Choice Products Return Center. Unauthorized returns may not be accepted. Once your claim is processed and approved, please allow 5-7 business days for the request to be completed. If a replacement unit or replacement parts are requested, the fulfillment time-frame is based on product availability.

For further assistance or to initiate a warranty claim, please contact Best Choice Products customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DGZHF56B>

More documents and user manuals: <https://manuals.plus/>