

## **COMFIER CF-5310-EU**

# **COMFIER Shiatsu Foot Massager with Heat (Model CF-5310-EU) User Manual**

Your guide to operating and maintaining your COMFIER Foot Massager.

## **1. INTRODUCTION**

Thank you for choosing the COMFIER Shiatsu Foot Massager. This device is designed to provide a comprehensive foot massage experience, combining kneading, shiatsu, vibration, and air compression with soothing heat. This manual provides essential information for safe and effective use of your foot massager.



Image 1.1: The COMFIER Shiatsu Foot Massager with its remote control.



Image 1.2: The foot massager is suitable for use after exercise, after standing all day, or for relieving discomfort from conditions like arthritis or plantar fasciitis.

## 2. SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in injury or damage to the product.

- Users must follow the instructions in the manual to prevent injury.
- Ensure correct intensity and duration settings for heat and massage.
- Avoid using the massager if you have a high fever, blood clots, or other serious health conditions. Consult a physician if you have any medical concerns.
- Switch off the massager when not in use and store it in a dry, safe place.
- Do not use the massager near water or electrical outlets to prevent risks of electrical damage.
- Keep out of reach of children.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support for assistance.

### 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Foot Massager Machine
- UL Home Adapter
- User Manual
- Remote Controller

## Package Includes:

- Foot Massager Machine
- UL Home Adapter
- User Manual
- Remote Controller



Image 3.1: Visual representation of the items included in the package and the product's dimensions.

### 4. PRODUCT FEATURES

The COMFIER Shiatsu Foot Massager offers a range of features designed for optimal foot relaxation and relief:

#### 4.1. Two Control Methods

Operate the massager conveniently using either the included remote control or the integrated touch panel. The remote control eliminates the need to bend down, making it accessible for users with back issues or mobility challenges. The touch panel provides a modern and elegant interface.

#### 4.2. Enhanced Functions

The massager includes a new pause function, which retains the remaining massage time and seamlessly resumes without resetting the 15-minute timer. A sleep mode mutes prompts during mode settings, ensuring a quiet massage experience without disturbance.

#### 4.3. Professional Foot Care

Experience a comprehensive foot care regimen with a blend of kneading, shiatsu, vibration, compression, and heat functions. Rotating wheels knead the soles, shiatsu targets the heels, vibration soothes the arch, and air compression massages the ankles and top of the feet for deep relaxation.



Image 4.1: Detailed view of the various massage techniques: vibration, kneading, and shiatsu, combined with air compression.

#### 4.4. Personalized Settings

Customize your massage experience with adjustable kneading, compression, vibration, and heat functions, each offering three intensity levels (low/medium/high). The default timer setting is 15 minutes.



Image 4.2: The massager provides three levels of soothing heat, ranging from 104°F to 140°F (40°C to 60°C).

## 5. SETUP

- 1. Unpack:** Carefully remove the foot massager and all accessories from the packaging.
- 2. Placement:** Place the massager on a flat, stable surface. Ensure there is enough space around the unit for proper ventilation.
- 3. Connect Power:** Plug the UL Home Adapter into the power port on the massager, then plug the adapter into a suitable electrical outlet.
- 4. Initial Check:** Before first use, ensure the foot sleeves are properly inserted and secured.

## 6. OPERATING INSTRUCTIONS

The COMFIER Foot Massager can be operated via its touch panel or the remote control.

### 6.1. Getting Started

- 1. Insert Feet:** Sit comfortably and place your feet into the foot openings. The massager accommodates foot sizes up to EUR 46.
- 2. Power On:** Press the **Power** button on the touch panel or remote control to turn on the device.

## 6.2. Using the Touch Panel and Remote Control



Image 6.1: The foot massager can be controlled using either the integrated touch panel or the wireless remote control.

# Customizable Settings




Image 6.2: Overview of the customizable settings available on the foot massager.

- **Knead (Kneden):** Adjust the intensity of the kneading massage (L/M/H).
- **Air (Luchtcompressie):** Control the air compression intensity (L/M/H).
- **Vibration (Trilling):** Select the vibration frequency (L/M/H).
- **Heat (Warmte):** Turn the heat function on/off and adjust its intensity (L/M/H).
- **Pause:** Press the pause button to temporarily stop the massage while retaining the remaining time. Press again to resume.
- **Mute:** Activate sleep mode to mute operational sounds for a quieter experience.
- **Timer:** The massager has a default 15-minute auto shut-off timer.

## 6.3. Power Off

Press the **Power** button again to turn off the massager. The device will also automatically shut off after 15 minutes of continuous use.

## 7. MAINTENANCE

Proper maintenance ensures the longevity and hygiene of your foot massager.

## 7.1. Cleaning

- **Foot Sleeves:** The foot sleeves are removable and washable. Unzip and remove them for cleaning. Hand wash or machine wash on a gentle cycle with mild detergent. Air dry completely before reattaching.
- **Exterior:** Wipe the exterior of the massager with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.



Image 7.1: The foot massager features removable and washable foot sleeves made from waterproof material for easy cleaning and hygiene.

## 7.2. Storage

When not in use, store the massager in a cool, dry place, away from direct sunlight and moisture. Ensure the power cord is neatly coiled and not kinked.

## 8. TROUBLESHOOTING

If you encounter any issues with your COMFIER Foot Massager, please refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Massager does not turn on.	Power cord not properly connected. No power from outlet.	Ensure the power adapter is securely plugged into both the massager and a working electrical outlet. Test the outlet with another device.
Massage intensity feels too weak or too strong.	Incorrect intensity setting.	Adjust the kneading, air compression, or vibration intensity using the control panel or remote control (L/M/H).
Heat function is not working.	Heat function is off or set to low.	Ensure the heat function is activated and set to a desired intensity level (L/M/H). Allow a few minutes for the heat to build up.
Unusual noise during operation.	Obstruction in the massage mechanism.	Turn off the massager and unplug it. Check for any foreign objects inside the foot openings. If the noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact COMFIER customer support.

## 9. SPECIFICATIONS

Specification	Detail
Brand	COMFIER
Model Name	CF-5310-EU
Item Model Number	CF-5310-EU
Product Dimensions	18.7L x 40.5W x 34.5H centimeters (7.36 x 15.94 x 13.58 inches)
Weight	3.12 kg (6.88 lbs)
Power Source	Battery (Adapter included)
Material	Plastic
Color	Black
Massage Type	Foot Massager (Kneading, Shiatsu, Vibration, Air Compression, Heat)
Max Foot Size	EUR 46
Product Benefits	Muscle therapy, pain relief
Wireless?	Yes (Remote Control)
Country of Origin	China
First Available Date	January 5, 2025

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official COMFIER website. You may also contact COMFIER customer service directly for

assistance with any product-related inquiries.

## Related Documents - CF-5310-EU

 <b>CONFIER</b> FUSSMASSEGERAT DE FOOT MASSAGER FR MASSAJEADOR DE PIES ES MASSAGGIATORE PIEDI IT MASAJEADOR DE PIÉS PT  <b>CE</b> User Manual CF-5913	<p><a href="#"><u>Comfier CF-5913 Shiatsu Foot Massager User Manual</u></a></p> <p>User manual for the Comfier CF-5913 Shiatsu Foot Massager Machine. Learn how to use this kneading foot massager with heat for pain relief, plantar fasciitis, and general relaxation. Includes operation, safety, maintenance, and warranty details.</p>
 <b>CONFIER</b> Leg and Foot Massager  <b>CE</b> User Manual CF-425H	<p><a href="#"><u>Comfier CF-F25H Leg and Foot Massager User Manual</u></a></p> <p>Comprehensive user manual for the Comfier CF-F25H Leg and Foot Massager, detailing safety instructions, product features, setup and operation, maintenance, troubleshooting, warranty information, and FCC compliance.</p>
 <b>CONFIER</b> Deep-Kneading Shiatsu Neck & Shoulder Massager  <b>CE</b> User Manual CF-6701	<p><a href="#"><u>Comfier CF-6701 Deep-Kneading Shiatsu Neck &amp; Shoulder Massager User Manual</u></a></p> <p>User manual for the Comfier CF-6701 Deep-Kneading Shiatsu Neck &amp; Shoulder Massager, covering product features, technical data, setup, operation, safety instructions, care, troubleshooting, and warranty information.</p>
 <b>CONFIER</b> Shiatsu Neck and Back Massager with Heat  <b>CE</b> User Manual CF-2303-KR	<p><a href="#"><u>COMFIER CF-2303-KR Shiatsu Neck and Back Massager with Heat User Manual</u></a></p> <p>Comprehensive user manual for the COMFIER CF-2303-KR Shiatsu Neck and Back Massager with Heat, covering safety instructions, features, technical data, setup, operation, controller functions, care, cleaning, troubleshooting, and warranty information.</p>
 <b>CONFIER</b> Shiatsu Nacken und Schulter Massagegerät mit Wärme DE Nacken- & Schulter-Massagegerät mit Wärme FR masseur chaleur pour cou et les épaules FR masajeador shiatsu para cuello y espalda con calor IT massaggiatore shiatsu per collo e spalle con calore PT massajeador de cuello y hombro shiatsu con calor ES  <b>CE</b> User Manual CF-6302	<p><a href="#"><u>COMFIER CF-6302 Shiatsu Nacken- und Schultermassagegerät mit Wärmefunktion – Bedienungsanleitung</u></a></p> <p>Entdecken Sie die COMFIER CF-6302 Bedienungsanleitung für das Shiatsu Nacken- und Schultermassagegerät mit Wärmefunktion. Erfahren Sie mehr über die Funktionen, Anwendung und Pflege dieses entspannenden Massagegeräts für Nacken und Schultern.</p>

1 Sicherheitshinweise

 **WICHTIGE HINWEISE !**

**UNBEDINGT AUFBEWAHREN !**

Lesen Sie die Bedienungsanleitung, indem Sie die Sicherheitshinweise, vor dem ersten Betrieb des Geräts, sorgfältig durchlesen. Diese Sicherheitshinweise sind wichtig für die sichere Nutzung a.d. Werkzeug des Geräts an Ort und Stelle.

grüne Farbe bedeutet: Wichtiges Sicherheitshinweis

**Zulassungserklärung**

 Diese Gebrauchsanleitung gehört zu diesem Gerät.

Sie enthält wichtige Informationen zur Inbetriebnahme und zum Betrieb des Geräts.

Die Gebrauchsanleitung ist für die korrekte Anwendung kein in diesem Verhältnis oder

zusammen mit dem Gerät zu verwenden.

**WARNING**

These Hinweise müssen eingehalten werden, um mögliche Verstüppungen des Betriebs zu verhindern.

**ACHTUNG**

These Hinweise müssen eingehalten werden, um mögliche Beschädigungen am Gerät zu verhindern.

 **HINWEIS**

These Hinweise geben Ihnen zusätzliche Zusatz-

Informationen zur Installation oder zum Betrieb.

 **Schulungshinweis**

**LOT**

Lot-Nr.

Hersteller

1

## [COMFIER FE-7204B Compression Leg Massager User Manual and Safety Guide](#)

Comprehensive user manual and safety guide for the COMFIER FE-7204B Compression Leg Massager, covering features, operation, maintenance, troubleshooting, and warranty information.