

MAXYOYO Adjustable Floor Sofa Couch

MAXYOYO Adjustable Floor Sofa Couch Instruction Manual

Model: Adjustable Floor Sofa Couch

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your MAXYOYO Adjustable Floor Sofa Couch. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

SAFETY INFORMATION

- Ensure all components are securely assembled before use.
- Do not exceed the recommended weight capacity (not specified, general advice).
- Keep away from open flames and heat sources.
- Avoid sharp objects that could damage the fabric.
- Supervise children when using the sofa bed, especially during adjustment.

PACKAGE CONTENTS

Your MAXYOYO Adjustable Floor Sofa Couch package includes the following items:

- 1 x Adjustable Floor Sofa Couch
- 2 x Coordinating Pillows
- Instruction Manual (this document)

Note: The sofa bed is compressed and vacuum-sealed for shipping efficiency. It requires time to expand to its

SETUP INSTRUCTIONS

1. **Step 1: Unpacking.** Carefully open the package and remove the vacuum-sealed sofa bed.

The Core of MAXYOYO

At the core of our brand is 'Versatility'. Our products offer a wide range of options, from diverse styles of floor mattresses, versatile sofas, to cozy bean bag beds.



Figure 1: Vacuum-sealed sofa bed upon unpacking.

2. **Step 2: Unfold and Install Frame.** Unfold the product and install any necessary frame components.

Simple Steps Before Use

1 Move box to the desired room	2 Remove the product
	
3 Remove compressed packaging	4 Wait 48 hours for recovery
	

Figure 2: Sofa bed after initial unfolding and frame installation.

3. **Step 3: Allow for Expansion.** Position the sofa bed in its desired location and allow it to breathe and expand for a minimum of **48 hours** to regain its original shape and size. Gentle tapping and fluffing can assist in the expansion process.

Service for You

We prioritize consumer experience and sustainable development, providing reliable and trustworthy products




Figure 3: Sofa bed fully expanded after 48 hours.

OPERATING INSTRUCTIONS

5-Position Adjustment

The MAXYOYO Floor Sofa Couch features a 5-position adjustable backrest, allowing you to customize your seating or lounging experience. To adjust the backrest:

1. **To Recline:** Gently push the backrest forward past 90 degrees until you hear a click. Then, slowly lower it to your desired reclining position.
2. **To Lay Flat:** Continue pushing the backrest forward past 90 degrees until it clicks into the fully flat position.
3. **To Raise:** From a flat or reclined position, lift the backrest upwards. It will click into place at each of the five preset angles.


Adjustable Floor Sofa Bed

▶▶▶ Multifunctional & Universal Use

Cozy Sofa



Recliner



Lounger



Floor Bed



Figure 4: Backrest adjustment mechanism.

SHREDDED FOAM FILLING



Shredded Foam Filling



High-Density Base Support Foam



Convenient Lying Down



Fine Workmanship



High Quality Fabric

Figure 5: Versatile configurations of the sofa bed.

Integrated Side Pockets

The sofa bed includes convenient side pockets for storing small items such as remote controls, magazines, or personal devices.

Rebound Time



Figure 6: Detail of side pockets and velvet fabric.

CARE AND MAINTENANCE

- **Cleaning:** For minor spills, gently blot with a clean, damp cloth. For deeper cleaning, use a mild upholstery cleaner suitable for velvet fabrics. Test on an inconspicuous area first.
- **Vacuuming:** Regularly vacuum the sofa with an upholstery attachment to remove dust and debris.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading of the fabric.
- **Fluffing:** Periodically fluff the pillows and cushions to maintain their shape and comfort.

TROUBLESHOOTING

Issue: Sofa does not appear to be full size or is still compressed.

Solution: The sofa is vacuum-sealed for shipping. It requires up to 48 hours to fully expand after unpacking. Ensure it is unfolded and in a well-ventilated area during this time. Gentle tapping and fluffing can aid the process.

Issue: Difficulty adjusting the backrest.

Solution: Ensure you are pushing the backrest forward past the 90-degree mark to engage the adjustment

mechanism before lowering it to a reclined or flat position. If raising, lift until it clicks into the desired angle.

SPECIFICATIONS

Brand	MAXYOYO
Model	Adjustable Floor Sofa Couch
Product Dimensions (D x W x H)	77"D x 54"W x 4.3"H (when flat)
Color	Dark Grey
Frame Material	Metal
Fill Material	Chipped Foam, High Density Foam
Fabric Type	Velvet
Seating Capacity	2
Reclining Positions	5
Assembly Required	Yes (minimal, primarily unfolding and expansion)

Product Size



Figure 7: Product dimensions.

WARRANTY AND SUPPORT

MAXYOYO provides customer support for any issues or questions you may have regarding your product. For specific warranty details or assistance, please refer to the purchase documentation or contact MAXYOYO customer service directly.

For further assistance, please visit the official MAXYOYO store or contact their customer support channels.