



[Manuals.plus](#) /

› [InnaMall](#) /

› InnaMall Portable Countertop Dishwasher User Manual

InnaMall HG-1244-QXF

InnaMall Portable Countertop Dishwasher User Manual

Model: HG-1244-QXF

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your InnaMall Portable Countertop Dishwasher. Please read it thoroughly before first use and keep it for future reference.

The InnaMall Portable Countertop Dishwasher is designed for compact living spaces such as small houses, apartments, dorms, RVs, and boats. It offers convenient dishwashing capabilities for various items including bowls, plates, and cutlery.



Figure 1: Front view of the InnaMall Portable Countertop Dishwasher, showing the control panel and viewing window.

SETUP AND INSTALLATION

Your dishwasher offers flexible installation options to suit your space.

Placement

Place the dishwasher on a stable, level countertop or sturdy table. Ensure there is adequate space around the unit for ventilation and access to water connections.

Water Connection

The dishwasher supports both desktop and embedded installation methods. It features an automatic water filling system after initial setup.

- **Inlet Pipe:** Connect the provided inlet pipe to a water source.
- **Drainage Pipe:** Connect the drainage pipe to a suitable drain.



Intimate handle

Easy to open and close,
easy to take



Lumen structure

High pressure washing,
safe and durable



Removable and washable filter

Efficient filtration, easy to
remove and wash



Water inlet and outlet

Easy to install

Figure 2: Illustration of desktop and embedded installation methods for the dishwasher.

Intelligent washing, oil stain sensing

Intelligently judge the degree of soiling of tableware and automatically match the washing mode




Figure 3: Close-up view of the water inlet and outlet connections on the dishwasher.

OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and washing programs for optimal performance.

Control Panel

The dishwasher features an LED display and touch controls for easy operation.

Washing Programs

Select from three available washing programs:

- **Standard:** For everyday dishware with normal soil levels.
- **Fast:** A quicker cycle for lightly soiled items.
- **Strong:** For heavily soiled dishes requiring intensive cleaning.

The 360° dual spray system ensures thorough cleaning, reaching all areas of the dishes.

Intelligent Washing

The dishwasher is equipped with intelligent oil stain sensing, which automatically assesses the degree of soiling and selects the most appropriate washing mode.



Figure 4: Diagram illustrating the intelligent oil stain sensing and automatic program matching feature.

Drying and Sterilization

After washing, the dishwasher utilizes high-temperature steam (75°C) for physical condensation drying and sterilization, which helps reduce mold and odor growth.

Waste Heat Drying Is More Energy-efficient

Use the high-temperature steam of the inner tank to promote physical condensation and drying, and reduce the growth of mold and odor in the machine



Figure 5: Illustration of the 75°C waste heat drying process for energy efficiency.




Figure 6: Visual representation of high temperature disinfection and hot air drying within the dishwasher.

Desktop disinfection cabinet



Completely sealed



75°C drying and sterilization

Traditional storage tableware



The dish rack is exposed to the air and easily dirty



The inside of the drain box is damp and easy to mold

Figure 7: Overview of the dishwasher's complete cycle: super fast wash, sterilization, strengthened air drying, and ventilation storage.

MAINTENANCE

Regular maintenance ensures the longevity and efficiency of your dishwasher.

Cleaning the Filter

The dishwasher is equipped with a removable and washable filter for efficient filtration. Regularly remove and clean the filter to prevent blockages and maintain washing performance.

- Locate the filter at the bottom of the wash tub.
- Twist or unclip the filter to remove it.
- Rinse the filter under running water to remove food particles. Use a brush if necessary.
- Reinstall the filter securely after cleaning.

General Cleaning

Wipe down the exterior of the dishwasher with a soft, damp cloth. For the interior, run a cleaning cycle with a dishwasher cleaner periodically.

TROUBLESHOOTING

This section addresses common issues you might encounter. For problems not listed here, please contact customer support.

- **Dishwasher not starting:** Ensure the power cord is securely plugged in and the door is fully closed. The safety magnetic induction door seal ensures a tight and secure cleaning process.
- **Water leakage:** Check that the inlet and drainage pipes are properly connected and secured. Ensure the door is closed completely.
- **Dishes not clean:** Verify that the filter is clean and not clogged. Ensure dishes are loaded correctly, not blocking the spray arms. Select the appropriate wash program for the soil level.
- **Unusual noises:** Check for any foreign objects inside the dishwasher that might be interfering with the spray arms or pump.

SPECIFICATIONS

Detailed technical specifications for your InnaMall Portable Countertop Dishwasher.

Feature	Specification
Model Name	Portable Countertop Dishwasher
Model Number	HG-1244-QXF
Dimensions (D x W x H)	15.74" x 17.71" x 15.74" (40 x 45 x 44 cm)
Net Weight	16.53 lbs (9.5 kg)
Rated Voltage	110V
Rated Frequency	50Hz
Rated Power	1200W
Water Consumption	8L (1.32 Gallons)
Control Type	Microcomputer / Touch
Washing Programs	Standard, Fast, Strong (3 cycles)
Material	PP, ABS, Stainless Steel (Rack/Basket)
Noise Level	55 dB
Capacity	Approx. 6 sets of dishes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the InnaMall official website.

Included Components:

- 1 x Countertop Dishwasher
- 1 x Inlet Pipe
- 1 x Drainage Pipe
- 1 x English User Manual