

[manuals.plus](#) /› [Proscenic](#) /› [Proscenic Q8 Robot Vacuum Cleaner with Mop User Manual](#)

Proscenic Q8

Proscenic Q8 Robot Vacuum Cleaner with Mop User Manual

1. INTRODUCTION

Thank you for choosing the Proscenic Q8 Robot Vacuum Cleaner with Mop. This device is designed to provide efficient and convenient floor cleaning by combining vacuuming and mopping functionalities. Equipped with advanced LiDAR navigation, powerful suction, and smart control options, the Q8 offers a comprehensive cleaning solution for various floor types and home environments. Please read this manual thoroughly before operating the device to ensure proper use, maintenance, and safety.

2. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate the robot in areas with open flames or fragile objects.
- Do not use the robot to pick up large debris, liquids, or burning objects.
- Ensure the charging base is placed on a level surface against a wall, with adequate clear space around it.
- Unplug the charging base from the outlet when not in use and before cleaning.
- Only use the manufacturer-specified charging adapter.
- Do not immerse the robot or charging base in water.
- Regularly clean the main brush, side brush, dustbin, and filters to maintain optimal performance.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Main Body (Proscenic Q8 Robot Vacuum Cleaner)
- Charging Base

- Charging Adapter
- Cleaning Brush
- HEPA Filter
- Mop Pad
- Side Brush
- User Manual

4. PRODUCT OVERVIEW

Robot Components



This image displays the Proscenic Q8 Robot Vacuum Cleaner from a top-down perspective, alongside its charging base and a detachable mopping module. The robot features a central LiDAR sensor for navigation, a power button, and a home button. The accompanying smartphone app interface is also shown, illustrating mapping and control functions.

- **LiDAR Navigation Sensor:** Located on top, used for 360° scanning and mapping.
- **Power/Clean Button:** Initiates or pauses cleaning, powers the robot on/off.
- **Home/Recharge Button:** Sends the robot back to its charging base.
- **Dustbin:** Collects dry debris during vacuuming.

- **Water Tank:** Holds water for mopping functionality.
- **Main Brush:** Central brush for deep cleaning carpets and hard floors.
- **Side Brush:** Sweeps debris from edges and corners towards the main brush.
- **Cliff Sensors:** Prevents the robot from falling down stairs.
- **Wall Sensors:** Helps the robot navigate along walls and avoid collisions.
- **Charging Contacts:** Connects with the charging base for power.

LiDAR Navigation System



This image illustrates the 360° LiDAR navigation system of the Proscenic Q8. The robot uses laser technology to precisely map its environment, enabling accurate positioning, efficient mapping, and optimal route planning to avoid obstacles day and night.

5. SETUP

5.1 Charging Base Placement

1. Place the charging base against a wall in an open, uncluttered area.
2. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides of the charging base and 1.5 meters (4.9 feet) in front of it.

3. Connect the power adapter to the charging base and plug it into a wall outlet.

5.2 Initial Charging

1. Place the robot onto the charging base, ensuring the charging contacts align.
2. Allow the robot to fully charge before its first use. A full charge typically takes 4-6 hours. The indicator light on the robot will change when fully charged.

5.3 App Download and Connection

1. Download the 'Proscenic' app from the App Store (iOS) or Google Play Store (Android).
2. Register an account and follow the in-app instructions to add your Q8 robot.
3. Ensure your smartphone is connected to a 2.4GHz Wi-Fi network during the pairing process. The robot does not support 5GHz Wi-Fi.

5.4 First Use and Mapping



This image illustrates the personalized cleaning capabilities of the Proscenic Q8, showcasing its ability to create and manage maps for up to 5 levels of a home. It depicts different rooms (Living Room, Kitchen, Bathroom, Study Room, Bedroom) with scheduled cleaning times and specific cleaning modes (vacuum, mop, or both) assigned to each, all controlled via the smartphone app.

1. For the first cleaning cycle, allow the robot to complete a full cleaning run without interruption. This

enables the LiDAR system to create an accurate map of your home.

2. The robot can store maps for up to 5 different levels or areas.

6. OPERATING INSTRUCTIONS

6.1 Starting and Stopping Cleaning

1. **Start Cleaning:** Press the Power/Clean button on the robot or use the 'Start' function in the Proscenic app.
2. **Pause Cleaning:** Press the Power/Clean button during operation.
3. **Stop Cleaning:** Press and hold the Power/Clean button for 3 seconds, or use the 'Stop' function in the app. The robot will return to its charging base.

6.2 Cleaning Modes



This image illustrates the versatility of the Proscenic Q8, highlighting its three primary cleaning modes: 'Vacuum & Mop' (with both dustbin and water tank attached), 'Mop Only' (with only the water tank/mop module), and 'Vacuum Only' (with only the dustbin). This allows the user to select the appropriate cleaning method for various floor types.

1. **Vacuum Only:** The robot will only vacuum. Ensure the dustbin is installed.

2. **Mop Only:** The robot will only mop. Attach the water tank with a damp mop pad.
3. **Vacuum & Mop:** The robot will perform both functions simultaneously. Ensure both the dustbin and water tank with mop pad are installed.

6.3 Suction Power and Water Flow Adjustment



This image visually represents the 6000Pa super powerful suction capability of the Proscenic Q8 Robot Vacuum Cleaner, showing debris being lifted from the floor. This high suction power is effective for cleaning various types of dirt.



This image highlights the 'Auto Boost Carpets Cleaning' feature of the Proscenic Q8. The robot automatically detects carpets and switches from Eco Mode to Max Mode to increase suction power for a deeper clean, as indicated by the visual representation of increased airflow and a close-up of the brush.


1. Adjust suction power (Eco, Standard, Max) and water flow levels (Low, Medium, High) via the Proscenic app to suit different floor types and cleaning needs.
2. The robot features an 'Auto Boost' function that automatically increases suction power when it detects carpeted surfaces.

6.4 Advanced Cleaning Features

1. **Scheduled Cleaning:** Set specific times for the robot to clean automatically using the app.
2. **No-Go Zones/Virtual Walls:** Define areas on the map where the robot should not enter or clean.
3. **Room-Specific Cleaning:** Select specific rooms or zones for cleaning via the app.
4. **Continuous Cleaning:** If the battery runs low during a cleaning cycle, the robot will automatically return to the charging base, recharge, and then resume cleaning from where it left off.

Continuous Cleaning After Breakpoints


When its battery is low, it automatically returns to the base to recharge and then resumes cleaning where it left off.



This image illustrates the 'Continuous Cleaning After Breakpoints' feature. When the robot's battery is low, it automatically returns to its charging base to recharge. Once sufficiently charged, it resumes cleaning from the exact spot it left off, ensuring complete coverage without manual intervention.


6.5 Matrix Clean

Matrix Clean No Spots Missed



MATRIX ROAD

Cleans in 2 Passes
Complete Ground Coverage: 98%




LINEAR ROAD

Cleans in 1 Pass
Cleaning Coverage: 60%

This image compares the 'Matrix Clean' pattern with a 'Linear Road' pattern. Matrix Clean involves cleaning in two passes, achieving 98% ground coverage, ensuring no spots are missed. In contrast, a Linear Road clean in one pass only achieves 60% coverage, highlighting the thoroughness of the Matrix Clean method.

The Q8 utilizes a 'Matrix Clean' pattern, performing two passes over an area to ensure comprehensive coverage and minimize missed spots.

6.6 Voice Control



This image shows a woman interacting with her Proscenic Q8 Robot Vacuum Cleaner using voice commands through a smartphone. The image highlights compatibility with various voice assistants, including Amazon Alexa, Google Assistant, Apple Siri, and IFTTT, allowing users to control the robot with simple spoken instructions.

The Proscenic Q8 can be controlled using voice commands through compatible smart home devices and platforms such as Amazon Alexa, Google Home, Siri, and IFTTT. Refer to the app for specific voice commands.

7. MAINTENANCE

Regular maintenance is crucial for optimal performance and longevity of your Proscenic Q8.

7.1 Dustbin Emptying

1. Empty the dustbin after each cleaning cycle or when the 'dustbin full' indicator appears in the app.
2. Open the robot's top cover, remove the dustbin, and discard collected debris.

7.2 Water Tank Refilling and Cleaning

1. Refill the water tank with clean water before each mopping session.
2. After mopping, empty any remaining water and clean the tank to prevent mold or odors.

3. Wash the mop pad regularly and allow it to air dry.

7.3 Main Brush Cleaning

1. Remove the main brush cover and lift out the main brush.
2. Use the provided cleaning tool to remove hair and debris tangled around the brush.
3. Reinstall the main brush and cover securely.

7.4 Side Brush Cleaning and Replacement

1. Regularly check the side brush for tangled hair or debris.
2. If the side brush is worn or damaged, replace it with a new one.

7.5 HEPA Filter Cleaning and Replacement

1. Tap the HEPA filter gently to remove dust. Do not wash the HEPA filter with water.
2. Replace the HEPA filter every 3-6 months, depending on usage.

7.6 Sensor and Charging Contact Cleaning

1. Wipe all sensors (cliff sensors, wall sensors) and charging contacts on both the robot and the charging base with a clean, dry cloth.
2. Ensure no dust or debris obstructs the sensors.

8. TROUBLESHOOTING

If you encounter issues with your Proscenic Q8, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not power on	Low battery; Power button not pressed correctly	Place robot on charging base; Press and hold power button for 3 seconds
Robot not charging	Charging contacts dirty; Charging base not powered	Clean charging contacts; Ensure charging base is plugged in
Robot gets stuck frequently	Obstacles in path; Sensors dirty	Clear cables and small objects; Clean cliff and wall sensors
Poor suction performance	Dustbin full; Filter clogged; Main/side brush tangled	Empty dustbin; Clean/replace filter; Clean main/side brush
App connection issues	Incorrect Wi-Fi band; Robot too far from router	Ensure 2.4GHz Wi-Fi; Move robot closer to router; Re-pair device
Mopping function not working	Water tank empty; Mop pad dry; Water outlet clogged	Refill water tank; Wet mop pad; Clean water tank outlet

9. SPECIFICATIONS

Feature	Detail





Feature	Detail
Brand	Proscenic
Model Name	P-UK-Q8-LB3
Product Dimensions	12.59" L x 12.59" W x 3.82" H
Item Weight	9.79 pounds
Battery Life	200 minutes
Voltage	28 Volts
Dustbin Capacity	600 Milliliters
Filter Type	Foam (HEPA)
Navigation Type	360° LiDAR Navigation
Special Features	Advanced Custom Cleaning, Auto-Docking, Lightweight, Low Noise, Pet Hair Pick Up, Eco Mode, Anti-Collision, Edge Cleaning, Multi-Floor Mapping, Anti-Fall
Control Methods	Proscenic App (2.4GHz WiFi), Alexa, Google Home, Siri, IFTTT

10. WARRANTY AND SUPPORT

The Proscenic Q8 Robot Vacuum Cleaner with Mop comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official Proscenic website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Proscenic customer service through the contact information provided on the official website or within the Proscenic app.

Related Documents - Q8

	<p>Proscenic Robot Vacuum APP User Guide</p> <p>A comprehensive guide to connecting and using the Proscenic APP for your robot vacuum, including integration with Amazon Alexa and Google Assistant, troubleshooting tips, and customer service contact information.</p>
	<p>Proscenic 850T Robot Vacuum User Manual</p> <p>Comprehensive user manual for the Proscenic 850T Robot Vacuum, covering setup, operation, maintenance, and troubleshooting. Learn how to use your robot vacuum for efficient cleaning.</p>
	<p>Proscenic Q8 Max Robot Vacuum User Manual</p> <p>Comprehensive user manual for the Proscenic Q8 Max Robot Vacuum, detailing setup, operation, maintenance, and safety guidelines for effective home cleaning.</p>
	<p>Proscenic APP User Guide for Robot Vacuum: Setup, Alexa Control, and Troubleshooting</p> <p>Comprehensive user guide for the Proscenic robot vacuum, detailing app connection, WiFi setup, Alexa integration, app functions, troubleshooting tips, and customer service contacts. Learn to maximize your Proscenic robot vacuum's capabilities.</p>
	<p>Proscenic M8/M8 PRO Robot Vacuum Cleaner Setup and User Guide</p> <p>A comprehensive guide to setting up and operating the Proscenic M8/M8 PRO robot vacuum cleaner. Learn how to connect to the ProscenicHome app, configure cleaning modes, manage settings, and integrate with voice assistants like Alexa and Google Home.</p>
	<p>Proscenic Robot Vacuum User Manual</p> <p>This user manual provides comprehensive instructions for setting up, operating, and maintaining the Proscenic robot vacuum cleaner, including safety precautions, cleaning modes, scheduling, troubleshooting, and FAQ.</p>