Bellemave FST00067-Q-AB1

Bellemave Queen Over Queen Heavy Duty Metal Bunk Bed

Model: FST00067-Q-AB1

1. Introduction

This manual provides detailed instructions for the assembly, safe operation, and maintenance of your Bellemave Queen Over Queen Heavy Duty Metal Bunk Bed. Designed for durability and space-saving, this bunk bed accommodates two Queen size mattresses and features a robust metal frame with built-in ladders and guardrails. Please read this manual thoroughly before assembly and use to ensure safety and proper function.



Image: The Bellemave Queen Over Queen Heavy Duty Metal Bunk Bed, fully assembled, showcasing its black metal frame and spacious design suitable for two Queen mattresses.

2. Safety Information

Your safety is paramount. Please adhere to the following safety guidelines:

- Always assemble according to the provided instructions to ensure stability.
- Do not exceed the weight capacity of 600 lbs for the lower bunk and 600 lbs for the upper bunk.
- Be cautious of sharp edges during assembly and use.
- Keep the area around the bunk bed clear to prevent accidents.
- The top bunk is not suitable for children under 6 years of age.
- Ensure guardrails are always in place and properly secured.
- Do not allow jumping on the bed.
- Use only a Queen size mattress that is compatible with the bed frame dimensions.

3. Package Contents

Your Bellemave bunk bed will arrive in two separate shipping boxes, which may arrive on different days. Please ensure you have received both packages before beginning assembly.

The packages include all necessary components and hardware for assembly. Mattresses are not included.

Upon receipt, carefully inspect all parts for any missing or damaged components. If any parts are missing or damaged, please contact customer support immediately.

4. Setup and Assembly

Assembly of the Bellemave bunk bed is required. A clear instruction manual with step-by-step guidance is included in your package. Please follow these instructions carefully.

- **Preparation:** Clear a spacious area for assembly. It is recommended to have at least two adults for assembly.
- **Unpack:** Carefully unpack all components and lay them out, verifying against the parts list in the included manual.
- **Follow Instructions:** Adhere strictly to the assembly steps provided in the separate instruction guide. Do not overtighten screws until instructed.
- **Check Connections:** Once assembled, ensure all bolts and connections are securely tightened for stability.

Size: inch




Image: Detailed dimensions of the Bellemave Queen Over Queen Bunk Bed, showing length, width, and height measurements for both bunks.



Image: A close-up view of the sturdy metal slat system that supports the mattress on both the upper and lower bunks.






Image: A detailed view of the integrated ladder, designed for safe and easy access to the top bunk.

5. Operating Instructions (Usage)

Once assembled, your Bellemave bunk bed is ready for use. Please observe the following for safe operation:

- **Weight Capacity:** The maximum weight capacity for both the upper and lower bunks is 600 lbs each. Do not exceed these limits.
- **Mattress Compatibility:** Use only Queen size mattresses. Ensure the mattress fits snugly within the frame to prevent gaps.
- **Ladder Use:** Always use the built-in ladder for climbing to and from the top bunk. Do not use chairs or other unstable objects.
- **Guardrails:** Ensure the guardrails on the top bunk are always in place and secure to prevent falls.
- **Ventilation:** Ensure adequate air circulation around the bed.

6. Maintenance

Regular maintenance will help prolong the life and ensure the safety of your bunk bed:

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the lacquered finish.
- **Tighten Connections:** Periodically check and re-tighten all bolts and screws to ensure the bed remains stable and secure. Loose connections can lead to creaking or instability.
- **Inspect Frame:** Regularly inspect the metal frame for any signs of wear, bending, or damage. Address any issues promptly.
- **Mattress Care:** Rotate and flip your mattresses regularly according to their manufacturer's recommendations.

7. Troubleshooting

If you encounter any issues with your Bellemave bunk bed, please refer to the following common solutions:

- **Missing Parts:** If you find any parts missing upon delivery, please contact customer support immediately with your order details.
- **Difficulty Assembling / Screws Not Fitting:** Ensure you are using the correct hardware for each step as indicated in the assembly manual. Do not force components. If a part appears defective, contact support.
- **Bed is Wobbly or Creaking:** This is typically caused by loose connections. Re-tighten all bolts and screws on the entire frame. Ensure the bed is on a level surface.
- **Structural Integrity Concerns (Bending/Damage):** If you observe any bending, cracks, or broken welds in the metal frame, cease using the bed immediately and contact customer support. Do not attempt to repair structural damage yourself.

8. Specifications

Feature	Specification
Model Number	FST00067-Q-AB1
Size	Queen over Queen
Product Dimensions (L x W x H)	82.67" x 62.99" x 64.96"
Color	Black
Finish Type	Lacquered
Included Components	Slat system
Compatible Mattress Size	Queen
Item Weight	55 pounds
UPC	733805184605
Weight Capacity (Each Bunk)	600 lbs

9. Warranty Information

Specific warranty details for the Bellemave Queen Over Queen Heavy Duty Metal Bunk Bed are not provided in this manual. For information regarding product warranty, including terms, conditions, and duration, please refer to the documentation included with your purchase or contact Bellemave customer support directly.

10. Customer Support

For any questions, concerns, or assistance with your Bellemave bunk bed, please do not hesitate to contact our customer support team:

Email: US-VC@bellemavehome.com

When contacting support, please provide your product model number (FST00067-Q-AB1) and a detailed description of your inquiry or issue to facilitate a quicker resolution.

© 2025 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question