

[Manuals.plus](#) /

> [Mova](#) /

> Mova K30 Mix Wet Dry Vacuum Cleaner User Manual

## Mova K30 Mix

# Mova K30 Mix Wet Dry Vacuum Cleaner User Manual

Model: K30 Mix | Brand: Mova

## INTRODUCTION

---

Thank you for choosing the Mova K30 Mix Wet Dry Vacuum Cleaner. This 4-in-1 cordless vacuum is designed for multi-surface cleaning, offering powerful 18000Pa suction for both wet and dry messes. Its innovative features include a 180° lie-flat design for reaching under furniture, dual-sided cleaning for edges, and a self-cleaning system with 140°F hot air drying. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Mova K30 Mix.

## PACKAGE CONTENTS

---

Please check the package contents upon unboxing to ensure all items are present:

- Main Body x1
- Handle x1
- Charging Base x1
- Spare Roller Brush x1
- Clean brush x1
- Combination Tool x1
- Motorized Mini Brush x1
- Dust Cup x1
- Motor Handle x1
- Cleaning Solution x1
- Replacement Filter x1



Figure 1: Overview of all components included in the Mova K30 Mix package.

## SETUP AND INITIAL USE

### 1. Assembly

1. Insert the handle into the main body until it clicks securely into place.

2. Place the charging base on a flat, stable surface near a power outlet.
3. Connect the power adapter to the charging base and plug it into the wall outlet.



**Figure 2:** The Mova K30 Mix in its upright vacuum configuration and as a handheld unit with various attachments.

## 2. Initial Charging

Before first use, fully charge the Mova K30 Mix. Place the vacuum on the charging base. The LED display will indicate charging status. A full charge typically takes approximately 4-5 hours.

## 3. Filling the Clean Water Tank

For wet cleaning, detach the clean water tank. Fill it with clean tap water up to the MAX line. You may add a small amount of the provided cleaning solution if desired. Reattach the tank securely.

# OPERATING INSTRUCTIONS

---

## 1. Power On/Off and Mode Selection

Press the power button to turn on the vacuum. The LED screen will display the current mode. Press the mode selection button to cycle through available cleaning modes:

- **Auto Mode:** Automatically adjusts suction power and water output based on detected dirt levels.
- **Turbo Mode:** Provides maximum suction for heavily soiled areas.
- **Suction Mode:** For vacuuming liquids without dispensing water.



## Smartly Handle Wet & Dry Messes

**Figure 3:** Visual representation of the Mova K30 Mix operating in Auto, Ultra, Suction, and Turbo modes for handling various wet and dry messes.

### 2. Cleaning Performance

The K30 Mix delivers 18,000 Pa of suction power and 500 RPM rapid mopping. It is suitable for hard floors, hardwoods,

vinyl, tile, and sealed wood.



18,000 Pa  
Suction

500 RPM  
Fast Mopping

Wet & Dry  
Messes

## Achieve Remarkable Clean with Ease

Figure 4: The Mova K30 Mix demonstrating its 18,000 Pa suction and 500 RPM fast mopping for effective wet and dry mess cleanup.

### 3. Specialized Cleaning Features

- **180° Lie-Flat Reach:** The vacuum's design allows it to lay nearly flat, reaching under furniture as low as 5.51 inches. The brush head is only 3.15 inches, enabling access to tight spaces.



**Figure 5:** The Mova K30 Mix showcasing its 180° lie-flat design, allowing it to clean effectively under low furniture. Dimensions of the brush head (3.15 in) and minimum clearance (5.51 in) are indicated.

- **0-inch Dual-Edge Cleaning:** The exclusive brush roller design allows for precise cleaning along baseboards and into corners, leaving no gaps.



## 0 in\* Dual-Edge Cleaning

**Figure 6:** The Mova K30 Mix demonstrating its ability to clean right up to edges and corners with its 0-inch dual-edge cleaning feature.

- **4-in-1 Versatility:** Easily switch between wet-dry vacuum, handheld vacuum, and specialized tools like the Floor Washer, Mini-Brush, and Combination Tool for comprehensive cleaning.



# All-in-One Multi-Functional Wet and Dry Vacuum

**Figure 7:** The Mova K30 Mix shown in various configurations, highlighting its 4-in-1 versatility as a wet-dry vacuum, handheld vacuum, and with specialized tools.

## MAINTENANCE

---

### 1. Dual Rotation Self-Cleaning & Hot Air Drying

After each use, place the vacuum on the charging base and press the self-cleaning button. The brush roller will undergo a dual rotation wash to remove debris and excess water. This is followed by a 30-minute 140°F hot air drying cycle to prevent odors and keep the brush dry.



**Figure 8:** The Mova K30 Mix's self-cleaning process, showing the brush roller being washed and then dried with 140°F hot air for 30 minutes.

## 2. Emptying the Dirty Water Tank

Regularly empty the dirty water tank after each cleaning session. Detach the tank, open the lid, and dispose of the contents. Rinse the tank with clean water and allow it to air dry before reattaching.

## 3. Cleaning/Replacing the HEPA Filter

The HEPA filter should be cleaned regularly to maintain optimal suction. Remove the filter from the dirty water tank assembly. Rinse it under running water until clean. Allow the filter to air dry completely for at least 24 hours before reinserting. Replace the filter every 3-6 months, or as needed, depending on usage.

## 4. Cleaning the Brush Roller

Even with self-cleaning, occasionally remove the brush roller for manual inspection and cleaning. Use the provided cleaning brush to remove any tangled hair or debris. Ensure the brush roller is free of obstructions for effective cleaning.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Battery is depleted; Not properly seated on charging base.	Charge the vacuum fully; Ensure the vacuum is correctly placed on the charging base.
Low Suction	Dirty water tank full; Clean water tank empty; Clogged brush roller; Clogged filter.	Empty dirty water tank; Refill clean water tank; Clean brush roller; Clean/replace HEPA filter.
Water Leakage	Water tanks not properly installed; Tank seals are dirty or damaged.	Ensure tanks are securely latched; Clean tank seals; Contact support if seals are damaged.
Unpleasant Odor	Dirty water tank not emptied/cleaned; Brush roller not dried properly.	Empty and thoroughly clean dirty water tank; Run self-cleaning cycle with hot air drying.

## SPECIFICATIONS

Feature	Detail
Brand	Mova
Model	K30 Mix
Special Feature	HEPA Filter, 180° Lie-Flat Reach, 140°F Hot Air Drying, Dual-Edge Cleaning
Filter Type	HEPA
Surface Recommendation	Hard Floor, Hardwoods, Vinyl, Tile, Sealed Wood
Power Source	Battery Powered
Cordless	Yes
Runtime	Up to 30 minutes (Floor Washing), Up to 50 minutes (Vacuuming)

Feature	Detail
Suction Power	18,000 Pa
Mopping Speed	500 RPM
Recommended Uses	Floor cleaning, wet and dry messes
Form Factor	Upright, Handheld



# Consistent Durable Performance

Figure 9: Illustration of the Mova K30 Mix's battery performance, indicating up to 30 minutes for floor washing and 50 minutes for vacuuming, covering up to 2583 sq ft.

For warranty information, technical support, or any inquiries regarding your Mova K30 Mix, please refer to the warranty card included in your package or visit the official Mova website. You can also contact Mova customer service through their official channels for assistance.

**Mova Official Store:** [Visit Mova Store on Amazon](#)



© 2024 Mova. All rights reserved.