

manuals.plus /

- > [qirita](#) /
- > [qirita 120 LED Selfie Light Model D10 User Manual](#)

qirita D10

qirita 120 LED Selfie Light Model D10 User Manual

Comprehensive instructions for operation and maintenance.

1. INTRODUCTION

Thank you for choosing the qirita 120 LED Selfie Light, Model D10. This portable and versatile lighting device is designed to enhance your photos, videos, and online presence by providing optimal illumination. It features adjustable color temperature, multiple brightness levels, and a long-lasting rechargeable battery, making it suitable for various applications with smartphones, tablets, laptops, and cameras. Please read this manual thoroughly before use to ensure proper operation and to maximize the product's lifespan.



Image 1.1: The qirita 120 LED Selfie Light, demonstrating its use with a smartphone and laptop for improved lighting.

2. PRODUCT FEATURES

- **Adjustable Color Temperature:** Offers 3 distinct lighting modes with color temperature adjustment from 2500K (warm light) to 9000K (cool white light) to match different environments and desired moods.
- **10 Brightness Levels:** Equipped with 120 high-brightness LEDs and 10 adjustable brightness settings, allowing precise control over illumination intensity.
- **High Color Rendering Index (CRI):** Features a CRI of over 95, ensuring natural and accurate color reproduction, particularly for skin tones.
- **Long-lasting Rechargeable Battery:** Integrated 3000mAh high-capacity battery provides extended operational time.
- **Universal Compatibility:** Designed with silicone padding to protect devices and is compatible with all smartphones, tablets, laptops, and other devices.
- **Flexible Mounting Options:** Includes a versatile clip with 180° adjustable angle and a 1/4" cold shoe mount for attachment to cameras, tripods, and selfie sticks.
- **Portable and Lightweight Design:** Weighs only 158g and is 15mm thick, making it easy to carry for on-the-go use.

PRODUCT STRUCTURE



Image 2.1: Demonstration of the three color temperature modes: Warm Light (2500K), Natural Light, and White Light (9000K).



Image 2.2: Visual comparison illustrating the enhanced color rendering with a CRI of 95+.

3. PACKAGE CONTENTS

The qirita 120 LED Selfie Light package includes the following items:

- 1 x qirita 120 LED Selfie Light (Model D10)
- 1 x Multi-function Clip with Cold Shoe Mount
- 1 x USB-C Charging Cable (not explicitly listed but implied by USB-C interface and charging capability)

4. PRODUCT OVERVIEW (PHYSICAL COMPONENTS)

Familiarize yourself with the main components of your selfie light:

PORTABLE & LIGHTWEIGHT

Easy to carry, easy to take photos anytime



Image 4.1: Labeled diagram of the qirita 120 LED Selfie Light's components.

1. **Color Temperature Adjustment Knob:** Used to cycle through and fine-tune the color temperature (2500K-9000K).
2. **Brightness Adjustment Knob:** Used to adjust the light intensity across 10 levels.
3. **Power Switch:** Turns the device On or Off.
4. **Battery Display:** Indicates the current battery level.
5. **Type-C Charging Interface:** Port for connecting the USB-C charging cable.
6. **Light Board:** The panel containing the 120 LED lights.
7. **1/4" Screws:** Standard mounting points for accessories like tripods.
8. **Cold Shoe Mount:** Accessory for attaching the light to cameras or other compatible equipment.

5. SETUP AND INSTALLATION

Follow these steps to set up your qirita 120 LED Selfie Light:

1. **Attach the Clip:** Securely attach the multi-function clip to the 1/4" screw hole on the bottom of the selfie light. Ensure it is tightened to prevent wobbling.
2. **Mounting to Device:**

- **For Phones/Tablets/Laptops:** Open the clip and attach it to the top edge of your device. The silicone padding on the clip will protect your screen and device from scratches. Adjust the light's angle as needed.
 - **For Cameras/Tripods/Selfie Sticks:** If your camera or accessory has a cold shoe mount, slide the cold shoe adapter on the clip into the mount. Alternatively, use the 1/4" screw hole on the clip to attach it to a tripod or selfie stick.
3. **Adjust Angle:** The light and clip assembly allows for a 180° adjustment. Position the light to achieve the desired illumination angle for your subject.



Image 5.1: The selfie light demonstrating compatibility with various devices.

LARGE 3000 MAH CAPACITY BATTERY

Can be charged using a power source, power bank or computer usb



Image 5.2: Illustration of the 180° adjustable angle and non-slip features of the clip.

6. OPERATING INSTRUCTIONS

To operate your qirita 120 LED Selfie Light:

1. **Power On/Off:** Locate the Power Switch on the side of the light. Slide it to the 'On' position to turn on the light. Slide it to the 'Off' position to turn it off.
2. **Adjust Brightness:** Use the Brightness Adjustment Knob to increase or decrease the light intensity. There are 10 levels of brightness available. Rotate the knob to achieve your desired illumination.
3. **Adjust Color Temperature:** Use the Color Temperature Adjustment Knob to cycle through the three main color modes (Warm, Natural, White) and fine-tune the temperature between 2500K and 9000K.
4. **Monitor Battery:** The Battery Display will show the remaining power. Ensure the light is sufficiently charged before use.

7. CHARGING THE DEVICE

The qirita 120 LED Selfie Light is equipped with a 3000mAh rechargeable battery.

1. **Connect Charging Cable:** Insert the USB-C end of the charging cable into the Type-C Charging Interface on the light.

2. **Connect to Power Source:** Connect the other end of the USB-C cable to a compatible USB power source, such as a laptop, PC, power bank, USB wall charger, or car charger.
3. **Charging Indicator:** The Battery Display will indicate the charging status. Once fully charged, the indicator will typically show a full battery.
4. **Charging Time:** Allow sufficient time for the battery to fully charge before extended use.



Image 7.1: The qirita selfie light connected to a power source for charging.

8. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your selfie light:

- **Cleaning:** Use a soft, dry cloth to clean the surface of the light. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Water:** This device is not waterproof. Avoid exposure to water or high humidity.
- **Handle with Care:** Avoid dropping or subjecting the device to strong impacts.
- **Battery Care:** For best battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

9. TROUBLESHOOTING

If you encounter any issues with your qirita 120 LED Selfie Light, please refer to the following common solutions:

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted. Power switch is off.	Charge the device using the provided USB-C cable. Ensure the power switch is in the 'On' position.
Light is dim or flickers.	Low battery. Brightness setting is too low.	Recharge the battery. Adjust the Brightness Adjustment Knob to a higher setting.
Cannot adjust color temperature or brightness.	Knobs are not being rotated correctly.	Ensure you are rotating the correct knob for the desired adjustment. Refer to Section 4 for component identification.

Problem	Possible Cause	Solution
Clip does not hold device securely.	Clip is not fully opened or device is too thick.	Ensure the clip is fully opened and properly positioned on the device. Verify your device's thickness is within the clip's capacity.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

10. SPECIFICATIONS

Feature	Detail
Model Number	D10
Manufacturer	QIRITA
Dimensions	13.9 x 7 x 3.7 cm
Weight	158 grams
LED Quantity	120 LEDs
Color Temperature	2500K - 9000K (Adjustable)
Brightness Levels	10 Levels (Adjustable)
Color Rendering Index (CRI)	> 95
Battery Capacity	3000mAh (Rechargeable)
Charging Interface	USB-C
Compatible Shoe Mount	Cold Shoe
UPC	658360830500

11. WARRANTY AND SUPPORT INFORMATION

For warranty claims, returns, or technical support, please refer to the retailer's return policy or contact the manufacturer directly.

- **Return Policy:** Standard Amazon return policy applies, allowing returns within 30 days of receipt for a change of mind. Specific procedures are in place for defective or damaged products.
- **Manufacturer Support:** For product-specific inquiries or issues not covered in this manual, please visit the official qirita store on Amazon or contact their customer service.