

Ahomly WR312-G

Ahomly WR312-G 4-Piece Outdoor Wicker Patio Furniture Set Instruction Manual

1. PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Ahomly WR312-G 4-Piece Outdoor Wicker Patio Furniture Set. This set is designed for outdoor use on balconies, backyards, and porches, offering comfortable seating and a functional table.

The set includes a love seat, two individual chairs, and a glass-top coffee table. Key features include an ergonomic recline tilt for comfort, wide seats and deep dimensions tailored for adult postures, a high backrest for full-body support, and durable hand-woven PE rattan construction.

Product Dimensions




Image 1: Overview of the Ahomly 4-Piece Outdoor Wicker Patio Furniture Set, featuring a love seat, two chairs, and a coffee table with beige cushions.

2. SETUP AND ASSEMBLY

Your Ahomly WR312-G patio furniture set requires assembly. All necessary hardware and tools (Allen wrench) are included. For successful installation, do not fully tighten any screws until all parts are loosely assembled. Once all components are in place, then firmly tighten all screws.

2.1 Unpacking and Component Identification

Carefully unpack all components from the box. Verify that all parts listed in the assembly instructions are present and undamaged before beginning assembly.

2.2 Assembly Steps

Follow the detailed assembly instructions provided in the packaging. It is recommended to have two people for assembly to ensure ease and proper alignment of parts. Avoid overtightening bolts initially to allow for flexibility during assembly.

Video 1: Official Ahomly video demonstrating the 4-piece furniture set, providing a visual overview of the components and their arrangement.

Video 2: Official Ahomly video showcasing the 4-piece patio furniture set, highlighting its design and suitability for outdoor spaces.

3. OPERATING AND USAGE GUIDELINES

This patio set is designed for comfortable outdoor lounging. The chairs feature a 110° ergonomic recline tilt, providing optimal relaxation and ease of standing. The 20" wide seats and 30" deep dimensions are tailored for adult postures, ensuring ample space and comfort. The 32" high backrest offers full-body support from the waist to the neck.

3.1 Weight Capacity

Do not exceed the weight limit of 550 pounds for the love seat chair. Individual chairs have a suitable weight capacity for typical adult use.

3.2 Placement

Place the furniture set on a flat, stable surface. It is suitable for various outdoor environments such as balconies, backyards, and porches.



Image 2: Close-up view illustrating the 110° ergonomic recline tilt design of the patio chair, enhancing comfort and ease of use.

4. MAINTENANCE

Proper maintenance will extend the lifespan and appearance of your patio furniture set.

4.1 Rattan Care

The furniture features 8mm hand-woven PE rattan, which is 20% thicker than ordinary rattan and weather-resistant. Clean the rattan surfaces with a soft cloth and mild soap solution. Rinse thoroughly and allow to air dry.



Image 3: Detailed view of the hand-woven PE wicker material, highlighting its tight weave and durable texture.

4.2 Cushion Care

The seat cushions are removable, easy to clean, and water-resistant. Unzip the covers to remove them for washing. Follow the care instructions on the cushion labels for best results.

Seat Cushion

- Removable
- Easy to clean
- Water-resistant



Image 4: Close-up of a seat cushion, showing its removable cover with a zipper for easy cleaning and its water-resistant properties.

4.3 Glass Tabletop Care

The coffee table features a tempered glass tabletop with a smooth surface that is easy to clean and offers heat stability. Use a soft cloth and glass cleaner for optimal results.

Tempered Glass Tabletop

Smooth Surface-Easy to Clean ·
Sophisticated Touch ·
Heat Stability ·



Image 5: View of the tempered glass tabletop, emphasizing its smooth, easy-to-clean surface and sophisticated appearance.

4.4 Environmental Protection

Keep the furniture set away from direct sunlight and harsh weather conditions to maintain its longevity and safety. Consider using a furniture cover during extreme weather or prolonged periods of non-use.

5. TROUBLESHOOTING

If you encounter any issues with your patio furniture set, please refer to the assembly instructions to ensure all components are correctly installed and tightened. For persistent problems or concerns, please contact customer support.

6. SPECIFICATIONS

Attribute	Value
Brand	Ahomly

Model Number	WR312-G
Set Name	4-Piece Outdoor Wicker Patio Furniture Set
Color	Beige
Material Type	Dacron, PE Rattan, Sponge, Wicker
Item Dimensions	45 x 45 x 32 inches
Item Weight	78.3 Pounds
Love Seat Weight Limit	550 pounds
Required Assembly	Yes
Included Components	Two chairs, glass table, loveseat, two pillows



Image 6: Detailed product dimensions for the love seat (45"W x 30"D x 32"H, 550lbs capacity), individual chair (26"W x 30"D x 32"H), and coffee table (29.5"L x 15.7"W x 15"H, 110lbs capacity).

7. WARRANTY AND SUPPORT

Ahomly offers a 1-year replacement guarantee for this product. For any questions or assistance, please contact Ahomly customer email support, available 24 hours. The product also comes with a 30-day easy return policy.