



[Manuals.plus](#) /

> [RXUJYC](#) /

> RXUJYC 9.0 Cuft Extra Large Home Safe Fireproof Waterproof, Heavy Duty Fire Proof Safes with Fireproof Bag, Electronic Keypad, Keys and Inner Cabinet, Anti-theft Large Safe Box for Home Business Office 9.0 Cub Instruction Manual

## **RXUJYC Extra Large Home Safe Box**

# **RXUJYC 9.0 Cuft Extra Large Home Safe Instruction Manual**

Model: Extra Large Home Safe Box

Brand: RXUJYC

## **INTRODUCTION**

Thank you for choosing the RXUJYC 9.0 Cuft Extra Large Home Safe. This heavy-duty, fireproof, and waterproof safe is designed to provide superior security for your valuable possessions, including laptops, pistols, jewelry, documents, and cash. Its robust construction and advanced features ensure your items are protected from theft, fire, and water damage. Please read this manual thoroughly before setup and operation to ensure proper use and maximize the safe's protective capabilities.



The RXUJYC 9.0 Cuft Extra Large Home Safe, designed for secure storage of various valuables.

## SETUP GUIDE

### Unpacking

Carefully remove the safe from its packaging. Inspect the safe for any signs of damage. Retain all packaging materials until you are satisfied with the product.


### Battery Installation

The electronic keypad requires 4 x 1.5V AAA batteries. Locate the battery compartment, typically behind the keypad or inside the door. Insert the batteries, ensuring correct polarity. An external battery case is provided for emergency power if internal batteries die.

### Anchoring the Safe

For enhanced security, it is highly recommended to anchor the safe to a wall or floor. The safe includes pre-drilled mounting holes and hardware. Choose a secure location, mark the drilling points, and use appropriate tools to secure the safe firmly.

# EXTRA LARGE SAFE BOX



Dimensions and internal layout of the safe, highlighting the inner cabinet and hidden lock box.

# HEAVY-DUTY HOME SAFE



The safe weighs 83 pounds, making it difficult to move without proper anchoring.

Your browser does not support the video tag.

This video demonstrates the initial setup steps, including battery installation, opening the safe with the default password, and the process of anchoring the safe to a wall or floor for maximum security.

## OPERATING INSTRUCTIONS

### Opening the Safe (Default Password)

To open the safe for the first time, use the default password, which is typically '1234'. Enter '1234' on the electronic keypad, then press '#'. The door should unlock, allowing you to open it.

### Setting Your Personal Code

1. With the safe door open, locate the red reset button on the inside of the door, near the hinge.
2. Press the reset button. You will hear a beep, indicating the safe is ready to accept a new code.
3. On the electronic keypad, input your desired 3-8 digit code.
4. Press '#' to confirm your new code. You will hear a confirmation beep.

## Opening with New Code

To open the safe with your new personal code, simply enter your 3-8 digit code on the keypad, then press '#'. The safe will unlock.

## Using Emergency Keys

In case you forget your password or the batteries are completely drained, you can use the emergency keys provided. Locate the hidden keyhole, insert the emergency key, and turn it to unlock the safe. It is recommended to store these keys in a secure location away from the safe.




The safe offers two convenient unlocking methods: digital password and emergency key.


## PRODUCT FEATURES

### Extra Large Capacity

With an extra-large size of 16.9" x 14.9" x 31.5", this safe provides ample space for a wide range of valuables. The interior is lined with soft felt to prevent scratches and wear on your items. A removable shelf allows for flexible organization of the internal space.



**WITH SHELF**



**WITHOUT SHELF**




The removable shelf allows for customizable storage configurations.

## Heavy-Duty Construction

The safe is built with a 65mm ultra-thick alloy pry-resistant steel door and features 7 x 30mm high-strength solid core lock bolts. Concealed, pry-resistant hinges and a recessed door design provide robust protection against forced entry. Weighing 83 pounds, the safe is difficult to move without anchoring.

# ALL-STEEL SECURITY SAFE



Detailed view of the safe's robust door construction and locking bolts.

## Fireproof and Waterproof Bag

Included with your safe is a waterproof and fireproof document bag. This bag provides an additional layer of protection for sensitive documents, cash, and jewelry against fire, hurricanes, and other environmental hazards.

# ***FIREPROOF DESIGN***

① **Metal Coating**

② **Steel Plate Layer**

③ **Fire-resistant Material**

④ **Metal Coating**



The safe's multi-layered construction includes fire-resistant materials for enhanced protection.

## **Dual Security Alarm System**

The safe is equipped with a dual alarm system. If three consecutive incorrect password attempts are made, the safe will lock for 20 seconds. After six incorrect attempts, it will lock for 5 minutes. This feature deters unauthorized access and provides an audible alert.

# KEEP VALUABLES AWAY FROM KIDS OR THIEVES



The dual security alarm system helps keep valuables safe from unauthorized access.

## Inner Cabinet and Hidden Lock Box

The safe includes a built-in inner cabinet and a bottom hidden lock box, offering an extra layer of privacy and organization for smaller, highly sensitive items. Both can be secured independently with their respective keys.

## MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Battery Check:** Periodically check the batteries in the electronic keypad. Replace them annually or when the low battery indicator appears to ensure continuous operation.
- **Key Storage:** Always store emergency keys and inner cabinet keys in a secure location separate from the safe. Do not store them inside the safe.
- **Door Mechanism:** Keep the door bolts and hinges clean and free of obstructions. Do not lubricate the locking mechanism.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Safe does not open with password.	Incorrect password entered. Low batteries. Keypad malfunction.	Re-enter password carefully. Replace batteries. Use emergency key. Contact customer support if issue persists.
Alarm sounds unexpectedly.	Multiple incorrect password attempts. Safe moved or tampered with.	Ensure correct password entry. Check for tampering. The alarm will reset after a set period or upon correct entry.
Door does not close or latch properly.	Obstruction in the door frame. Bolts not retracting fully.	Check for any items blocking the door. Ensure the handle is fully turned to retract bolts before closing.
Keypad is unresponsive.	Dead batteries. Loose battery connection.	Replace all batteries. Ensure batteries are inserted correctly.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	RXUJYC
Product Dimensions	14.9"D x 16.9"W x 31.5"H
Capacity	9 Cubic Feet
Material	Alloy Steel
Special Features	Alarm System, Sensor Light, Combination Lock, Anti-Theft, Removable Shelf
Mounting Type	Floor Mount
Control Type	Push Button Control
Included Components	1 x Home Safe, 2 x Emergency Keys, 2 x Hidden Safe Keys, 1 x Fireproof Bag, 2 x Inner Cabinet Keys
Alarm	Audible
Water Resistance Level	Water Resistant
Item Model Number	Extra Large Home Safe Box

## WARRANTY AND SUPPORT

Your RXUJYC Home Safe is designed for durability and reliability. For any questions, technical assistance, or warranty claims, please refer to the contact information provided with your purchase or visit the official RXUJYC website. Please have your product model number and purchase details ready when contacting support.

