



Manuals.plus /

- › **4 EVER WINNER /**
- › 4 EVER WINNER White Desk with Drawers, Model CD SEVEN 241105 - Instruction Manual

4 EVER WINNER CD SEVEN 241105

4 EVER WINNER White Desk with Drawers, Model CD SEVEN 241105 - Instruction Manual

Comprehensive instruction manual for the 4 EVER WINNER White Desk with Drawers, Model CD SEVEN 241105. Includes assembly, safety, and maintenance guidelines for optimal use.

PRODUCT OVERVIEW

The 4 EVER WINNER White Desk with Drawers, Model CD SEVEN 241105, is a versatile and stylish addition to any home office, bedroom, or study area. Designed with a farmhouse aesthetic, it combines functionality with a clean, retro-industrial appearance. This desk features a built-in monitor stand to promote ergonomic posture, multiple storage options including a file drawer, and a spacious desktop for various activities.



Image: The 4 EVER WINNER White Desk with a monitor placed on its elevated stand, showcasing its functional design.

IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent injury or damage to the product.

- Always assemble the desk according to the provided instructions.
- Ensure that the desk is fully assembled and stable before use.
- Do not place heavy objects on the desk that exceed its weight limit.
- When using a monitor, ensure it is properly placed on the monitor stand and does not exceed the stand's weight limit.
- Always anchor the desk to the wall or floor to prevent tipping, especially if using it with a monitor.

- Keep the desk away from heat sources and do not place liquids on it to prevent damage.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. Refer to the assembly video for a visual guide to components.

Your browser does not support the video tag.

Video: "How to install the computer desk?" - This video provides a detailed overview of all components and step-by-step assembly instructions for the computer desk.

The package includes all necessary hardware kits and clear instructions for assembly.

ASSEMBLY INSTRUCTIONS

Assembly is recommended for two people. A screwdriver is recommended for assembly. Please follow the steps outlined in the provided videos and diagrams.

Step 1: Prepare Components

Unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the labels in the instruction manual.



Image: A detailed diagram showing the dimensions of the desk and its individual components, including drawers and shelves.

Step 2: Assemble the Main Frame

Begin by connecting the side panels to the main desktop using the provided hardware. Ensure all connections are secure.

Your browser does not support the video tag.

Video: "White Computer Desk with Drawers" - This video demonstrates the assembly process for the main frame and drawer components.

Step 3: Install Drawer Slides

Attach the drawer slides to the interior panels of the desk. Pay attention to the orientation of the slides to ensure smooth operation of the drawers.

Step 4: Assemble Drawers


Construct the drawers by attaching the side, front, and back panels. Install the drawer handles as shown in the instructions. The desk includes a file drawer designed for A4 sized folders and additional storage drawers.



Easy to push and pull drawer



Computer desk with monitor shelf



Storage Shelf Under Desk



wide desktop writing table

Image: The desk with its drawers open, revealing storage space, and a monitor placed on the elevated shelf.

Step 5: Integrate Monitor Stand and Shelves

Attach the monitor stand and any additional storage shelves to the desktop. The monitor stand helps raise your screen to an ergonomic height, reducing neck and back strain. The desk also features a cable management hole to keep cords organized.



Image: Close-up details of the desk, highlighting the cable management hole, rounded corner design, and button metal handle.

Step 6: Insert Drawers

Carefully slide the assembled drawers into their respective slots, ensuring they glide smoothly on the installed slides.

Your browser does not support the video tag.

Video: "Small Desk with Drawers" - This short video demonstrates the functionality of the drawers and overall desk structure.

OPERATING INSTRUCTIONS

- **Drawers:** Gently pull the handles to open and push to close. Avoid forcing drawers to prevent damage to the slides.
- **Monitor Stand:** Place your monitor on the elevated stand for improved ergonomics. Ensure the monitor's weight does not exceed the stand's capacity.
- **Cable Management:** Utilize the cable management hole to route and organize power cords and other cables, keeping your workspace tidy.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** Protect the desk from excessive moisture and direct sunlight to prevent warping or discoloration.

TROUBLESHOOTING

- **Desk feels wobbly:** Ensure all screws and fasteners are securely tightened. Check that the desk is on a level surface.
- **Drawers do not slide smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure no objects are obstructing the slides.
- **Missing parts:** If any parts are missing or damaged upon delivery, contact customer support for assistance.

SPECIFICATIONS

Attribute	Detail
Brand	4 EVER WINNER
Model Number	CD SEVEN 241105
Color	White
Materials	Wood
Product Dimensions (D x W x H)	20.5"D x 44"W x 38.2"H
Item Weight	65 Pounds
Number of Drawers	4
Special Features	Monitor Stand, File Drawer, Storage Shelves, Cable Management Hole
Required Assembly	Yes
Recommended Number of People for Assembly	2
Tools Recommended For Assembly	Screw Driver

WARRANTY AND SUPPORT

This 4 EVER WINNER product comes with a limited warranty. For specific details regarding warranty coverage, claims, or any product-related inquiries, please refer to the warranty card included in your package or contact 4 EVER WINNER customer support directly.

If your computer desk with storage is damaged, lost, or scratched during delivery, we will assist you in resolving the issue.

