Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Csasan J90 Pro

Csasan J90 Pro Wireless Earbuds User Manual

Model: J90 Pro | Brand: Csasan

Introduction

The Csasan J90 Pro Wireless Earbuds offer an advanced audio experience with Bluetooth 5.3 technology, extended playtime, and clear call quality. Designed for comfort and durability, these in-ear earphones are suitable for various activities, from workouts to daily commutes.



Image: The Csasan J90 Pro Wireless Earbuds in their charging case, showcasing the LED display.

What's in the Box

Your Csasan J90 Pro package includes the following items:

- 2 x J90 Pro Bluetooth Earbuds
- 1 x Charging Case
- 1 x USB-C Cable
- 3 x Pairs of Ear Caps (S, M, L)
- 1 x User Manual

Setup Guide

1. Charging the Earbuds and Case

Before first use, ensure both the earbuds and the charging case are fully charged. The charging case features an LED display that shows the remaining battery level of the case and the charging status of each earbud.

- Connect the provided USB-C cable to the charging port on the case and a power source.
- The LED display will indicate charging progress. A full charge for the case takes approximately 1.5 hours.
- Place the earbuds into the charging case. They will automatically begin charging.



Image: The charging case with its LED display showing battery levels for the case and individual earbuds.

2. Pairing with Your Device

The J90 Pro earbuds utilize Bluetooth 5.3 for a fast and stable connection. They feature one-step pairing for convenience.

1. Ensure Bluetooth is enabled on your smartphone, laptop, or other compatible device.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.
3. On your device, search for Bluetooth devices and select "J90 Pro" from the list.
4. Once connected, you will hear a confirmation prompt, and the earbuds are ready for use.




Image: Visual representation of the one-step pairing process with a smartphone, showing the earbuds automatically connecting upon opening the case.

Operating Instructions

The J90 Pro earbuds feature sensitive touch controls for easy management of calls and music playback.

Music Playback

- **Play/Pause:** Tap once on either earbud.

- **Next Song:** Tap twice on the right earbud.
- **Previous Song:** Tap twice on the left earbud.
- **Volume Up:** Press and hold the right earbud.
- **Volume Down:** Press and hold the left earbud.

Call Management

- **Answer Call:** Tap once on either earbud.
- **End Call:** Tap once on either earbud during a call.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Triple tap on either earbud.



Image: Detailed diagram illustrating the touch control functions for music, calls, and voice assistant.

Maintenance

To ensure the longevity and optimal performance of your Csasan J90 Pro Wireless Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The earbuds feature an IPX7 waterproof rating, meaning they can withstand splashes, sweat, and rain. However, they are not designed for submersion in water or use during swimming. Ensure the charging port is dry before charging.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Ear Caps:** Periodically remove and clean the ear caps. Replace them if they become worn or damaged to maintain optimal fit and sound quality.

Troubleshooting

If you encounter issues with your J90 Pro earbuds, try the following common troubleshooting steps:

Problem	Solution
Earbuds not pairing/connecting	• Ensure Bluetooth is enabled on your device. • Make sure the earbuds are charged and the case is open. • Forget "J90 Pro" from your device's Bluetooth settings and try pairing again. • Restart your device.
Only one earbud working	• Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. • Ensure both earbuds are charged. • Try resetting the earbuds (refer to user manual for specific reset instructions if available, otherwise try forgetting and re-pairing).
Low volume or poor sound quality	• Adjust the volume on both your device and the earbuds. • Ensure ear caps are properly fitted and clean. • Check for obstructions in the earbud speakers. • Ensure the earbuds are within range of your device.
Charging issues	• Check the USB-C cable and charging adapter for damage. • Ensure the charging contacts on the earbuds and inside the case are clean and dry. • Try a different charging cable or power source.

Specifications

Model Name	J90 Pro

Brand	Csasan
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Type	Dynamic Driver (13mm)
Frequency Range	20 Hz - 20,000 Hz
Battery Life	Up to 40 Hours (with charging case)
Single Charge Playtime	Up to 8 Hours
Charging Time	Approx. 1.5 Hours (case)
Water Resistance Level	IPX7 Waterproof
Control Method	Touch
Earbud Weight	4g (each)

Warranty and Support

For warranty information and customer support, please refer to the official Csasan website or contact their customer service directly. Keep your purchase receipt for any warranty claims.
Common support inquiries include:

- Product registration
- Technical assistance
- Replacement parts
- Warranty claims

© 2024 Csasan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DH2L6WZ5

More documents and user manuals: **https://manuals.plus/**