Unineo SF20250525B0DH2RNX13

Unineo 75-Inch Electric Fireplace TV Stand Instruction Manual

Model: SF20250525B0DH2RNX13

Introduction Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the Unineo 75-Inch Electric Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions thoroughly before use and retain them for future reference.



Figure 1: Unineo 75-Inch Electric Fireplace TV Stand.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

General Safety Guidelines:

- Read all instructions before installing or using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped, or damaged in any manner.
- Do not use outdoors.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- All electrical heaters have hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable vapors or liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

3. Package Contents

Your Unineo Electric Fireplace TV Stand will arrive in two separate packages, which may not arrive simultaneously. Please ensure all components are present before beginning assembly.






Figure 2: Packaging and overall dimensions.

Included Components:

- TV Stand components (numbered for easy identification)
- Electric Fireplace Insert
- Remote Control (for both fireplace and LED lights)
- Assembly Hardware
- Instruction Manual

4. Setup and Assembly

Assembly is recommended for two people for faster and safer installation. No electrician is required; simply plug in the unit.

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out. Verify that all numbered pieces and hardware are present according to the included parts list.
2. **Assemble the Main Frame:** Follow the step-by-step instructions provided in the separate assembly guide. Ensure all connections are secure.
3. **Install the Electric Fireplace:** Once the main TV stand frame is assembled, carefully slide the electric fireplace insert into its designated opening.
4. **Install Doors and Shelves:** Attach the barn-style doors and install the adjustable glass shelves in the side cabinets. The glass shelves can hold up to 20 lbs.
5. **Cable Management:** Utilize the convenient cable management features to organize wires from your TV and media equipment.



Figure 3: Media equipment shelf dimensions.



Figure 4: Adjustable glass shelves.

Placement:

- Place the TV stand on a flat, stable surface.
- Ensure adequate clearance around the unit for proper ventilation of the fireplace heater.
- The TV stand can accommodate TVs up to 85 inches.

5. Operating Instructions

The electric fireplace and LED lights can be controlled via the included remote control or the touch panel on the fireplace unit.

Electric Fireplace Operation:

- **Power On/Off:** Press the power button on the remote or touch panel to turn the fireplace on or off.
- **Flame Colors:** The 3-side panoramic fireplace features 12 flame colors and 13 log ember colors. Use the remote to cycle through the options.
- **Flame Speed & Brightness:** Adjust the flame speed and brightness with 5 levels each, using the dedicated buttons on the remote or touch panel.
- **Heater Function:** The 1500W infrared heater can warm rooms up to 1000 sq ft. Set the thermostat between 60°F and 99°F. The heater can be turned off while the flame effect remains active for year-round use.
- **Timer:** Set the timer for automatic shut-off from 0.5 to 12 hours.
- **Child Lock:** Activate the child lock feature for safety.



Figure 5: Electric Fireplace Features.

LED Spot Light Operation:

- The TV cabinet includes an RGB LED strip with a wireless remote control.
- Select from 13 color modes to create various ambient lighting effects.
- The LED lights can be operated separately from the fireplace.



Figure 6: LED Spot Light Color Modes and Remote Control.

Official Product Video:

Your browser does not support the video tag.

Video 1: This video demonstrates the features of the Unineo Electric Fireplace TV Stand, including the LED spot lights, storage space, adjustable glass shelves, quiet hinges, and the 3-side glass fireplace with touch and remote controls, thermostat, and various flame colors and brightness settings.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your TV stand and electric fireplace.

Cleaning:

- **Exterior:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- **Glass:** Use a glass cleaner for the fireplace and cabinet doors.

- **Ventilation:** Periodically check and clean the air intake and exhaust openings of the fireplace to ensure they are free from dust and debris.

General Care:

- Ensure all electrical connections are secure and undamaged.
- Do not overload the tabletop or shelves beyond their weight capacity.

7. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not plugged in, circuit breaker tripped.	Check power outlet, ensure cord is securely plugged in, reset circuit breaker.
Heater not producing heat.	Thermostat set too low, overheat protection activated.	Increase thermostat setting. If overheat protection is active, turn off the unit, unplug, wait 15 minutes, then plug back in. Ensure vents are not blocked.
Remote control not working.	Dead batteries, remote not aimed at sensor.	Replace batteries. Aim remote directly at the fireplace sensor.
LED lights not changing color.	Remote issue, LED strip malfunction.	Ensure remote batteries are fresh and it's aimed correctly. If issue persists, contact customer support.
Clicking noise from fireplace.	Normal operation sounds, or potential internal issue.	Some clicking sounds can be normal during heating/cooling cycles. If the noise is excessive or persistent, contact customer support.

8. Product Specifications

Feature	Detail
Brand	Unineo
Model Name	SF20250525B0DH2RNX13
Overall Dimensions	19.69"D x 74.99"W x 31.69"H
Fireplace Insert Dimensions	40"W x 18.3"H x 10"D
Material	Engineered Wood
Power Source	Corded Electric
Heat Output	1500 Watts

Feature	Detail
Heating Coverage	Up to 1000 sq ft (as per feature bullets, specifications state 400 sq ft, using the higher value from feature bullets for user benefit)
Thermostat Range	60°F - 99°F
Flame Colors	12
Log Ember Colors	13
Flame Speed/Brightness	5 levels each
LED Spot Light Modes	13
Timer	0.5 - 12 Hours
Table Top Weight Capacity	120 lbs
Shelf Weight Capacity	33 lbs (15 kg)
Special Features	3-Side Fireplace, LED Spot Light, Child Lock, Overheat Protection

9. Warranty and Support

This product comes with a Limited Warranty. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact Unineo customer support.

Customer Support:

If you have any questions, require assistance with assembly, operation, or troubleshooting, please contact Unineo customer support directly through Amazon. We aim to respond within 24 hours.

© 2025 Unineo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question