

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SUNGOOYUE](#) /
- › [SUNGOOYUE Y60 2.4G Wireless Keyboard User Manual](#)

SUNGOOYUE Y60

SUNGOOYUE Y60 2.4G Wireless Keyboard User Manual

Model: Y60 | Brand: SUNGOOYUE

1. INTRODUCTION

Thank you for choosing the SUNGOOYUE Y60 2.4G Wireless Keyboard. This ergonomic, 75-key keyboard features a unique punk style design and offers reliable 2.4G wireless connectivity for both home and office environments. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- 1 x SUNGOOYUE Y60 2.4G Wireless Keyboard
- 1 x USB 2.4G Receiver

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert two (2) AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: The underside of the keyboard with the battery compartment open, indicating where to insert two AAA batteries.

3.2 Connecting the 2.4G Receiver

1. Take out the USB 2.4G receiver from the keyboard's storage slot (usually located near the battery compartment).
2. Plug the USB receiver into an available USB port on your computer.
3. Your computer should automatically detect and install the necessary drivers. This process may take a few moments.
4. Once the drivers are installed, the keyboard is ready for use.



Image: A close-up view of the compact USB 2.4G wireless receiver.

3.3 System Compatibility

This keyboard is compatible with the following operating systems:

- Windows XP
- Windows 7
- Windows 8
- Windows 10

4. OPERATING INSTRUCTIONS

The SUNGOOYUE Y60 keyboard features a 75-key layout with an ergonomic design for comfortable typing. Simply begin typing after successful setup. The 2.4G wireless connection provides a stable link up to 10 meters from the receiver.



Image: A top-down view of the SUNGOOYUE Y60 keyboard, highlighting its 75-key layout and distinctive round keycaps.

4.1 Multimedia Function Keys

The keyboard includes multimedia function keys integrated into the F1-F12 keys. These functions are typically accessed by pressing the **Fn** key simultaneously with the desired F-key. Refer to the keycap legends for specific multimedia controls (e.g., volume control, media playback).

5. POWER SAVING

The SUNGOOYUE Y60 keyboard is equipped with intelligent power-saving technology. To conserve battery life, the keyboard will enter a sleep mode after a period of inactivity. To wake the keyboard, simply press any key. Ensure to turn off the keyboard using the power switch (if available) when not in use for extended periods, such as overnight or during travel.

6. MAINTENANCE

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the keyboard. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the keyboard's performance degrades or it stops responding. Always use new AAA batteries and dispose of old batteries responsibly.
- **Storage:** When not in use for a long time, remove the batteries and store the keyboard in a dry, cool place.

7. TROUBLESHOOTING

If you encounter issues with your keyboard, please refer to the following troubleshooting steps:

- **Keyboard not responding:**
 - Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
 - Ensure the USB 2.4G receiver is securely plugged into a working USB port on your computer. Try a different USB port.
 - Move the keyboard closer to the receiver to rule out range issues (maximum 10 meters).
 - Restart your computer.
- **Keys not working or delayed input:**
 - This could indicate low battery power. Replace the batteries.
 - Ensure there are no obstructions under the keycaps.
 - Check for interference from other wireless devices.
- **Connection drops frequently:**
 - Ensure the receiver is not blocked by metal objects or other electronic devices.
 - Try plugging the receiver into a front USB port if using a desktop computer, or use a USB extension cable to position the receiver closer to the keyboard.

8. SPECIFICATIONS

Model	Y60
Brand	SUNGOOYUE
Connection Method	2.4G Wireless
Number of Keys	75 keys
Keycap Style	Punk
Battery Type	2 x AAA battery (not included)
Operating Distance	Up to 10 meters
System Compatibility	Windows XP, Win7, Win8, Win10

Keyboard Description	Ergonomic
Recommended Use	Office

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official SUNGOOYUE website. Keep your purchase receipt as proof of purchase for any warranty claims.