

[Manuals.plus](#) /

> [CrossBeats](#) /

> CrossBeats Shuffl ANC Neckband Bluetooth Wireless Earphones User Manual

CrossBeats Shuffl

CrossBeats Shuffl ANC Neckband Bluetooth Wireless Earphones User Manual

Model: Shuffl | Brand: CrossBeats

1. INTRODUCTION

Welcome to the CrossBeats Shuffl ANC Neckband Earphones user manual. This guide provides essential information on how to set up, operate, maintain, and troubleshoot your new earphones. The Shuffl ANC Neckband offers an immersive audio experience with Active Noise Cancellation, dual device pairing, and extended playtime, designed for both music enthusiasts and gamers.



Image: CrossBeats Shuffl ANC Neckband Earphones, highlighting its noise cancellation capabilities.

2. WHAT'S IN THE BOX

Upon unboxing your CrossBeats Shuffl ANC Neckband Earphones, please ensure all the following components are present:

- CrossBeats Shuffl ANC Neckband Earphones
- USB Type-C Charging Cable

- Additional Ear Cushions (various sizes)
- User Manual
- Warranty Card

3. PRODUCT OVERVIEW

The CrossBeats Shuffl ANC Neckband features a flexible neckband design with integrated controls and magnetic earbuds for convenience. The earbuds are equipped with anti-bacterial form ear tips and shark fin hooks for a secure and comfortable fit.



Image: Front view of the CrossBeats Shuffl ANC Neckband Earphones.

4. SETUP

4.1 Charging the Earphones

Before first use, fully charge your Shuffl ANC Neckband. Use the provided USB Type-C cable to connect the earphones to a compatible power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status.

- **SnapCharge Technology:** A 10-minute charge provides up to 12 hours of playtime.
- **Total Playtime:** Up to 120 hours on a full charge.



Image: Illustration of the CrossBeats Shuffl ANC Neckband Earphones highlighting its 120+ hours of playtime.

4.2 Bluetooth Pairing

The Shuffl ANC Neckband uses Bluetooth v5.4 for stable and efficient connectivity.

1. Ensure the earphones are powered on (separate magnetic earbuds).
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available devices and select "CrossBeats Shuffl" from the list.
4. Once connected, the LED indicator on the neckband will confirm successful pairing.

Dual Device Pairing: The Shuffl ANC Neckband supports simultaneous connection to two devices. After pairing with the

first device, disable Bluetooth on it. Pair with the second device. Then, re-enable Bluetooth on the first device; the earphones should automatically connect to both.

Dual Pairing Neckband



Mobile to PC



Mobile to Mobile



Image: Visual representation of the dual pairing feature, connecting to both mobile and PC, and mobile to mobile.



Image: Close-up of the neckband's internal components, highlighting the Bluetooth 5.4 Low Energy Chipset for stable connection.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

The Shuffl ANC Neckband features a Magnetic Hall Switch for effortless power control.

- **Power On:** Separate the magnetic earbuds. The earphones will automatically power on and attempt to connect to the last paired device.
- **Power Off:** Bring the magnetic earbuds together. The earphones will automatically power off.



Image: Demonstration of the Magnetic Hall Switch for powering the earphones on and off by separating or joining the earbuds.

5.2 Active Noise Cancellation (ANC) & Transparency Mode

The Shuffl ANC Neckband provides up to 30dB of Active Noise Cancellation to minimize ambient sounds, allowing for a more focused listening experience. It also features a Transparency Mode to let you hear your surroundings when needed.

- Refer to the physical controls on the neckband for switching between ANC On, ANC Off, and Transparency Mode. (Specific button function may vary, refer to included quick start guide for exact button mapping).

ANC Mode with 30dB Noise Cancelling



Image: Earbud with sound waves indicating 30dB Noise Cancelling capability.




Image: Illustrates the ability to switch between ANC Off, ANC On, and Transparency modes to adapt to different environments.

5.3 Dedicated Gaming Mode

Activate the dedicated Gaming Mode for an ultra-low latency audio experience of 40ms, ensuring synchronized audio and visuals during gameplay.

- Refer to the physical controls on the neckband for activating Gaming Mode.

Dedicated Game Mode



Image: The neckband earphones positioned with a smartphone showing a game, emphasizing the dedicated game mode.



Image: The neckband earphones depicted in a gaming scenario, highlighting its suitability for gaming with low latency.

5.4 AI Voice Assistant

Access your device's AI voice assistant (Siri or Google Assistant) directly from your earphones.

- Press and hold the designated button on the neckband to activate the voice assistant.





Image: Close-up of the earphone controls, illustrating the activation of Siri and Google Assistant.

5.5 Hands-Free Calling with AI ENC

Make and receive calls with clarity thanks to the built-in microphone and AI Environmental Noise Cancelling (ENC) technology, which reduces background noise during calls.

Hands-Free Calling



Escape the hassle of holding your mobile phones during calls

Image: A person using the neckband earphones for hands-free calling.

5.6 Audio Experience

The Shuffl ANC Neckband is engineered for superior sound quality:

- **14.2mm Ti Dynamic Drivers:** Deliver powerful bass and clear audio.
- **Built-in Subwoofer with EcoBlast Technology:** Enhances bass response for a rich sound profile.
- **360° Audio Effect:** Provides an immersive soundstage.

14.2mm Ti Drivers designed in 2024

With bass reverberating on maximum precision.





Image: Detailed view of the 14.2mm Ti Drivers, illustrating their design for precise bass and audio.

360° Audio Effect



Immerse yourself in the tranquility of our 360° Surround Audio that brings every beat to life making you feel music not just listen!

Image: Illustrates the immersive 360° Audio Effect provided by the earphones.



EQ Personalised for You - Balanced Bass, Perfect Treble

Image: An equalizer graph demonstrating the balanced bass and perfect treble audio profile.

6. MAINTENANCE

To ensure the longevity and optimal performance of your CrossBeats Shuffl ANC Neckband Earphones, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the neckband and earbuds with a soft, dry cloth. For ear tips, you can gently remove them and clean with a damp cloth, ensuring they are completely dry before reattaching.
- **Storage:** When not in use, store the earphones in a clean, dry place, away from extreme temperatures and direct sunlight.
- **Water Resistance:** The earphones are water resistant (IPX4 rating, if applicable, based on 'Water Resistant' spec). Avoid submerging them in water or exposing them to heavy rain. Dry thoroughly if they get wet from sweat or light splashes.
- **Ear Tips:** The anti-bacterial form ear tips help maintain hygiene. Replace them if they become worn or damaged.

7. TROUBLESHOOTING

If you encounter any issues with your CrossBeats Shuffl ANC Neckband Earphones, please refer to the following common solutions:

Problem	Possible Solution
Earphones do not power on.	Ensure the earbuds are separated. Check battery level and charge the earphones if necessary.
Cannot pair with a device.	Ensure Bluetooth is enabled on your device and the earphones are in pairing mode. Move earphones closer to the device. Forget the device from your phone's Bluetooth list and try pairing again.
No sound or low volume.	Check the volume levels on both the earphones and your connected device. Ensure the earphones are properly connected. Try playing different audio sources.
Sound cutting in and out.	Move closer to your connected device. Avoid obstacles between the earphones and the device. Reduce interference from other wireless devices.

Problem	Possible Solution
Low battery announcement is too loud/frequent.	This is a characteristic of the earphones when battery level drops to 10%. To stop the announcements, charge the earphones until the battery level is above 20%.
ANC not working effectively.	Ensure ANC mode is activated. Check that the earbuds are properly seated in your ears to create a good seal.

8. SPECIFICATIONS

Detailed technical specifications for the CrossBeats Shuffl ANC Neckband Earphones:

Model Name	Shuffl
Noise Control	Active Noise Cancellation (30 dB)
Connectivity Technology	Wireless, Bluetooth
Bluetooth Version	5.4
Audio Latency	40 Milliseconds (Gaming Mode)
Audio Driver Size	14.2 mm Ti Dynamic Drivers
Playtime	Up to 120 Hours
Fast Charging	10 Mins charge = 12 Hours Playtime (SnapCharge)
Control Type	Button, Touch
Water Resistance Level	Water Resistant
Item Weight	30 Grams
Special Features	Sweatproof, AI Voice Assistant, Sportier Neckband, Fast Charging, Microphone Included, Environmental Noise Cancelling
Included Components	Ear Cushions, Cable, User Manual, Warranty Card

9. WARRANTY & SUPPORT

Your CrossBeats Shuffl ANC Neckband Earphones come with a warranty. Please refer to the included warranty card for details regarding the warranty period and terms and conditions.

For any product-related queries, technical support, or warranty claims, please contact CrossBeats customer service through the contact information provided on your warranty card or the official CrossBeats website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question