

[Manuals.plus](#) /

› [Wodeer](#) /

› Wodeer Narrow Shoe Cabinet EC2003 Instruction Manual

Wodeer EC2003

Wodeer Narrow Shoe Cabinet EC2003 Instruction Manual


Model: EC2003 | Brand: Wodeer

1. SAFETY INFORMATION

Always secure the cabinet to the wall using the provided hardware to prevent tipping. Read and follow all assembly instructions carefully to avoid injury. Keep the area around the cabinet clear of obstructions and never leave small children or pets unattended near the cabinet.

Prevent Tip-Over Incidents

Ensuring your family's safety



✓ With Anti-toppling Device



✗ Without Anti-toppling Device

Anti-Toppling Device



Image: Illustration demonstrating the importance of installing the anti-tipping device to ensure stability and prevent accidents, especially in homes with children.

2. PRODUCT OVERVIEW

The Wodeer Narrow Shoe Cabinet EC2003 is designed for efficient shoe storage in entryways, hallways, and other narrow spaces. It features a slim profile and multiple flip drawers to keep footwear organized and out of sight.

Key Features:

- **Space-Saving Design:** Ultra-slim 9.26-inch depth, ideal for narrow areas.
- **Large Capacity:** Innovative 2-tier flip drawer structure provides ample storage.
- **Adjustable Shelves:** Removable and adjustable shelves in each flip drawer accommodate various shoe types, including high heels and boots.
- **Durable Construction:** Crafted from high-quality, waterproof engineered wood with a wear-resistant surface.
- **Enhanced Stability:** Includes a heavy-duty anti-tip kit for secure wall mounting.



Image: Product dimensions illustrating the compact design suitable for narrow spaces.



Image: Visual representation of the cabinet's large storage capacity and versatility for different shoe types.

Your browser does not support the video tag.

Video: An official Wodeer video demonstrating the shoe cabinet's features, including the flip drawers and overall storage capacity.

3. SETUP AND ASSEMBLY

This shoe cabinet requires assembly. All necessary hardware and detailed instructions are included in the package. Please follow the steps carefully to ensure proper and safe construction.

Before You Begin:

- Unpack all components and verify against the parts list in the included manual.
- Ensure you have the required tools (e.g., screwdriver, hammer).
- Assemble on a soft, clean surface to prevent scratches.

Assembly Steps:

1. Identify all parts and hardware using the provided labels.

2. Follow the step-by-step diagrams and instructions in the assembly manual.
3. Securely fasten all connections, but do not overtighten screws.
4. Install the anti-tip kit as directed to anchor the cabinet to the wall.



Image: A visual comparison demonstrating the organizational improvement achieved by using the shoe cabinet.

4. OPERATING INSTRUCTIONS

Using the Flip Drawers:

Each of the three drawers operates with a flip-down mechanism. Gently pull the top edge of a drawer outwards to open it. The drawer will tilt forward, revealing two tiers for shoe storage. Push the drawer back into place until it is flush with the cabinet to close it.

Adjusting Shelves:

The shelves within each flip drawer are removable and adjustable. To adjust a shelf, carefully lift it from its current position and place it into a different set of slots to change the height. To remove a shelf, simply lift it out. This allows customization for various shoe sizes and styles, such as high heels or ankle boots.



Image: Detail of the pull-out shoe rack mechanism, highlighting the two-tier storage within each drawer.



Image: Close-up of the shoe cabinet's interior, demonstrating the adjustable shelves for accommodating different shoe heights.

5. MAINTENANCE AND CARE

Cleaning:

The cabinet's wear-resistant white surface is easy to clean. Use a soft, damp cloth with a mild, non-abrasive cleaner. Wipe dry immediately to prevent water damage. Avoid harsh chemicals or abrasive materials that could damage the finish.

General Care:

- Periodically check all screws and connections to ensure they remain tight.
- Avoid placing excessively heavy items on top of the cabinet.
- Keep the cabinet away from direct sunlight and extreme temperature changes to prevent material warping or discoloration.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Cabinet feels unstable or wobbly.	Anti-tip kit not installed or loose connections.	Ensure the anti-tip kit is securely mounted to the wall. Check and tighten all assembly screws.
Drawers do not flip smoothly or get stuck.	Obstruction, incorrect assembly of drawer mechanism, or overloaded drawer.	Check for any items blocking the drawer's movement. Review assembly instructions for the drawer mechanism. Do not overload drawers beyond their capacity.
Missing or damaged parts upon arrival.	Shipping damage or packaging error.	Contact Wodeer customer support immediately for free parts replacement.

7. SPECIFICATIONS

Feature	Detail
Brand	Wodeer
Model Number	EC2003 (WD-2003-80-10)
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	9.25" x 31.51" x 47.24"
Item Weight	52.5 Pounds
Number of Drawers	3 (Flip Drawers)
Number of Shelves	6 (2 per drawer, adjustable/removable)
Installation Type	Freestanding (with wall-mount anti-tip kit)
Room Type	Entryway, Hallway, Living Room
Additional Features	Anti-Tipping Device Included

8. WARRANTY AND SUPPORT

Wodeer stands behind the quality of its products. Each shoe storage rack comes with a worry-free service guarantee, including free parts replacement.

If you receive any damaged pieces or have missing parts during assembly, please contact our 24/7 support team for a fast, free replacement. We are committed to ensuring your entryway furniture arrives perfect and remains functional.

For returns, the product is eligible for a refund or replacement within 30 days of purchase, in accordance with the return policy.

For further assistance or inquiries, please refer to the contact information provided in your product packaging or visit the official Wodeer store on Amazon: [Wodeer Store](#).