

[Manuals.plus](#) /

› [Dream On Me](#) /

› Dream On Me Fisher-Price Play All Day Portable Playard Instruction Manual

Dream On Me 435FP

Fisher-Price Play All Day Portable Playard

MODEL: 435FP-RB

Manufactured by Dream On Me

Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Fisher-Price Play All Day Portable Playard. Please read all instructions carefully before use and retain this manual for future reference. This playard is designed for children aged 6 to 36 months, weighing up to 25 pounds, and who are less than 35 inches tall.

Product Features

- **One-Hand Fold:** Designed for quick and easy setup and takedown.
- **Breathable Mesh Walls:** Four mesh sides ensure optimal airflow and visibility.
- **Sturdy Frame:** Provides a secure and stable environment.
- **Built-in Wheels:** Allows for effortless mobility between rooms.
- **Removable Foam Pad:** Offers a comfortable surface for play and rest, and is easy to clean.
- **Compact Design:** Folds compactly for storage and travel, includes a convenient carry bag.
- **ASTM Certified:** Meets safety standards for playards.

Play All Day Playard



Figure 1: Key features of the Play All Day Playard.

Setup Instructions

The Fisher-Price Play All Day Portable Playard is designed for tool-free assembly. Follow these steps to set up your playard:

1. **Unpack:** Remove the playard from its carry bag and unfasten any securing straps.
2. **Unfold Frame:** Stand the playard upright. Ensure the center of the floor is not pushed down. Pull up on the center of each side rail until it locks into place. You should hear a click. If a rail does not lock, pull it up again firmly.
3. **Lock Side Rails:** Once all four side rails are locked, push down the center of the playard floor until it lies flat and is securely in place.
4. **Insert Mattress Pad:** Place the included foam mattress pad firmly into the bottom of the playard.

Play All Day

Playard



©2024 Mattel.

Figure 2: Playard fully assembled.

Your browser does not support the video tag.

Video 1: Official demonstration of the Play All Day Playard setup and folding process.

Operating Instructions

Using your playard for daily activities and travel is straightforward:

Folding the Playard

To fold the playard for storage or transport, follow these steps:

1. **Remove Mattress Pad:** Take out the foam mattress pad from the playard.
2. **Pull Up Center Strap:** Locate the strap in the center of the playard floor and pull it upwards. This will cause the floor to begin collapsing.
3. **Unlock Side Rails:** On each side rail, locate the 'Press to Unlock' mechanism (usually a button or squeeze tab).

Press the mechanism while simultaneously pushing the rail downwards to unlock it. Repeat for all four rails.

4. **Collapse:** Once all rails are unlocked and the floor is partially collapsed, push the sides inward to fully fold the playard into a compact shape.
5. **Secure and Store:** Use the provided straps to secure the folded playard and place it into the carry bag.

Easy to Fold & Travel Ready

Folds easily with just one hand



©2024 Mattel.

Figure 3: Step-by-step illustration of the playard folding process.

Maintenance and Cleaning

Regular maintenance and cleaning will ensure the longevity and hygiene of your playard.

- **Fabric Cleaning:** The fabric surfaces of the playard are wipeable. Use a damp cloth and mild soap to clean any soiled areas. Do not use harsh abrasives or bleach.
- **Mattress Pad:** The foam mattress pad can be wiped clean with a damp cloth and mild soap. Allow it to air dry completely before placing it back in the playard.
- **Frame:** Wipe the metal and plastic parts of the frame with a damp cloth. Ensure all parts are dry before folding or storing.
- **Inspection:** Periodically check the playard for loose screws, worn parts, or torn mesh. Discontinue use if any damage is found and contact customer support for replacement parts or repair.

Light Weight and Portable



©2024 Mattel.

Figure 4: The playard is designed for easy cleaning and durability.

Troubleshooting

If you encounter issues with your playard, refer to the following common solutions:

- **Difficulty Locking Side Rails:** Ensure the center of the playard floor is not pushed down before attempting to lock the side rails. The rails must be pulled up firmly until they click into place. If the center is already pushed down, pull it up slightly to release tension on the rails, then lock the rails, and finally push the center down.
- **Difficulty Unlocking Side Rails:** Make sure you are pressing the 'Press to Unlock' mechanism on each rail while simultaneously pushing the rail downwards. Sometimes a firm, quick motion is required.
- **Playard Not Folding Completely:** Ensure the mattress pad is removed and the center strap on the floor is pulled up completely before attempting to unlock the side rails. All four rails must be unlocked for the playard to fold compactly.

Specifications

Product Dimensions (L x W x H)	39.3 x 27.5 x 27 inches
Item Model Number	435FP-RB
Product Weight	15.43 pounds
Maximum Weight Recommendation	25 Pounds
Age Range	6-36 months
Material Composition	Aluminum, Polyester

Product Specs:

Product Weight:
16.94 LBS

Weight Capacity:
25 LBS



Convenient carry bag

©2024 Mattel.

Figure 5: Detailed product specifications.

Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always ensure the playard is fully assembled and all locking mechanisms are engaged before placing a child inside.
- Never leave a child unattended in the playard.
- Do not use this playard if any parts are broken, torn, or missing.
- Do not substitute parts. Contact the manufacturer for replacement parts.
- To prevent falls, do not leave a child in the playard when they are able to climb out.
- To prevent strangulation, do not place items with a string around a child's neck, such as hood strings or pacifier cords. Do not suspend strings over a playard or attach strings to toys.
- To prevent suffocation, never use plastic shipping bags or other plastic film as mattress covers not sold by the manufacturer. They can cause suffocation.
- Never use a mattress or padding thicker than what is provided or recommended by the manufacturer.
- Keep the playard away from open flames, heaters, or other heat sources.
- Ensure the playard is placed on a flat, level surface.

Warranty and Support

Dream On Me stands behind the quality of its products. For specific warranty details, please refer to the documentation included with your purchase or visit the official Dream On Me website. If you have any questions, require replacement parts, or need assistance with assembly or operation, please contact Dream On Me customer support. Contact information can typically be found on the product packaging or the manufacturer's website.

© 2024 Dream On Me. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question